



I N D E X

Numerics

- 2.4-GHz WMIC, contrasted with 4.9-GHz WMIC **1-8**
- 802.11g **3-6, 3-9**
- 802.1x authentication **4-13**

A

AAA

- server group **4-25**
- aaa authentication login command **4-24**
- aaa authorization command **4-27**
- aaa new-model command **4-22, 4-25**
- abbreviating commands **A-4**
- access point
 - security settings, matching client devices **8-24**
 - WDS **9-1**

accounting

- with RADIUS **4-28**
- with TACACS+ **4-32, 4-37**

accounting command

- 5-2**

administrator access

- 4-21**

Advanced Encryption Standard (AES)

1-7

AES-CCMP

- 8-1**

Aironet 802.11 extensions

4-40

Aironet Client Utility (ACU)

17-3

antenna gains

B-4

antennas

3-13

ARPANET

4-1

attributes, RADIUS

- vendor-proprietary **4-30**

- vendor-specific **4-29**

authentication

- EAP server **4-20, 8-3**
- local mode with AAA **4-38**
- MAC address **8-5**
- NTP associations **4-47**
- RADIUS
 - key **4-22**
 - login **4-24**
 - server configuration for fast secure roaming **9-5**
 - TACACS+
 - defined **4-32**
 - key **4-34**
 - login **4-34, 4-35**
 - authentication network-eap command **9-10**
 - authentication types
 - CCKM key management **8-5**
 - EAP-FAST **8-4**
 - EAP-TLS **8-4**
 - EAP-TTLS **8-5**
 - MAC address **8-5**
 - matching on root devices and non-root bridges **8-24**
 - Network-EAP **8-3**
 - open **8-1**
 - shared key **8-2**
 - using WPA key management **8-6**
 - authorization
 - with RADIUS **4-27**
 - with TACACS+ **4-32, 4-36**

autoinstall

5-2

B

- banner login command **4-5**
- banner motd command **4-4**

- banners
 configuring
 login [4-5](#)
 message-of-the-day login [4-4](#)
 default configuration [4-3](#)
 when displayed [4-3](#)
- basic data rate [3-1](#)
- basic settings
 checking [17-2](#)
- beacon period command [3-18](#)
- blocking communication between clients [3-16](#)
- bootloader [17-7](#)
- BOOTP [4-2](#)
- BR350 interoperability [6-2](#)
- bridge-group command [3-17, 6-9](#)
- Bridge Group Virtual Interface (BVI) [2-3](#)
- bridge interoperability [6-2](#)
- bridge protocol data unit (BPDU) [6-1](#)
- BSSIDs [5-3](#)
-
- C
- carrier busy test [3-21](#)
- CCKM [8-5](#)
- CDMA [1-1](#)
- CDP
 disabling for routing device [13-4](#)
 enabling and disabling [13-4](#)
 monitoring [13-5](#)
- Centralized Key Management (CCKM) [8-1](#)
- certificates
 configuring [8-6](#)
- channel
 spacing [3-7, 3-9](#)
- channel command [3-7](#)
- channel data rates [3-8, 3-10](#)
- channel settings [3-6](#)
- cipher suites
 enabling [8-5](#)
- with WPA [8-8](#)
- Cisco Centralized Key Management
See CCKM
- Cisco Centralized Key Management (CCKM) [1-7](#)
- Cisco IOS image release [1-8](#)
- Cisco IOS image upload [A-9](#)
- Cisco TAC [17-1](#)
- CiscoWorks 2000 [14-4](#)
- CKIP [1-7](#)
- CKIP (Cisco Key Integrity Protocol) [8-2](#)
- CLI
 abbreviating commands [A-4](#)
 command modes [A-2](#)
 editing features
 enabling and disabling [A-6](#)
 keystroke editing [A-7](#)
 wrapped lines [A-8](#)
 error messages [A-4](#)
 filtering command output [A-9](#)
 getting help [A-3](#)
 history
 changing the buffer size [A-5](#)
 described [A-5](#)
 disabling [A-6](#)
 recalling commands [A-5](#)
 no and default forms of commands [A-4](#)
- client communication, blocking [3-16](#)
- clock
See system clock
- clock set command [4-44](#)
- clock timezone command [4-45](#)
- CMIC [1-7, 8-2](#)
- CMIC (Cisco Message Integrity Check)
See CMIC
- command-line interface
See CLI
- command modes [A-2](#)
- commands
 aaa authentication login [4-24](#)

aaa authorization **4-27**
 aaa new-model **4-22, 4-25**
 abbreviating **A-4**
 accounting **5-2**
 authentication network-eap **9-10**
 banner login **4-5**
 banner motd **4-4**
 beacon period **3-18**
 bridge-group **3-17, 6-9, 10-4**
 cdp enable **13-4**
 cdp holdtime **13-3**
 cdp timer **13-3**
 channel **3-7**
 clear cdp counters **13-5**
 clear cdp table **13-5**
 client profile multiple **6-5**
 clock set **4-44**
 clock timezone **4-45**
 concatenation **3-14**
 del **17-4**
 distance **3-15**
 dot11 interface speed **9-11**
 encapsulation **10-3**
 encapsulation dot1q **10-4**
 encryption **6-5**
 encryption mode cipher **8-1**
 fragment-threshold **3-19**
 hostname **4-1**
 infrastructure-client **3-16**
 infrastructure SSID **5-2**
 interface dot11radio **6-1**
 interface dot11radio0 **10-3**
 interface fastEthernet0.x **10-4**
 ip domain-lookup **4-3**
 ip domain-name **4-2**
 ip name-server **4-2**
 login authentication **4-25**
 no and default **A-4**
 ntp authenticate **4-47**
 ntp peer **4-49**
 packet retries **3-19**
 parent **3-20**
 parent timeout **3-20**
 payload-encapsulation **3-14**
 power **3-5, 3-8**
 prompt **4-1**
 radius-server host **4-23**
 rts **3-18**
 rts retries **3-18**
 set **17-6**
 set BOOT **17-6**
 setting privilege levels **4-10**
 show cdp **13-5**
 show cdp entry **13-5**
 show cdp interface **13-5**
 show cdp neighbors **13-5**
 show cdp traffic **13-5**
 show controller dot11radio **3-4**
 show dot11 carrier busy **3-21**
 spacing **3-7, 3-9**
 speed **3-1, 3-3**
 ssid **6-1**
 tftp_init **17-5**
 vlan **5-2**
 community strings
 configuring **14-5**
 overview **14-4**
 concatenation **3-18, 3-19**
 concatenation command **3-14**
 configuration files
 creating using a text editor **15-9**
 deleting a stored configuration **15-18**
 downloading
 preparing **15-10, 15-12, 15-15**
 reasons for **15-8**
 using FTP **15-12**
 using RCP **15-16**
 using TFTP **15-10**

- guidelines for creating and using [15-8](#)
 invalid combinations when copying [15-4](#)
 types and location [15-9](#)
 uploading
 preparing [15-10, 15-12, 15-15](#)
 reasons for [15-8](#)
 using FTP [15-14](#)
 using RCP [15-17](#)
 using TFTP [15-11](#)
 connections, secure remote [4-39](#)
 console cable [2-1](#)
 console port
 cable [2-2](#)
 cryptographic message integrity [8-2](#)
 crypto pki CLI [8-6](#)
 crypto software image [4-39](#)
-
- D
- data rate
 basic [3-1](#)
 setting [3-1](#)
 throughput [3-2](#)
 data rates [3-8, 3-10](#)
 date
 See NTP and system clock
 daylight saving time [4-46](#)
 default
 commands [A-4](#)
 configuration, resetting [17-3](#)
 default configuration
 banners [4-3](#)
 DNS [4-2](#)
 NTP [4-47](#)
 password and privilege level [4-6](#)
 SNMP [14-5](#)
 system message logging [16-3](#)
 TACACS+ [4-33](#)
 del command [17-4](#)
- Delivery Traffic Indication Message (DTIM) [5-3](#)
 DHCP [2-3, 4-2](#)
 directories
 changing [15-3](#)
 creating and removing [15-4](#)
 displaying the working [15-3](#)
 distance command [3-15](#)
 distance setting [3-15](#)
 DNS
 default configuration [4-2](#)
 display configuration [4-3](#)
 overview [4-2](#)
 setting up [4-2](#)
 domain names
 DNS [4-2](#)
 Domain Name System
 See DNS
 dot11 interface speed command [9-11](#)
 downloading
 configuration files
 preparing [15-10, 15-12, 15-15](#)
 reasons for [15-8](#)
 using FTP [15-12](#)
 using RCP [15-16](#)
 using TFTP [15-10](#)
 image files
 deleting old image [15-21](#)
 preparing [15-19, 15-22, 15-27](#)
 reasons for [15-18](#)
 using FTP [15-23](#)
 using RCP [15-29](#)
 using TFTP [15-20](#)
-
- E
- editing features
 enabling and disabling [A-6](#)
 keystrokes used [A-7](#)
 wrapped lines [A-8](#)

- EIRP **B-4**
- enable password **4-7**
- enable secret password **4-7**
- encrypted software image **4-39**
- encryption for passwords **4-7**
- encryption mode cipher command **8-1**
- Enhanced Distributed Channel Access (EDCA) **1-7**
- error messages
- during command entry **A-4**
 - setting the display destination device **16-5**
 - severity levels **16-7**
 - system message format **16-2**
- Ethernet encapsulation **3-14**
- Ethernet indicator **17-1**
- Ethertype protocols
- protocols
 - Ethertype **C-2**
- Express Security page **2-4**
- Extensible Authentication Protocol
- See EAP*
- extensions, Aironet **4-40**
-
- F**
- Fast Ethernet Switch mobile interface card (FESMIC) **2-1**
- fast secure roaming
- and WDS **9-4**
 - authentication server **9-5**
- features **1-7**
- files
- copying **15-4**
 - deleting **15-5**
 - displaying the contents of **15-7**
 - tar
 - creating **15-5**
 - displaying the contents of **15-6**
 - extracting **15-7**
 - image file format **15-19**
- file system
- displaying available file systems **15-1**
- displaying file information **15-3**
- local file system names **15-1**
- network file system names **15-4**
- setting the default **15-3**
- filtering
- show and more command output **A-9**
- filters
- configuring using CLI **12-2**
 - protocol **C-1**
- Flash device **15-1**
- forward-delay time **6-6**
- fragmentation threshold **3-19**
- fragment-threshold command **3-19**
- frequencies **B-2**
- FTP
- accessing MIB files **D-2**
 - configuration files
 - downloading **15-12**
 - overview **15-11**
 - preparing the server **15-12**
 - uploading **15-14**
 - image files
 - deleting old image **15-26**
 - downloading **15-23**
 - preparing the server **15-22**
 - uploading **15-26**
-
- G**
- get-bulk-request operation **14-2**
- get-next-request operation **14-2, 14-4**
- get-request operation **14-2, 14-4**
- get-response operation **14-2**
- global configuration mode **A-3**
- GPRS **1-4**
- group key updates **8-22**

H

help, for the command line **A-3**
history
 changing the buffer size **A-5**
 described **A-5**
 disabling **A-6**
 recalling commands **A-5**
history table, level and number of syslog messages **16-8**
host name, ARPANET rules **4-1**
hostname command **4-1**

I

image, operating system **17-5**
indicators **17-1**
infrastructure-client command **3-16**
infrastructure SSID command **5-2**
inter-client communication, blocking **3-16**
interface configuration mode **A-3**
Interior Gateway Protocol (IGP) **1-4**
IP address **2-3**
 release and renew **2-1**
ip domain-lookup command **4-3**
ip domain-name command **4-2**
ip name-server command **4-2**
IP port protocols **C-4**
IP protocols
 protocols
 IP **C-3**
ISO designators for protocols **C-1**

K

KCK **GL-4**
KEK **GL-4**
key features **1-7**
key management types **8-8**

L

LEAP
 setting on client and access point **8-24**
LED indicators
 Ethernet **17-1**
 radio traffic **17-1**
 status **17-1**
Load balancing **4-40**
login authentication
 with RADIUS **4-24**
 with TACACS+ **4-34, 4-35**
login authentication command **4-25**
login banners **4-3**
log messages
 See system message logging

M

MAC address
 authentication **8-5**
 troubleshooting **17-3**
management options
 CLI **A-1**
memory
 Flash **15-1**
Message Authentication Code **GL-5**
Message Integrity Check
 See MIC
Message Integrity Code (MIC), definition **GL-5**
message-of-the-day (MOTD) **4-3**
messages
 to users through banners **4-3**
method list **4-21**
MIBs
 accessing files with FTP **D-2**
 location of files **D-2**
 overview **14-1**
 SNMP interaction with **14-4**

MIC [4-40, 8-1, 17-3](#)
 MoIP tunnel [1-5](#)
 monitoring, CDP [13-5](#)
 multicast [3-15](#)
 multiple basic SSIDs (multiple BSSIDs)
 description [5-3](#)
 requirements and guidelines [5-3](#)
 multiple client profiles
 configuring WMIC [6-3, 6-5](#)
 description [6-1](#)

N

name-to-address translation [4-3](#)
 Network-EAP [8-3](#)
 Network Time Protocol
 See NTP
 no commands [A-4](#)
 non-root bridge
 infrastructure SSID [5-2](#)
 NTP
 associations
 authenticating [4-47](#)
 enabling broadcast messages [4-50](#)
 peer [4-49](#)
 server [4-49](#)
 default configuration [4-47](#)
 displaying the configuration [4-54](#)
 overview [4-41](#)
 restricting access
 creating an access group [4-52](#)
 disabling NTP services per interface [4-53](#)
 source IP address, configuring [4-54](#)
 stratum [4-41](#)
 synchronizing devices [4-49](#)
 time
 synchronizing [4-41](#)
 ntp authenticate command [4-47](#)
 ntp peer command [4-49](#)

O

OFDM [1-8](#)

P

packet retries command [3-19](#)
 pairwise [GL-5](#)
 Pairwise Master Key (PMK) [GL-5](#)
 parent command [3-20](#)
 parent timeout command [3-20](#)
 password reset [17-3](#)
 passwords
 default configuration [4-6](#)
 encrypting [4-7](#)
 setting
 enable [4-6](#)
 enable secret [4-7](#)
 with usernames [4-9](#)
 payload-encapsulation command [3-14](#)
 per-VLAN Spanning Tree (PVST) [6-2](#)
 PKI
 ports, protected [3-17](#)
 power level, maximum [B-4](#)
 preamble [3-12](#)
 preferential treatment of traffic
 See QoS
 pre-shared key [8-22](#)
 primary intersection [1-3](#)
 privileged EXEC mode [A-2](#)
 privilege levels
 exiting [4-11](#)
 logging into [4-11](#)
 overview [4-5, 4-10](#)
 setting a command with [4-10](#)
 prompt command [4-1](#)
 protocol filters [12-2, C-1](#)
 protocols
 IP port [C-4](#)

public key infrastructure

See PKI

Public Secure Packet Forwarding **3-16**

Q

QoS

configuration guidelines **11-4**

impact on wireless LAN **11-2**

overview **11-1**

precedence **11-2**

quality of service

See QoS

R

radio

configuring channel settings **3-6**

configuring transmit power **3-5**

distance setting **3-15**

indicator **17-1**

radio frequency data rates **3-8, 3-10**

radio management **9-1**

RADIUS

administrator access **4-21**

attributes

 vendor-proprietary **4-30**

 vendor-specific **4-29**

configuring

 accounting **4-28**

 authentication **4-24**

 authorization **4-27**

 communication, global **4-22, 4-28**

 communication, per-server **4-21, 4-22**

 multiple UDP ports **4-22**

 default configuration **4-21**

 defining AAA server groups **4-25**

 displaying the configuration **4-31**

 identifying the server **4-21**

limiting the services to the user **4-27**

method list **4-21**

operation of **4-20**

overview **4-19**

SSID **5-2**

suggested network environments **4-19**

tracking services accessed by user **4-28**

radius-server host command

range **3-2**

rate limit, logging **16-9**

RCP

configuration files

 downloading **15-16**

 overview **15-14**

 preparing the server **15-15**

 uploading **15-17**

image files

 deleting old image **15-30**

 downloading **15-29**

 preparing the server **15-27**

 uploading **15-31**

regulatory domains **B-2**

release and renew the IP address **2-1**

reloading access point image **17-5**

Remote Authentication Dial-In User Service

See RADIUS

Remote Copy Protocol

See RCP

request to send (RTS) **3-18**

restricting access

 NTP services **4-52**

 passwords and privilege levels **4-5**

 TACACS+ **4-32**

RFC

 1157, SNMPv1 **14-2**

 1305, NTP **4-41**

 1901, SNMPv2C **14-2**

 1902 to 1907, SNMPv2 **14-2**

roaming, fast secure roaming using CCKM **9-2**

- root port **6-1**
- rts command **3-18**
- rts retries command **3-18**
-
- S**
- secondary intersection **1-3**
- secure remote connections **4-39**
- Secure Shell
 See SSH
- Secure Shell (SSH)
 See SSH
- security **2-4**
 protocol **4-21**
 root device and non-root bridge settings **8-24**
 synchronizing **8-24**
 troubleshooting **17-3**
 security settings, Express Security page **2-4**
 self-healing wireless LAN **9-4**
 sequence numbers in log messages **16-6**
 server group
 AAA **4-25**
 set BOOT command **17-6**
 set command **17-6**
 set-request operation **14-4**
 severity levels, defining in system messages **16-7**
 shared-key authentication **8-2**
 show controller dot11radio command **3-4**
 show dot11 carrier busy command **3-21**
 show vlan **10-6**
Simple Network Management Protocol
 See SNMP
- SNMP
 accessing MIB variables with **14-4**
 agent
 described **14-3**
 disabling **14-5**
 community strings
 configuring **14-5**
- overview **14-4**
configuration examples **14-9**
default configuration **14-5**
limiting system log messages to NMS **16-8**
manager functions **14-2**
MIBs, location of **D-2**
overview **14-1, 14-4**
snmp-server view **14-9**
status, displaying **14-10**
system contact and location **14-9**
trap manager, configuring **14-8**
traps
 described **14-2**
 enabling **14-7**
 overview **14-1, 14-4**
 types of **14-7**
 versions supported **14-2**
software images
 delete from Flash **17-5**
 location in Flash **15-18**
 tar file format, described **15-19**
spacing command **3-7, 3-9**
spanning-tree
 root port **6-1**
Spanning Tree Protocol (STP) **6-1**
speed command **3-1, 3-3**
- SSH
 crypto software image **4-39**
 described **4-39**
 description **2-2**
 displaying settings **4-40**
 SSH Communications Security, Ltd. **2-2**
- SSID
 2.4-GHz radio **5-2**
 configuring **5-2**
 default (tsunami) **17-2**
 default configuration **5-2**
 disable **5-2**
 infrastructure SSID **5-2**

- RADIUS **5-2**
 - troubleshooting **17-2**
 - understanding **5-1**
 - VLAN **2-4, 4-12, 5-3**
 - without VLANs **4-11**
 - static WEP **4-11**
 - with open authentication, setting on client and access point **8-24**
 - with shared key authentication, setting on client and access point **8-24**
 - statistics
 - CDP **13-5**
 - SNMP input and output **14-10**
 - status indicators **17-1**
 - STP
 - BPDU message exchange **6-2**
 - designated port, defined **6-3**
 - designated switch, defined **6-3**
 - displaying status **6-14**
 - inferior BPDU **6-3**
 - interface states
 - blocking **6-6**
 - disabled **6-7**
 - forwarding **6-6, 6-7**
 - learning **6-7**
 - listening **6-7**
 - overview **6-5**
 - overview **6-1**
 - root port, defined **6-3**
 - timers, described **6-4**
 - stratum, NTP **4-41**
 - summer time **4-46**
 - switchport protected command **3-17**
 - syslog
 - See* system message logging
 - system clock **4-41**
 - configuring
 - daylight saving time **4-46**
 - manually **4-44**
 - time zones **4-45**
 - displaying the time and date **4-44**
 - overview **4-41**
 - See also NTP
 - system message logging
 - default configuration **16-3**
 - defining error message severity levels **16-7**
 - disabling **16-4**
 - displaying the configuration **16-11**
 - enabling **16-4**
 - facility keywords, described **16-11**
 - level keywords, described **16-8**
 - limiting messages **16-8**
 - message format **16-2**
 - overview **16-1**
 - rate limit **16-9**
 - sequence numbers, enabling and disabling **16-6**
 - setting the display destination device **16-5**
 - timestamps, enabling and disabling **16-6**
 - UNIX syslog servers
 - configuring the daemon **16-10**
 - configuring the logging facility **16-10**
 - facilities supported **16-11**
 - system name **4-1**
 - manual configuration **4-1**
-
- T
- TAC **17-1**
 - TACACS+
 - accounting, defined **4-32**
 - authentication, defined **4-32**
 - authorization, defined **4-32**
 - configuring
 - accounting **4-37**
 - authentication key **4-34**
 - authorization **4-36**
 - login authentication **4-34, 4-35**

default configuration [4-33](#)
 displaying the configuration [4-38](#)
 identifying the server [4-34](#)
 limiting the services to the user [4-36](#)
 operation of [4-33](#)
 overview [4-32](#)
 tracking services accessed by user [4-37](#)

tar files

creating [15-5](#)
 displaying the contents of [15-6](#)
 extracting [15-7](#)
 image file format [15-19](#)

Telnet [2-1, 2-2](#)Temporal Key Integrity Protocol (TKIP) [8-1](#)

Terminal Access Controller Access Control System Plus
See TACACS+

TFTP [17-5](#)

configuration files
 downloading [15-10](#)
 preparing the server [15-10](#)
 uploading [15-11](#)

image files

deleting [15-21](#)
 downloading [15-20](#)
 preparing the server [15-19](#)
 uploading [15-22](#)

tftp_init command [17-5](#)

TFTP server

Cisco IOS image upload [A-9](#)

throughput [3-2, 3-7](#)

time

See NTP and system clock [4-41](#)

timestamps in log messages [16-6](#)time zones [4-45](#)TKIP [4-40](#)

transmit and receive antennas

configuring [3-13](#)

transmit power [3-5](#)transmit speed [3-1](#)

traps
 configuring managers [14-7](#)
 defined [14-2](#)
 enabling [14-7](#)
 notification types [14-7](#)
 overview [14-1, 14-4](#)
 troubleshooting [17-1](#)
 with CiscoWorks [14-4](#)
 with system message logging [16-1](#)
 tunnel [1-5](#)

U

universal workgroup bridge
 and multiple client profiles [6-1](#)

UNIX syslog servers

daemon configuration [16-10](#)
 facilities supported [16-11](#)
 message logging configuration [16-10](#)

upgrading software images

See downloading

uploading

configuration files
 preparing [15-10, 15-12, 15-15](#)
 reasons for [15-8](#)
 using FTP [15-14](#)
 using RCP [15-17](#)
 using TFTP [15-11](#)

image files

preparing [15-19, 15-22, 15-27](#)
 reasons for [15-18](#)
 using FTP [15-26](#)
 using RCP [15-31](#)
 using TFTP [15-22](#)

user EXEC mode [A-2](#)username-based authentication [4-9](#)

V

VLAN

- and bridges [10-2](#)
- configuring [10-3](#)
- overview [10-1](#)
- SSID [2-4, 4-11, 4-12, 5-3](#)
- with wireless bridges [10-3](#)
- vlan command [5-2](#)

W

WDS

- access point [9-1](#)
- and fast secure roaming [9-4](#)
- and WMIC [9-1](#)
- CLI commands [9-9](#)
- guidelines and requirements [9-4](#)

web site

- Cisco Software Center [17-7](#)

WEP

- configuring key [8-2](#)
- described [8-2](#)
- key example [8-5](#)
- key restrictions [8-4](#)
- keys [17-3](#)
- troubleshooting [17-3](#)
- with EAP [8-3](#)

Wi-Fi Multimedia

See WMM

Wi-Fi Protected Access

See WPA

Wi-Fi Protected Access (WPA) [4-13](#)

Wired Equivalent Privacy

See WEP

wireless bridges [10-3](#)

Wireless Domain Services

See WDS

WMIC

and WDS [9-1](#)

- Cisco IOS image upload procedure [A-9](#)
- multiple client profiles [6-3, 6-5](#)

WMM

workgroup bridge

infrastructure SSID [5-2](#)

world mode

802.11d standard [3-11](#)

Cisco legacy [3-11](#)

enabling and disabling [3-11](#)

WPA [4-11](#)

cipher suite [8-1](#)

description [8-6](#)

key management [8-6](#)

WPA2 [1-7](#)