



## Release Note for Software Version 2.0

---

The 2.0 software release supports the existing Catalyst 3000 and CPW1601, and introduces and supports the following features:

- Catalyst 3200 Modular Stackable Switch
- Dual port Fast Ethernet card with ISL capability
- Cisco's VTP
- Embedded RMON agent with critical RMON statistics
- Backup and restore of switch's NVRAM configuration
- Software control of port half/full-duplex modes
- Heterogenous mixtures of Catalyst 3000, Catalyst 3200, and CPW1601 in the same Stack
  - single image support of a Stack of any combination of switch models

***Important.*** Read the first two pages of this document *before* upgrading to the 2.0 version of software.

### Critical 2.0 Software Upgrading Instructions



**Caution** If you are upgrading an existing system, you *MUST* upgrade the bootcode first. If you do not, the system *will not* boot when restarted.

- See the section "Downloading the 2.0 Image to an Existing System" in this document for complete details.
- If you inadvertently download the image, see the section "Recovering from not Upgrading the bootcode First" in this document for the recovery procedure.

### Memory Limitations

RMON, Vlans, Spanning tree and ISL are all supportable in a Stack of 4MB boxes.

There are, however, some restrictions when you use switches with 4MB of memory.

For a single unit or a Stack:

- ATM modules require 8MB of memory regardless of whether they are installed in a single switch or in a Stack configuration. ATM will not run in a 4MB box.

For a Stack:

- If the IP Controller switch is only 4MB, RMON statistics can be gathered only on that box.
- The number of VLANS (in the VTP VLAN Configuration) should be no more than 64, with ports assigned to no more than 14 VLANs.
- Do not increase the number of RMON history buckets beyond 50.

8MB of memory removes these limitations.

### System Limitations

The following is a list of certain system configuration limitations when using 2.0 software.

- Do not install more than two ATM expansion modules per switch.
- Do not configure more than four trunks (ISL or ATM) per switch.
- There is a possibility of being able to over-subscribe the system configuration in a Catalyst 3200.

### Configuration Notes

- Spanning Tree is on by default
- 2.0 software requires 1MB of flash and so will not fit in a Kalpana Pro16.
- 2.0 software provides the ability to use software to control the duplex modes as well as being able to use the switches on the card or module.

### NMS Applications

Existing versions of CiscoView can not manage switches that are running software version 2.0. A new service package supporting the 2.0 release will be available on CCO by November 1, 1996. This release of CiscoView will not support new features in 2.0, but will provide the existing level of support for all platforms.

NMS applications may fail when accessing a large, very heavily loaded Stack. This is due to the system taking too long to respond to certain NMS applications.

## Known Anomalies

The following are known conditions in this version of the software release. It is not known at this time whether these conditions will be fixed in the next release of software.

### Detection of Error During Boot Process

In rare circumstances, the system may detect an error during the boot process. The system will switch to VTP transparent mode and reboot in this mode to preserve known VLAN information.

### System May Lose VLAN Port Assignments

In rare circumstances, a Stack 's VLAN port assignments can be lost during the boot process. This only happens when the system is a) in a Stack , and b) either booting or having a new box join an existing Stack where the new box will become the IP controller (i.e. the lowest numbered box).

### CDP Packets on ATM ELANs

CDP packets are not sent out the ATM ELANs. CDP Packets from other Cisco devices will be received on the ATM port. This will be fixed in the 2.1 release.

### CDP/VTP Interoperability with the Catalyst 5000

In order to ensure VTP and CDP interoperability with the Catalyst 5000 an IP address must be established on the default VLAN on the Catalyst 5000. If this is not done, VTP and CDP advertisements on an ISL trunk from the Catalyst 3000 will not be processed by the Catalyst 5000. Normal traffic is not affected.

### Port Statistics Menu

After exiting the Port Statistics menu, the screen may still refresh itself when the switch is under heavy traffic. To solve this problem, re-enter the menu and exit it again.

### SNMP Queries of VLAN Statistics

VLAN Statistics have not been implemented. SNMP queries on VLAN Statistics will return zero.

## Documentation

The term VLAN “domain” has in most cases been replaced by the term VLAN “name” for the 2.0 release. Some of the sections in version one (-01) of the Installation and Configuration Guide has not been updated to the new term. There are many instances (especially in the Configuration menu sections) that may still use the old term of (VLAN) domain. Be aware that in most cases the proper term is (VLAN) name. This will be corrected in the next version, version two (-02) of the Installation and Configuration Guides. Also Check CCO for the latest version of this document.

## Upgrading an Existing System

---

**Note** The following sections refer to upgrading an existing configured system *only*. Ignore the following sections if you are installing a system that already contains the 2.0 version of software.

---

### Preserving Existing VLAN/Domains in a VTP Configuration

If you are concerned with preserving your existing VLAN/Domain configuration in a VTP environment, review the section “Preserving a VTP Configuration” at the end of this document.

### Downloading the 2.0 Image to an Existing System

If you download the 2.0 image to an existing system without first upgrading the bootcode, the system will fail to boot when you reset the box. All new boxes shipping with 2.0 will have the new bootcode; the problem applies only to boxes being upgraded in the field.

To avoid the problem, the bootcode on existing boxes must be upgraded before upgrading the main image to 2.0.

There is a hidden option in the tftp download menu which allows tftp download of the bootcode. This feature was added in the 1.1.3 and 9.1 versions; it is NOT in the 9.0 version of the code. If you are running something earlier than 9.1 or 1.1.3, this technique will not work. Upgrade to one of those versions first.

Make sure you have the following files from CCO or from the upgrade 3.5 disk:

<b>UNIX</b>	<b>DOS</b>
c3000-main-2_0_1.gz	C3K_201.GZ
c3000-boot-2_0_1.ima	C3K_BOOT.IMA
c3000-mib-2_0_1.mib	C3K_201.MIB
c3000-schema-2_0_1.schema	C3K_201.SCH
c3000-readme-2_0_1.txt	README.TXT

## Upgrading the bootcode

Use the following steps to upgrade the bootcode:

---

**Note** The bootcode upgrade procedure is the same as the main image download procedure, with the following exception: At the end of the filename, **\*boot** is added so that the filename is downloaded into the boot area.

---

**Step 1** Enter the Download/Upload menu

**Step 2** Enter the TFTP Download/Upload... menu

**Step 3** Enter your TFTP Server Address, Download VLAN

**Step 4** Enter the Main Image Download... menu

- UNIX: For the Main Image Download Filename enter the following command:  
**c3000-boot-2\_0\_1.ima\*boot**
- DOS: For the “Main Image Download Filename enter:  
**C3K\_BOOT.IMA \*boot**

**Step 5** Download the image. If in a Stack , select “Execute Main Image Stack Network Download”

You can now use the same menu to download the 2.0 main image in the normal way. Reset the box after both images are downloaded and the system will come up running 2.0.

## Recovering from not Upgrading the bootcode First

You need to do a serial download of the new bootcode to recover. Serial download is a slow process, but it has the advantage of working even if the main image is not loadable (as in this case). Here are step by step instructions, starting from booting up and getting hung:

**Step 1** The system starts to boot. The following text is displayed:

Cisco Catalyst Boot Firmware P/N 57-1327-02, Copyright 1995

- Initiating bootstrapping sequence.
- Boot image integrity check...Passed.
- Control transferred to boot process.

- Relocating main image to DRAM.....

**Step 2** Now it gets stuck. Press the RESET button.

**Step 3** When you see the following line, push the SYSREQ button.

- Relocating main image to DRAM...

---

**Note** If you wait until the dots stop printing, it's too late press the SYSREQ button. If you push the SYSREQ button before the dots start printing, you'll go into the debugger. If that happens, push the RESET button and try again.

---

**Step 4** A menu with the following text should appear:

System Request Menu

-----

- 1. Xmodem download of boot image
- 2. Xmodem download of main image
  
- 3. Clear Non-Volatile RAM
- 4. Reset the system
  
- 0. Exit and Continue

Choice=>

**Step 5** Select option 1. A menu with the following text should appear:

System Request Menu

-----

- 1. Xmodem download of boot image
- 2. Xmodem download of main image
  
- 3. Clear Non-Volatile RAM
- 4. Reset the system
  
- 0. Exit and Continue

Choice=>

**Step 6** Select option 1. The following text should appear:

SysReq: Beginning Xmodem download of boot image.

SysReq: Waiting for binary file...

On a Sun workstation

- 1 On a Sun workstation using tip, type:  
~C
- 2 The following text should appear:  
SysReq: Waiting for binary file...  
~CLocal command?
- 3 Type the following:  
sx C3KBOOT.IMA (or whatever the file is called)

On PC's or other terminal emulator programs

- 1 On PC's or other terminal emulator programs simply perform an xmodem send of the file C3KBOOT.IMA (or whatever the file is called)
- 2 Use the following menu:

System Request Menu

-----

1. Xmodem download of boot image
2. Xmodem download of main image
  
3. Clear Non-Volatile RAM
4. Reset the system
  
0. Exit and Continue

Choice=>

- 3 Select choice one.
- 4 The following text should appear:  
SysReq: Beginning Xmodem download of boot image.  
SysReq: Waiting for binary file...  
~CLocal command?  
sx epsboot.ima  
Sending C3KBOOT.IMA, 443 XMODEM blocks.  
Give your local XMODEM receive command now.  
Sector xx xk

After all the boot image sectors have been downloaded, you should see the following:

System Request Menu

-----

- 1. Xmodem download of boot image
- 2. Xmodem download of main image
  
- 3. Clear Non-Volatile RAM
- 4. Reset the system
  
- 0. Exit and Continue

Choice=>

- 5 Select choice one.

SysReq: Beginning Xmodem download of boot image.

SysReq: Waiting for binary file...

~CLocal command?

sx epsboot.ima

Sending C3KBOOT.IMA, 443 XMODEM blocks.

Give your local XMODEM receive command now.

Sector 442 55k away for 31 seconds!

Done. (located at 30010000)

SysReq: Overlaying old boot image and rebooting...

- 6 Once this is done, the system will reboot automatically with the new bootcode and the following text should appear:

Cisco Catalyst Boot Firmware P/N 57-1327-02, Copyright 1995

- Initiating bootstrapping sequence.
- Boot image integrity check...Passed.
- Control transferred to boot process.

Boot Firmware (Phase II) v2.0

- Relocating main image to DRAM.....Done.
- Main image integrity check...succeeded.



- Control transferred to main process.

System Software Version 2.0 (1), Copyright 1994-1996.

System started on Xxx. Xxx x, xxxx xx:xx:xx

8 Megabytes System memory

2 Megabytes Network memory

- Initialization started
- File system initialized
- System temperature is within safe operating levels
- Checking file system integrity
- Warmboot initialization started
- LAN ports detected:
  - 10Base-T: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
  - StkPort : 25
- CPU Network memory test...
- CPU Network memory test...Passed
- Initializing Ports: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 25
- Initializing system address table
- System entering stand-alone mode
- System initialization complete
- Starting SNMPv1 agent task
- Enabling port: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 25

Press RETURN key to activate console...

### New bootcode support

The new bootcode will support all previous versions of the main image, including 9.0, 9.1, 1.1.3, and 1.3. It is recommended that you upgrade the bootcode on all the systems, even if you are not planning to upgrade them to 2.0 immediately, since the problem with the existing version of the bootcode will continue to occur with all future releases (2.1, 2.2, etc.).

## Preserving a VTP Configuration

The following sections explain how to preserve an existing VTP/VLAN configuration.

---

**Note** The following sections apply *only* if you are going into an existing VTP environment and you want to preserve the present VLAN configuration. If you are not upgrading an existing configuration, ignore the following sections.

---

### How to Integrate a Pre-2.0 Release Into An Existing VTP Environment

As dictated by the VTP specification, the configuration of ports onto old EtherSwitch domains is now constrained by VTP as long as the switch is participating in VTP (that is, as long as it isn't in VTP Transparent mode). This means that a local port cannot be assigned to any VLAN which is not configured via VTP. Thus, what used to be called Domain Port Configuration is now essentially VTP VLAN Configuration and the selections available to the user now consist of those defined in VTP rather than the switch's constant 64 choices. When a VTP VLAN is deleted and removed from the database for the administrative domain, all local ports assigned to it automatically become unassigned. An unassigned port does not belong to any VLAN and does not forward packets.

Besides local ports, IP, SNMP, Spanning Tree, and TFTP choices which were previously dependent upon the old domain context are now dependent on the VTP VLAN context. For instance, an IP address configured for the switch is now defined in a VTP VLAN and only applies to IP packets received on that VLAN, whether over a trunk or a local port. When a VTP VLAN is deleted all such parameters are permanently lost. If you don't want to lose the old parameters, you have the option of using the following procedures to reconfigure your switch after you download the 2.0 switch Software Release

#### Examine the Local VTP Database Created by the Upgrade

In the 2.0 Release, the VTP and VLAN configuration replaces the current domain configuration. After the switch software reads the pre-2.0 configuration database, the 2.0 release code then modifies it to create a valid 2.0 configuration database. The result of this is a new VTP database which will be the one implemented locally after the initialization is complete.

#### VTP Transparent Mode

This database places the local Stack in VTP Transparent mode in order to give you the opportunity to complete the necessary manual steps of the upgrade procedure. In Transparent mode, all VTP configuration propagation packets are transparently forwarded to other trunks and are not used for local configuration. Until the Stack leaves Transparent Mode, all VLAN configuration is entirely under local control.

The initial VTP database will contain 68 VLANs: 64 Ethernet VLANs which are created to represent the 64 pre-2.0 Virtual EtherSwitches (what were formerly called Domains in some places) and the four VTP-mandatory non-Ethernet default VLANs which exist in all VTP databases.

The first of the 64 Ethernet VLANs corresponds to the VTP-mandatory default Ethernet VLAN and also to the pre-2.0 default Virtual EtherSwitch. The names of the other Ethernet VTP VLANs should correspond to the names of the Virtual EtherSwitches they replaced. Ports should be assigned to VLANs corresponding to the Virtual EtherSwitch to which they had previously been assigned.

IP, Spanning Tree, SNMP, and TFTP configuration parameters which had previously specified a Virtual EtherSwitch(es) now specify the corresponding VLAN(s)

#### Analyze and Determine Local VLAN Modifications Needed for Integration

In order to integrate into a VTP-controlled VLAN database environment, it is necessary to leave Transparent Mode and allow the global VTP database to overwrite the local one.

Before you do this, it is important to understand the consequences of this so you can take the necessary steps to prepare the local configuration.

When a device receives a new VTP database which supersedes its existing one, it implements the new database locally as appropriate. If new VLANs (as identified by their VLAN id number) are defined in the new database, then they are created locally. This allows the assignment of local ports to these new VLANs.

---

**Note** If old VLANs do not exist in the new database (as identified by their VLAN id number), they will be erased locally. The effect of this is the unassigning of any local ports and parameters ( for example, an IP address defined for the Stack on the local VLAN) that are assigned to that VLAN, and *permanently* losing their configuration information.

---

Regardless of whether the local device has begun running VTP or not, the trunk mapping of VLANs will occur as specified in the VTP database using VLAN id for ISL trunks and VLAN name for LANE trunks. Whether or not this mapping is appropriate for your configuration depends on which ports on a local Stack need to be members of the same VLAN (with other local assigned ports that exist on remote devices across the trunk and beyond).

### Assigning local ports

To insure that the local VLAN port and parameter assignments resolve correctly and do not get deleted (once they are controlled by VTP):

- Determine which global VLANs (as determined by the VLAN id number and *not* the VLAN name in the global database) will need to contain the ports and parameters, now assigned to each local VLAN, that was created in the upgrade process. (Local VLANs corresponding to previously unused Virtual EtherSwitches are of no concern and may be ignored.)

For example, after the upgrade procedure, Virtual EtherSwitch 5, named Engineering, with five ports and an IP address of 192.5.5.5, will be changed to VLAN Engineering VTP id number 5 with the same port/IP assignments.

If you need to move VLAN Engineering from VTP id number 5 to another global VLAN with different VTP id number, follow the instructions in the Moving Local VLAN Assignments section.

### Moving Local VLAN Assignments

If, in the example in the previous section, the user determines that the ports and address in local VLAN 5 need to be assigned to global VLAN 281 (because this will allow desired connectivity to other ports in global VLAN 281) the VLAN will need to be moved.

### Procedure to move VLANs

First of all, VLAN 281 needs to exist in order to move ports and parameters there. (The VLANs corresponding to the pre-2.0 database created are assigned id numbers 1 through 64 and the mandatory non-ethernet default VLANs are assigned id numbers 1002 through 1005.)

**Step 1** The VLAN 281 must be created using the VTP VLAN Configuration Sub-menu (under the VLAN and VTP Configuration Menu.) If integration into the global database is imminent, there is no need to be concerned with most of the VTP parameters assigned to VLAN 281 in the local database since these will ultimately be overwritten by the global database. However, since there is a limit of 68 VLANs on a local device, one of the existing VLANs will need to be deleted to make room for VLAN 281. Use the delete function in this menu to remove a VLAN that is not needed.

**Step 2** Add VLAN 281 using the Add function in the VTP VLAN Configuration menu. The parameters that need to be configured are:

- the VLAN name (since all VLANs must have unique name of at least one character)
- the VLAN type (must be Ethernet)
- the VLAN MTU (must be 1500).

The last two values will default as desired (Ethernet type/1500 MTU) when using this function in the VTP VLAN Parameter Configuration Menu. (As covered in a later section, the new VLAN need not and probably should not be made Preferred in the Local Preferred VLANs Configuration menu.)

**Step 3** Once VLAN 281 is created, ports and local parameters may be moved from VLAN 5 to VLAN 281. To move a local VLAN in a single step, use the Reassign Ports in Local VLAN sub-menu under the VLAN and VTP Configuration menu.

**Step 4** The Reassign Ports in Local VLAN menu has four selectable items:

- source VLAN - The source VLAN assignment allows you to select a preferred VLAN from which the VLAN ports and parameters are being moved.
- destination VLAN - The destination VLAN allows you to select any existing VLANs to which to move the ports and parameters.
- the “Execute Reassignment” function
- the “Leave Unchanged” function.

**Step 5** In this example, the source VLAN would be VLAN 5 and the destination VLAN would be VLAN 281. Select the Execute Reassignment function to complete the move. Check that all local static ports and parameters have been moved from VLAN 5 to VLAN 281.

## Final Integration

After all local VLAN moves have been executed and the local VLAN configuration appears correct, integrate this information into the global VTP environment. This procedure must be performed carefully since it may have a drastic effect on local configuration. Use the following steps for this procedure:

- Step 1** Do a TFTP save of the configuration database. To do this, go to the Downloads/Upload menu and the TFTP Download/Upload sub-menu.
- Step 2** To allow access to the system from the outside, go to the VTP Administrative Configuration menu.
- Step 3** Set the Local Mode parameter to either Server or Client mode. If the global VTP database contains no secret value (password) and assuming the local environment has only one VTP administrative domain, this is the only necessary procedure you need to do. However, if you have set a secret value, it also will need to be set in the VTP Administrative Configuration menu  
  
The local device learns the administrative domain name from the first peer to subsequently advertise it to the rest.
- Step 4** If necessary, the local mode may be reset to Transparent mode and the configuration uploaded back into the device. Do not simply reload the configuration database without resetting the local VTP mode.
- Step 5** After a period of time (normally not exceeding five minutes), the global VTP configuration should be received over the default Ethernet VLAN of any ISL or LANE trunk from a VTP peer (not itself in Transparent mode).
- Step 6** The local VTP configuration should now be identical to the global one. If the VLAN moves have been done correctly all the ports and parameters should be assigned as desired and connected to ports in remote devices on their corresponding VLANs.

## Preferred VLANs as Destinations In The Reassign Ports in Local VLAN Menu

A preferred VLAN is a VLAN that contains configuration parameters such as IP/port assignments. A non-preferred VLAN does not have any local configuration parameters.

The source of a local VLAN move must be a preferred VLAN. This is because only preferred VLANs contain local port and (non-default) parameter assignments.

It is preferable to have the destination of a VLAN move be a non-preferred VLAN with no locally configured parameters.

However, if the destination VLAN of the move has configured values, you can perform one of the following actions:

- You can decide to swap the position of the two VLANs, taking all their ports and parameters with them. This is effectively a simultaneous two-way move.
- You can merge the two preferred VLANs into one. This would have the effect of combining all the ports of the source and destination VLANs into the destination VLAN.

A further selection on the VLAN and VTP Configuration menu will allow you to choose which of the two VLAN's local IP and Spanning Tree parameters are kept (assigned to the destination VLAN) and which are discarded.

## Reassign Ports in Local VLAN

This display is used to move a fully configured Stack into a pre-existing VTP administrative domain.

**Figure 1 Reassign Ports in a Local VLAN Menu**

**Reassign Ports in Local VLAN**

This is a specialized display useful for moving a fully configured stack into a pre-existing VTP administrative domain. Its specific function is to move all ports and parameters on this local device from one VLAN into another. It does not alter the global VTP VLAN configuration in any way.

Source VLAN (preferred)	<unassigned>
Destination VLAN	<unassigned>

  

Execute reassignment	Leave Unchanged
----------------------	-----------------

Enter preferred VLAN from which ports and parameters are to be reassigned.  
Use cursor keys to select action. Press <RETURN> to confirm choice.  
Press <CTRL><P> to return to Main Menu.

H6117

## An Example of How To Upgrade Into a VTP Environment

The following database (Table 1) assumes you would like to integrate the ports on the VLANs named *local-(appropriate name)* on the Stack being upgraded to 2.0, using VTP, into the correspond global VLANs name *global-(appropriate name)*. For instance, it is desired that ports 2, 4, and 8 (which originally belonged to *local-W* on the local Stack will ultimately become members of the VLAN named *global-W*.

Table 1 VTP Database

Local VTP Database			Global VTP Database	
VLAN ID #	VLAN Name	Ports	VLAN ID#	VLAN Name
1	default	1, 3, 15	1	default
2	local-w	2, 4, 8	2	global-A
3	local-x	5, 10, 16	3	global-B
4	local-y	6, 12, 14	4	global-C
5	local-z	7, 9, 11, 13	5	global-W
6	VLAN 5		6	global-D
7	VLAN 6		8	global-E
8	VLAN 7		12	global-X
9	VLAN 8		25	global-F
10	VLAN 9		67	global-Y
11	VLAN 10		281	global-Z
.				
.				
.				
.				
64	VLAN 63			

- 1 The Local VTP Database is an example of what might be found in the VTP VLAN configuration after the upgraded box boots up the first time. The “Global” database is the one found in any box in the network currently running VTP in non-transparent mode.
- 2 In the section, Analyze and Determine Local VLAN Modifications Needed for Integration, the user needs to move the local ports and parameters initially assigned to VLAN 2 into VLAN 5. Those assigned to VLAN 3 will be moved to VLAN 12. Those assigned to VLAN 4 will be moved to VLAN 67, and those assigned to VLAN 5 will be moved to VLAN 281. The user would not care about local VLANs numbers over 5 if there are no ports or parameters assigned to them.
- 3 In the section, Moving Local VLAN Assignments, the user would move the VLANs as planned in section, Analyze and Determine Local VLAN Modifications Needed for Integration. Since VLANs 67 and 281 do not exist on the local database, the user would need to first delete two unneeded local VLANs (for instance, VLAN 63 and VLAN 64), and then add VLANs 67 and 281. All of this is done in transparent mode.
- 4 Since VLAN 12 already exists and is preferred (all of the 64 Ethernet VLANs created during upgrade are created as preferred VLANs), it does not have to be created. However, the user needs to choose between swapping VLAN 3 with it or merging VLAN 3 into it. It doesn't matter how it is handled since the user didn't have anything in VLAN 12 that is needed to be saved.
- 5 Since VLAN 5 already exists and is important to the user, the user must take care to handle it correctly when doing the move from VLAN 2 to VLAN 5. Move local-z to the newly created VLAN 281 before moving local-w to VLAN 5.

As an alternative, you could swap VLANs 2 and 5 first, thus moving the ports and parameters of local-z to local-w and vice versa. (Note that the names do not move.) Then move VLAN 2 to VLAN 281.

- 6 Once the four move operations are performed, the user (after TFTP saving the configuration), may change the local Stack into VTP server or client mode.

After this has been done (and sufficient time has passed such the configuration has propagated from a neighboring device or Stack running VTP), the Local database should go away completely and the user will see the Global database implemented on the upgraded Stack . All the ports and parameters should have survived the move, however, and will be found in the VLANs they were assigned to by VLAN id number before the mode was changed.



## Obtaining Service and Support

For service and support for a product purchased from a reseller, contact the reseller. Resellers offer a wide variety of Cisco service and support programs, which are described in the section “Service and Support” in the information packet that shipped with your chassis.

---

**Note** If you purchased your product from a reseller, you can access Cisco Connection On-line (CCO) as a guest. CCO is Cisco Systems’ primary, real-time support channel. Your reseller offers programs that include direct access to CCO’s services.

---

For service and support for a product purchased directly from Cisco, use CCO.

## Cisco Connection On-line

CCO is Cisco Systems’ primary, real-time support channel. SMARTnet customers and partners can self-register on CCO to obtain additional content and services.

---

**Note** If you purchased your product from a reseller, you can access CCO as a guest. Your reseller offers programs that include direct access to CCO’s services.

---

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to Cisco’s customers and business partners. CCO services include product information, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously—a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, and Internet e-mail, and is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: <http://www.cisco.com>.
- WWW: <http://www-europe.cisco.com>.
- WWW: <http://www-china.cisco.com>.
- Telnet: [cco.cisco.com](http://cco.cisco.com).
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and baud rates up to 14.4 kbps.

For a copy of CCO’s Frequently Asked Questions (FAQ), contact [cco-help@cisco.com](mailto:cco-help@cisco.com). For additional information, contact [cco-team@cisco.com](mailto:cco-team@cisco.com).

---

**Note** If you need technical assistance with a Cisco product that is under warranty or covered by a Cisco maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com.

---

Please use CCO to obtain general information about Cisco Systems, Cisco products, or upgrades. If CCO is not accessible, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.

---

This document is to be used in conjunction with the *document\_title* publication.

AtmDirector, AutoConnect, AutoRoute, AXIS, BPX, Catalyst, CD-PAC, CiscoAdvantage, CiscoFusion, Cisco IOS, the Cisco IOS logo, *CiscoLink*, CiscoPro, the CiscoPro logo, CiscoRemote, the CiscoRemote logo, CiscoSecure, Cisco Systems, CiscoView, CiscoVision, CiscoWorks, ClickStart, ControlStream, EdgeConnect, EtherChannel, FairShare, FastCell, FastForward, FastManager, FastMate, FastPADImp, FastPADmicro, FastPADmp, FragmentFree, FrameClass, Fulcrum INS, IGX, Impact, Internet Junction, JumpStart, LAN<sup>2</sup>LAN Enterprise, LAN<sup>2</sup>LAN Remote Office, LightSwitch, NetBeyond, NetFlow, Newport Systems Solutions, *Packet*, PIX, Point and Click Internetworking, RouteStream, Secure/IP, SMARTnet, StrataSphere, StrataSphere BILLder, StrataSphere Connection Manager, StrataSphere Modeler, StrataSphere Optimizer, Stratm, StrataView Plus, StreamView, SwitchProbe, SwitchVision, SwitchWare, SynchroniCD, *The Cell*, The FastPacket Company, TokenSwitch, TrafficDirector, Virtual EtherSwitch, VirtualStream, VlanDirector, Web Clusters, WNIC, Workgroup Director, Workgroup Stack, and XCI are trademarks; Access by Cisco, Bringing the Power of Internetworking to Everyone, Enter the Net with MultiNet, and The Network Works. No Excuses, are service marks; and Cisco, the Cisco Systems logo, CollisionFree, Combinet, EtherSwitch, FastHub, FastLink, FastNIC, FastPacket, FastPAD, FastSwitch, ForeSight, Grand, Grand Junction, Grand Junction Networks, the Grand Junction Networks logo, HSSI, IGRP, IPX, Kalpana, the Kalpana logo, LightStream, MultiNet, MultiWare, OptiClass, Personal Ethernet, Phase/IP, RPS, StrataCom, TGV, the TGV logo, and UniverCD are registered trademarks of Cisco Systems, Inc. All other trademarks, service marks, registered trademarks, or registered service marks mentioned in this document are the property of their respective owners.

Copyright © 1996, Cisco Systems, Inc.  
All rights reserved. Printed in USA.  
969R