



Cisco ONS 15540 ESPx TL1 Command Reference

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 526-4100

Text Part Number: OL-3629-01



THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCSP, the Cisco Square Bridge logo, Cisco Unity, Follow Me Browsing, FormShare, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, GigaDrive, GigaStack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, Registrar, ScriptShare, SlideCast, SMARTnet, StrataView Plus, SwitchProbe, TeleRouter, The Fastest Way to Increase Your Internet Quotient, TransPath, and VCO are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0406R)

Cisco ONS 15540 ESPx TLI Command Reference

Copyright © 2004 Cisco Systems, Inc. All rights reserved.



| | |
|---|-------------|
| Preface | xvii |
| Purpose | xvii |
| Audience | xvii |
| Organization | xvii |
| Related Documentation | xviii |
| Document Conventions | xviii |
| Safety and Warning Information | xix |
| Obtaining Documentation | xix |
| Cisco.com | xix |
| Ordering Documentation | xix |
| Documentation Feedback | xx |
| Obtaining Technical Assistance | xx |
| Cisco Technical Support Website | xx |
| Submitting a Service Request | xx |
| Definitions of Service Request Severity | xxi |
| Obtaining Additional Publications and Information | xxi |

CHAPTER 1

| | |
|---|------------|
| Getting Started | 1-1 |
| 1.1 Setting Up TL1 Communication | 1-2 |
| 1.1.1 Opening a TL1 Session | 1-2 |
| 1.2 TL1 Command Syntax | 1-3 |
| 1.3 Autonomous Messages | 1-4 |
| 1.3.1 Alarm Codes | 1-4 |
| 1.4 TL1 Commands by User Security | 1-5 |
| 1.5 Mixed Mode Timing Support | 1-6 |
| 1.6 TL1 Command Completion Behavior | 1-6 |
| 1.6.1 Explicit List of AIDs - No Wildcards | 1-6 |
| 1.7 Command Completion Behavior for Retrieval Commands | 1-7 |
| 1.7.1 Explicit List of AIDs for Retrieval Commands - No Wildcards | 1-7 |

CHAPTER 2

TL1 Command Components 2-1

- 2.1 Generic Parameter Types 2-1
 - 2.1.1 CTAG 2-1
 - 2.1.2 TID 2-1
- 2.2 Parameters Values and Defaults 2-1
 - 2.2.1 Parameter Values 2-2
 - 2.2.2 Default Parameter Values 2-4
 - 2.2.2.1 10-GE Interface Configuration 2-4
 - 2.2.2.2 APS 2-5
 - 2.2.2.3 CDP 2-5
 - 2.2.2.4 Memory Management 2-5
 - 2.2.2.5 NTP 2-5
 - 2.2.2.6 OSCP 2-6
 - 2.2.2.7 Redundancy 2-6
 - 2.2.2.8 Security 2-6
 - 2.2.2.9 Threshold List Configuration 2-6
 - 2.2.2.10 Topology Neighbor Configuration 2-7
 - 2.2.2.11 Transparent Interface Configuration 2-7
 - 2.2.2.12 VOA Module Interface Configuration 2-7
- 2.3 Access Identifiers 2-7
- 2.4 Errors 2-8
- 2.5 Commands by Category 2-14

CHAPTER 3

TL1 Commands 3-1

- 3.1 ACT-USER: Activate User 3-1
- 3.2 ALW-MSG-ALL: Allow Message All 3-2
- 3.3 ALW-SWDX-EQPT: Allow Switch Duplex Equipment 3-2
- 3.4 CANC-USER: Cancel User 3-3
- 3.5 CPY-MEM: Copy Memory 3-3
- 3.6 DLT-FFP-OCH: Delete Facility Protection OCH 3-4
- 3.7 DLT-IP: Delete IP 3-5
- 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3-6
- 3.9 DLT-MEM: Delete Memory 3-7
- 3.10 DLT-NBR: Delete Neighbor 3-7
- 3.11 DLT-NTPASSOC: Delete NTP Associations 3-8
- 3.12 DLT-PATCH: Delete Patch 3-9
- 3.13 DLT-THR-OCH: Delete Threshold OCH 3-11

- 3.14 DLT-USER-SECU: Delete User Security 3-12
- 3.15 ED-DAT: Edit Date 3-12
- 3.16 ED-FFP-OCH: Edit Facility Protection 3-13
- 3.17 ED-GBE10: Edit 10-GE 3-15
- 3.18 ED-IP: Edit IP 3-17
- 3.19 ED-NE-CDP: Edit Network Element CDP 3-17
- 3.20 ED-NE-GEN: Edit Network Element General 3-18
- 3.21 ED-NE-OSCP: Edit Network Element OSCP 3-19
- 3.22 ED-OCH: Edit Optical Channel 3-19
- 3.23 ED-PID: Edit Password 3-23
- 3.24 ED-THR-OCH: Edit Thresholds OCH 3-24
- 3.25 ED-USER-SECU: Edit User Security 3-25
- 3.26 ENT-FFP-OCH: Enter Optical Protection 3-26
- 3.27 ENT-IP: Enter IP 3-28
- 3.28 ENT-IPROUTE-STATIC: Enter Static Routes 3-29
- 3.29 ENT-NBR: Enter Neighbor 3-29
- 3.30 ENT-NTPASSOC: Enter NTP Associations 3-31
- 3.31 ENT-PATCH: Enter Patch 3-32
- 3.32 ENT-THR-OCH: Enter Thresholds OCH 3-33
- 3.33 ENT-USER-SECU: Enter User Security 3-35
- 3.34 FORMAT-MEM: Format Memory 3-35
- 3.35 INH-MSG-ALL: Inhibit Message All 3-36
- 3.36 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment 3-37
- 3.37 INIT-REG-ETH: Initialize Register Ethernet 3-37
- 3.38 INIT-REG-GBE10: Initialize Register 10-GE 3-38
- 3.39 INIT-REG-OCH: Initialize Register OCH 3-38
- 3.40 INIT-SYS: Initialize System 3-39
- 3.41 OPR-LPBK-GBE10: Operate Loopback on the 10-GE 3-39
- 3.42 OPR-LPBK-OCH: Operate Loopback OCH 3-40
- 3.43 OPR-PROTNSW-OCH: Operate Protection Switch OCH 3-41
- 3.44 RLS-LPBK-GBE10: Release Loopback on the 10-GE 3-42
- 3.45 RLS-LPBK-OCH: Release Loopback OCH 3-42
- 3.46 RLS-PROTNSW-OCH: Release Protection Switch OCH 3-43
- 3.47 RST-MEM: Restore Memory 3-43
- 3.48 RST-NE-CDP: Restore Global CDP Attributes 3-44

| | | |
|------|---|------|
| 3.49 | RTRV-ALM-ALL: Retrieve Alarms All | 3-45 |
| 3.50 | RTRV-ALM-ENV: Retrieve Alarms Environmental | 3-46 |
| 3.51 | RTRV-ATTR-rr: Retrieve Attributes | 3-47 |
| 3.52 | RTRV-CDPNBR-OCH: Retrieve CDP Neighbor OCH | 3-48 |
| 3.53 | RTRV-COND-ALL: Retrieve Condition All | 3-50 |
| 3.54 | RTRV-EQPT: Retrieve Equipment | 3-50 |
| 3.55 | RTRV-FFP-OCH: Retrieve Facility Protection OCH | 3-54 |
| 3.56 | RTRV-FILE: Retrieve File | 3-56 |
| 3.57 | RTRV-GBE10: Retrieve 10-GE Interfaces | 3-58 |
| 3.58 | RTRV-HDR: Retrieve Header | 3-60 |
| 3.59 | RTRV-IP: Retrieve IP | 3-61 |
| 3.60 | RTRV-IPROUTE: Retrieve IP Route | 3-61 |
| 3.61 | RTRV-LOG: Retrieve Log | 3-62 |
| 3.62 | RTRV-MEM: Retrieve Memory | 3-63 |
| 3.63 | RTRV-NBR: Retrieve Neighbor | 3-65 |
| 3.64 | RTRV-NE-CDP: Retrieve Network Element CDP | 3-65 |
| 3.65 | RTRV-NE-GEN: Retrieve Generic NE Configuration Values | 3-66 |
| 3.66 | RTRV-NE-OSCP: Retrieve Network Element OSCP | 3-67 |
| 3.67 | RTRV-NTP: Retrieve NTP | 3-68 |
| 3.68 | RTRV-NTPASSOC: Retrieve NTP Associations | 3-69 |
| 3.69 | RTRV-OCH: Retrieve Optical Channel | 3-70 |
| 3.70 | RTRV-PATCH: Retrieve Patch | 3-72 |
| 3.71 | RTRV-PM-ENCAP: Retrieve Performance Encapsulation | 3-74 |
| 3.72 | RTRV-PM-EQPT: Retrieve Performance Monitoring Equipment | 3-76 |
| 3.73 | RTRV-PM-GBE10: Retrieve Performance Monitoring on 10-GE | 3-77 |
| 3.74 | RTRV-PMMODE-OCH: Retrieve Performance Mode OCH | 3-79 |
| 3.75 | RTRV-PM-rr: Retrieve Performance Monitoring | 3-79 |
| 3.76 | RTRV-THR-OCH: Retrieve Thresholds OCH | 3-81 |
| 3.77 | RTRV-TH-rr: Retrieve Threshold | 3-83 |
| 3.78 | RTRV-TOD: Retrieve Time of Day | 3-84 |
| 3.79 | RTRV-USER-SECU: Retrieve User Security | 3-84 |
| 3.80 | RTRV-VOA: Retrieve VOA | 3-85 |
| 3.81 | SET-ATTR-rr: Set Attributes | 3-86 |
| 3.82 | SET-NTP: Set NTP | 3-88 |
| 3.83 | SET-PMMODE-OCH: Set Performance Mode OCH | 3-88 |

- 3.84 SET-SID: Set System Identification 3-89
- 3.85 SET-TH-rr: Set Optical Threshold 3-89
- 3.86 SET-VOA: Set VOA 3-91
- 3.87 SQUEEZE-MEM: Squeeze Memory 3-92
- 3.88 SW-DX-EQPT: Switch Duplex Equipment 3-92

INDEX



Figure 1-1

Autonomous Message Format 1-4



TABLES

| | | |
|-------------------|--|-------------|
| <i>Table 1-1</i> | Command Access | 1-5 |
| <i>Table 1-2</i> | Security Default Timeouts | 1-6 |
| <i>Table 2-1</i> | Command Components | 2-2 |
| <i>Table 2-2</i> | 10-GE Interface Configuration Default Values | 2-4 |
| <i>Table 2-3</i> | APS Default Values | 2-5 |
| <i>Table 2-4</i> | CDP Default Values | 2-5 |
| <i>Table 2-5</i> | Memory Management Default Values | 2-5 |
| <i>Table 2-6</i> | NTP Default Values | 2-5 |
| <i>Table 2-7</i> | OSCP Default Values | 2-6 |
| <i>Table 2-8</i> | Redundancy Default Values | 2-6 |
| <i>Table 2-9</i> | Security Default Values | 2-6 |
| <i>Table 2-10</i> | Threshold List Configuration Default Values | 2-6 |
| <i>Table 2-11</i> | Topology Neighbor Configuration Default Values | 2-7 |
| <i>Table 2-12</i> | Transparent and VOA Interface Configuration Default Values | 2-7 |
| <i>Table 2-13</i> | Transparent and VOA Interface Configuration Default Values | 2-7 |
| <i>Table 2-14</i> | AIDs for the Cisco ONS 15540 ESPx | 2-8 |
| <i>Table 2-15</i> | Error Codes and Messages | 2-9 |
| <i>Table 2-16</i> | TL1 Commands by Category | 2-14 |



Preface

This preface explains the purpose, intended audience, organization, and conventions for the *Cisco ONS 15540 ESPx TL1 Command Reference*, and it provides information on how to obtain related documentation.

Purpose

This publication explains the use of TL1 (Transaction Language 1) for the Cisco ONS 15540 ESPx. Use this guide in conjunction with the appropriate publications listed in the “[Related Documentation](#)” section.

Audience

To use this publication, you should be familiar with Cisco or equivalent optical transmission hardware and cabling, telecommunications hardware and cabling, electronic circuitry and wiring practices, and preferably have experience as a telecommunications technician.

Organization

This Cisco ONS 15540 ESPx TL1 Command Reference is organized into the following chapters:

| Chapter | Title | Description |
|-----------|--|--|
| Chapter 1 | Getting Started | Explains how to gain access to a TL1 session, command syntax, and autonomous messages. |
| Chapter 2 | TL1 Command Components | Describes the components of TL1 commands, including AIDs (access identifiers) and parameter types. |
| Chapter 3 | TL1 Commands | Lists and describes the Cisco ONS 15540 ESPx TL1 commands. |

Related Documentation

Use this Cisco ONS 15540 ESPx TL1 Command Reference in conjunction with the following publications:

- [Regulatory Compliance and Safety Information for the Cisco ONS 15500 Series](#)
- [Cisco ONS 15540 ESPx Planning Guide](#)
- [Cisco ONS 15540 ESPx Hardware Installation Guide](#)
- [Cisco ONS 15540 ESPx Optical Transport Turn-Up and Test Guide](#)
- [Cisco ONS 15540 ESPx Cleaning Procedures for Fiber Optic Connections](#)
- [Cisco ONS 15540 ESPx Configuration Guide](#)
- [Cisco ONS 15540 ESPx Command Reference](#)
- [Cisco ONS 15540 ESPx System Alarms and Error Messages](#)
- [Cisco ONS 15540 ESPx Troubleshooting Guide](#)
- [Network Management for the Cisco ONS 15540 ESPx](#)
- [MIB Quick Reference for the Cisco ONS 15500](#)
- [Cisco ONS 15540 ESPx Software Upgrade Guide](#)

Document Conventions

This publication uses the following conventions:

| Convention | Application |
|-----------------------------|---|
| boldface | Commands and keywords in body text. |
| <i>italic</i> | Command input that is supplied by the user. |
| [] | Keywords or arguments that appear within square brackets are optional. |
| { x x x } | A choice of keywords (represented by x) appears in braces separated by vertical bars. The user must select one. |
| Ctrl | The control key. For example, where Ctrl + D is written, hold down the Control key while pressing the D key. |
| screen font | Examples of information displayed on the screen. |
| boldface screen font | Examples of information that the user must enter. |
| < > | Command parameters that must be replaced by module-specific codes. |



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the document.



Caution

Means *reader be careful*. In this situation, the user might do something that could result in equipment damage or loss of data.



Warning

This warning symbol means *danger*. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.

Safety and Warning Information

For safety and warning information, refer to the *Regulatory Compliance and Safety Information for the Cisco ONS 15500 Series* document that accompanied the product. This document describes the international agency compliance and safety information for the Cisco ONS 15500 series. It also includes translations of the safety warnings that appear in the Cisco ONS 15500 series documentation.

Obtaining Documentation

Cisco documentation and additional literature are available on Cisco.com. Cisco also provides several ways to obtain technical assistance and other technical resources. These sections explain how to obtain technical information from Cisco Systems.

Cisco.com

You can access the most current Cisco documentation at this URL:

<http://www.cisco.com/univercd/home/home.htm>

You can access the Cisco website at this URL:

<http://www.cisco.com>

You can access international Cisco websites at this URL:

http://www.cisco.com/public/countries_languages.shtml

Ordering Documentation

You can find instructions for ordering documentation at this URL:

http://www.cisco.com/univercd/cc/td/doc/es_inpk/pdi.htm

You can order Cisco documentation in these ways:

- Registered Cisco.com users (Cisco direct customers) can order Cisco product documentation from the Ordering tool:

<http://www.cisco.com/en/US/partner/ordering/index.shtml>

- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco Systems Corporate Headquarters (California, USA) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

Documentation Feedback

You can send comments about technical documentation to bug-doc@cisco.com.

You can submit comments by using the response card (if present) behind the front cover of your document or by writing to the following address:

Cisco Systems
Attn: Customer Document Ordering
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

For all customers, partners, resellers, and distributors who hold valid Cisco service contracts, Cisco Technical Support provides 24-hour-a-day, award-winning technical assistance. The Cisco Technical Support Website on Cisco.com features extensive online support resources. In addition, Cisco Technical Assistance Center (TAC) engineers provide telephone support. If you do not hold a valid Cisco service contract, contact your reseller.

Cisco Technical Support Website

The Cisco Technical Support Website provides online documents and tools for troubleshooting and resolving technical issues with Cisco products and technologies. The website is available 24 hours a day, 365 days a year at this URL:

<http://www.cisco.com/techsupport>

Access to all tools on the Cisco Technical Support Website requires a Cisco.com user ID and password. If you have a valid service contract but do not have a user ID or password, you can register at this URL:

<http://tools.cisco.com/RPF/register/register.do>

Submitting a Service Request

Using the online TAC Service Request Tool is the fastest way to open S3 and S4 service requests. (S3 and S4 service requests are those in which your network is minimally impaired or for which you require product information.) After you describe your situation, the TAC Service Request Tool automatically provides recommended solutions. If your issue is not resolved using the recommended resources, your service request will be assigned to a Cisco TAC engineer. The TAC Service Request Tool is located at this URL:

<http://www.cisco.com/techsupport/servicerequest>

For S1 or S2 service requests or if you do not have Internet access, contact the Cisco TAC by telephone. (S1 or S2 service requests are those in which your production network is down or severely degraded.) Cisco TAC engineers are assigned immediately to S1 and S2 service requests to help keep your business operations running smoothly.

To open a service request by telephone, use one of the following numbers:

Asia-Pacific: +61 2 8446 7411 (Australia: 1 800 805 227)

EMEA: +32 2 704 55 55

USA: 1 800 553 2447

For a complete list of Cisco TAC contacts, go to this URL:

<http://www.cisco.com/techsupport/contacts>

Definitions of Service Request Severity

To ensure that all service requests are reported in a standard format, Cisco has established severity definitions.

Severity 1 (S1)—Your network is “down,” or there is a critical impact to your business operations. You and Cisco will commit all necessary resources around the clock to resolve the situation.

Severity 2 (S2)—Operation of an existing network is severely degraded, or significant aspects of your business operation are negatively affected by inadequate performance of Cisco products. You and Cisco will commit full-time resources during normal business hours to resolve the situation.

Severity 3 (S3)—Operational performance of your network is impaired, but most business operations remain functional. You and Cisco will commit resources during normal business hours to restore service to satisfactory levels.

Severity 4 (S4)—You require information or assistance with Cisco product capabilities, installation, or configuration. There is little or no effect on your business operations.

Obtaining Additional Publications and Information

Information about Cisco products, technologies, and network solutions is available from various online and printed sources.

- Cisco Marketplace provides a variety of Cisco books, reference guides, and logo merchandise. Visit Cisco Marketplace, the company store, at this URL:

<http://www.cisco.com/go/marketplace/>

- The Cisco *Product Catalog* describes the networking products offered by Cisco Systems, as well as ordering and customer support services. Access the Cisco Product Catalog at this URL:

<http://cisco.com/univercd/cc/td/doc/pcat/>

- *Cisco Press* publishes a wide range of general networking, training and certification titles. Both new and experienced users will benefit from these publications. For current Cisco Press titles and other information, go to Cisco Press at this URL:

<http://www.ciscopress.com>

- *Packet* magazine is the Cisco Systems technical user magazine for maximizing Internet and networking investments. Each quarter, Packet delivers coverage of the latest industry trends, technology breakthroughs, and Cisco products and solutions, as well as network deployment and troubleshooting tips, configuration examples, customer case studies, certification and training information, and links to scores of in-depth online resources. You can access Packet magazine at this URL:

<http://www.cisco.com/packet>

- *iQ Magazine* is the quarterly publication from Cisco Systems designed to help growing companies learn how they can use technology to increase revenue, streamline their business, and expand services. The publication identifies the challenges facing these companies and the technologies to help solve them, using real-world case studies and business strategies to help readers make sound technology investment decisions. You can access iQ Magazine at this URL:

<http://www.cisco.com/go/iqmagazine>

- *Internet Protocol Journal* is a quarterly journal published by Cisco Systems for engineering professionals involved in designing, developing, and operating public and private internets and intranets. You can access the Internet Protocol Journal at this URL:

<http://www.cisco.com/ipj>

- World-class networking training is available from Cisco. You can view current offerings at this URL:

<http://www.cisco.com/en/US/learning/index.html>



Getting Started

TL1 (Transaction Language One) is a subset of the input and output messages contained in the ITU (International Telecommunications Union) MML (Man-Machine Language). TL1 provides a standard set of messages that can be used for communicating between operating systems and network elements, and personnel and network elements. The Cisco ONS 15540 ESPx can support up to 32 concurrent TL1 sessions. For more information about TL1, refer to Telcordia document GR-833-CORE, *Network Maintenance: Network Element and Transport Surveillance Messages*.

This chapter provides information and procedures for getting started with TL1 including:

- [1.1 Setting Up TL1 Communication, page 1-2](#)
- [1.2 TL1 Command Syntax, page 1-3](#)
- [1.3 Autonomous Messages, page 1-4](#)
- [1.4 TL1 Commands by User Security, page 1-5](#)
- [1.5 Mixed Mode Timing Support, page 1-6](#)
- [1.6 TL1 Command Completion Behavior, page 1-6](#)
- [1.7 Command Completion Behavior for Retrieval Commands, page 1-7](#)


1.1 Setting Up TL1 Communication

The period during which a user is logged into the Cisco ONS 15540 ESPx is called a session. You can use Telnet to open a session (login). The TL1 PID (password) is masked when accessing a TL1 session. When you logout, you are closing a session. The Cisco ONS 15540 ESPx allows a maximum of 32 concurrent TL1 sessions.

1.1.1 Opening a TL1 Session

Use the following procedure to open a TL1 session through Telnet. In the procedure the Activate and Cancel User commands are shown in their input format. For more information about these and other commands and messages, see [Chapter 3, “TL1 Commands.”](#)

To access TL1 commands in a Telnet session with a PC running Windows, follow these steps:

-
- Step 1** Type **cmd** at the DOS prompt and then click **OK**. (The same steps can also be done from a UNIX prompt.)
- Step 2** Type **TELNET <NODE IP ADDRESS OR NODE NAME> <PORT NUMBER>** and then press **Enter**.
The node IP address or name refers to the IP address or name of the node that you want to communicate with. Port number is the port (2361, 3082, or 3083) where TL1 commands are understood. If the connection is successful, a screen opens with a prompt.
- Step 3** Open a TL1 session by typing **ACT-USER:[<TID>]:<UID>:<CTAG>::<PID>;**
-
-  **Note** When the semicolon is typed, the command is issued immediately.
-
- Step 4** Close a TL1 session by typing **CANC-USER:[<TID>]:<USERID>:<CTAG>;**
-

1.2 TL1 Command Syntax

TL1 commands conform to the following syntax:

```
a:b:c:d:e: ... z;
```

where:

“a” is the command code

“b” is the target identifier (TID)

“c” is the access identifier (AID) or the user identifier (UID)

“d” is the correlation tag (CTAG)

“e: ... z;” are other positions required for various commands

The TID, AID, UID, and CTAG route and control the TL1 command. Other parameters provide additional information required to complete the action requested by the command. TL1 command codes, parameter names, and parameter values can be either uppercase or lowercase exclusively or any combination of the two, unless specifically noted in the command description.

The TID is a unique name given to each system when it is installed. The name identifies the particular NE (network element) to which each command is directed. Each TID can have a maximum of 20 ASCII characters limited to letters, digits, and hyphens, but each TID must start with an alphabetic character. The presence of the TID is required in all input commands, but its value can be null (represented by two successive colons). The TID can be null when the operating system directly communicates with the target NE. The recommended value for the TID, when it is used, is the target’s CLI code.



Note

If the TID contains any characters other than letters and digits, such as spaces, the text string form (enclosed in double quotes) must be used.

The AID is an access code used to identify and address specific objects within the Cisco ONS 15540 ESPx. These objects include individual pieces of equipment, transport spans, access tributaries, and other objects.

The CTAG is a unique identifier given to each input command by the user. When the Cisco ONS 15540 ESPx system responds to a specific command, it includes the command’s CTAG in the reply. Including the CTAG eliminates discrepancies about which response corresponds to which command. Valid CTAG values include strings of up to six characters comprised of identifiers (alphanumeric, beginning with a letter) or decimal numerals (a string of decimal digits with an optional non-trailing “.”).

The following specification characters are used throughout this document as vehicles for defining the syntax:

- < > enclose a symbol specifier, for example <CTAG>.
- [] enclose an optional symbol, for example [<TID>].
- “ ” enclose a literal character, for example an output format “SLOT-7:PLUGIN,TC,,,,,:\“EQUIPMENT PLUG-IN\”,TCC”
- ^ is a space, a literal blank character used only in examples of messages.


1.3 Autonomous Messages

The autonomous TL1 messages are listed alphabetically in [Chapter 2, “TL1 Command Components”](#). [Figure 1-1](#) shows the autonomous message format. The autonomous message tag (ATAG) is used for message sequencing. The number is incremented by one for each autonomous message sent by the Cisco ONS 15540 ESPx. The Cisco ONS 15540 ESPx uses whole numbers 0000 to 9999.


Note

Some autonomous messages (REPT DBCHG and REPT EVT SESSION, for example) differ slightly from the format shown in the third line of [Figure 1-1](#).

Figure 1-1 Autonomous Message Format



1.3.1 Alarm Codes

The alarm code indicates the severity of the autonomous message. Valid values for alarm codes in decreasing order of severity are as follows:

- *C Critical alarm
- ** Major alarm
- *^ Minor alarm
- A^ Non-alarm message

Critical, major, and minor correspond to the reporting of alarmed events. The non-alarm message designation is used when the NE is reporting non-alarmed events, periodic measurements, or results of previously scheduled diagnostics or audits. If multiple alarms are reported in the same message, the alarm code is the highest severity of those being reported.

The following example shows an output message that includes the critical alarm code:

```

AB7-56 1970-01-01 16:02:10
*C 100.100 REPT ALM EQPT
"SYSTEM:CR,HITEMP,NSA,,,,:\High Temperature\",TCC"
  
```

For more information about alarms, see the [“2.4 Errors”](#) section on page 2-8.

1.4 TL1 Commands by User Security

Table 1-1 specifies command access privileges for each user security level.

Table 1-1 Command Access

| Command | Superuser | Provisioning | Maintenance | Retrieve |
|-----------------------|-----------|--------------|-------------|----------|
| ALW-MSG-SECU | X | | | |
| ALW-USER-SECU | X | | | |
| APPLY | X | | | |
| COPY-RFILE | X | | | |
| DLT-USER-SECU | X | | | |
| ED-DAT | X | | | |
| ED-USER-SECU | X | | | |
| ENT-USER-SECU | X | | | |
| INH-MSG-SECU | X | | | |
| INH-USER-SECU | X | | | |
| REPT EVT SECU | X | | | |
| DLT-*_* | X | X | | |
| ED-*_* | X | X | | |
| ENT-*_* | X | X | | |
| SET-*_* | X | X | | |
| SET-TOD | X | X | | |
| INIT-*_* | X | X | X | |
| OPR-*_* | X | X | X | |
| RLS-*_* | X | X | X | |
| RMV-*_* | X | X | X | |
| RST-*_* | X | X | X | |
| SW-*_* | X | X | X | |
| ACT-*_* | X | X | X | X |
| ALW-*_* | X | X | X | X |
| CANC-*_* | X | X | X | X |
| ED-PID | X | X | X | X |
| INH-*_* | X | X | X | X |
| REPT * * ¹ | X | X | X | X |
| RTRV-*_* | X | X | X | X |

1. REPT EVT SECU applies to the Superuser only.

User security levels limit the amount of time a user can leave the system idle before the TL1 session is locked to prevent unauthorized users from making changes. Higher security levels have shorter timeouts. If provisioned, it only affects users who are not currently logged in. A user who is logged in has to log out and log back in before the new timeouts can take effect.

Table 1-2 shows security levels and their default timeouts.

Table 1-2 Security Default Timeouts

| Security Level | Default Timeouts |
|----------------|------------------|
| Retrieve | Unlimited |
| Maintenance | 60 minutes |
| Provisioning | 30 minutes |
| Superuser | 15 minutes |

1.5 Mixed Mode Timing Support

Although TL1 supports mixed mode timing in this release, we strongly advise against its implementation. Mixed mode timing runs an inherent risk of creating timing loops. Refer to Telcordia document GR-436-CORE, *Digital Network Synchronization Plan*, for recommended synchronization planning.

1.6 TL1 Command Completion Behavior

When you enter a TL1 command, one of three completion codes is returned. The completion codes are: completed (COMPLD), partial (PRTL), and deny (DENY). You can specify an explicit, implicit, or explicit with implicit list as explained in the following sections.



Note

The command completion behavior does not apply to the following commands: RTRV-CRS, RTRV-ALM, and RTVR-COND commands.

1.6.1 Explicit List of AIDs - No Wildcards

If a set of AIDs (access identifiers) is explicitly listed, including a set of just one AID, then each AID must complete successfully to return a COMPLD message. If more than one AID is in the set and at least one AID succeeds but all do not, then a PRTL with errors for each failed AID is returned. If all AIDs in the set fail, a DENY with errors for each failed AID is returned.

```
SLOT-1
FAC-2-1&FAC-3-3&FAC-4-2
```


1.7 Command Completion Behavior for Retrieval Commands

If you enter a RTRV-CRS command, then one of three completion codes is returned. They are completed (COMPLD), partial (PRTL), and deny (DENY). You can specify an explicit, implicit, or explicit with implicit list as explained in the following sections.

1.7.1 Explicit List of AIDs for Retrieval Commands - No Wildcards

For an explicit list of AIDs on a RTRV-EQPT command, an error code is returned for each AID that fails validation (for example, the user specifies STS-N-13 when SLOT-N only contains an OC-12) or for each AID where no matching cross-connection is found. To determine the completion code, follow the rules from the [“1.6.1 Explicit List of AIDs - No Wildcards” section on page 1-6](#). If the result is either PRTL or COMPLD, then a list of matching cross-connections will accompany the response.





TL1 Command Components

This chapter describes the components of TL1 commands and autonomous messages for the Cisco ONS 15540 ESPx including:

- [2.1 Generic Parameter Types, page 2-1](#)
- [2.2 Parameters Values and Defaults, page 2-1](#)
- [2.3 Access Identifiers, page 2-7](#)
- [2.4 Errors, page 2-8](#)
- [2.5 Commands by Category, page 2-14](#)

2.1 Generic Parameter Types

This section provides a description of generic parameter types defined for the TL1 messages used in the Cisco ONS 15540 ESPx.

2.1.1 CTAG

The user includes the correlation tag (CTAG) in each command and the NE repeats it in the response to allow the user to associate the command and the response messages.



Note

The valid values for a CTAG are strings of up to 6 characters comprised of identifiers (alphanumeric, beginning with a letter) or decimal numerals (a string of decimal digits with an optional non-trailing “.”).

2.1.2 TID

The TID (target identifier) is the name of the NE where the command is addressed. TID is the Telcordia name for the system.

2.2 Parameters Values and Defaults

This section lists the command parameters, the valid values, and the default values.

2.2.1 Parameter Values

Table 2-1 lists the commands parameters and the valid values.

Table 2-1 Command Components

| Component | Values |
|-----------|--|
| ASSOCTYPE | PEER SERVER |
| CDP | N Y |
| CLKPERIOD | 0 TO 4294967295 clock ticks (2^{-32} second) |
| CMDMODE | FRCD NORMAL |
| CONTYPE | ESS SEFS-S SESS CVRD CDLHEC |
| CTYPE | 1WAY 2WAY |
| DSCRVY | CDP MANUAL |
| ENCAP | ESCON FC-1G FC-2G FDDI FE FICON GIGE OC3 OC12 OC48 STM1 STM4 STM16 SYSPLEX-CLO SYSPLEX-ETR SYSPLEX-ISC-COMP SYSPLEX-ISC-PEER TENGIGE UNKNOWN |
| ENSWOTM | 1 to 120 seconds |
| ERRTYPE | CDLHEC CVRD CVS |
| FLC | N Y |

Table 2-1 Command Components (continued)

| Component | Values |
|--------------|---|
| FRCENDHOP | N Y |
| FROMDEV | BOOFLASH PCMCIA-0 PCMCIA-1 SBY-BOOTFLASH SBY-PCMCIA-0 SBY-PCMCIA-1 |
| HELLOHLDWN | 150 to 30000 milliseconds |
| HELLOINTV | 100 to 10000 milliseconds |
| HOLDTIME | 10 to 255 seconds |
| INACTFCTR | 1 to 50 |
| INDEX | 1 to 64 |
| LINKDIRN | BOTH RX TX |
| LPBKTYPE | FACILITY TERMINAL |
| LSC | N Y |
| MASTER | N Y |
| MAXASSOC | 0 TO 4294967295 clock ticks(2^{-32} second) |
| MODE | FRC NORMAL |
| MSGCH | AUTO DCC IP OSC |
| MSGHOLDCOUNT | 2 to 10 messages |
| MSGHOLDTM | 100 to 10000 milliseconds |
| MSGMAXINTVTM | 1 to 120 seconds |
| MSTRATUM | 1 to 16 |
| NTFCNCDE | CR MJ MN |
| OFC | N Y |
| PMSTATE | ON OFF |
| PSDIRN | BI UNI |

Table 2-1 Command Components (continued)

| Component | Values |
|------------|---|
| RATE | 16000 to 2500000 kHz |
| RVRTM | 0 to 720 seconds |
| SENDVER | 1 to 2 |
| THRTYPE | ALMTHR DEGR EVTHR FAIL |
| TODEV | BOOFLASH PCMCIA-0 PCMCIA-1 SBY-BOOTFLASH SBY-PCMCIA-0 SBY-PCMCIA-1 |
| TRGAPS | N Y |
| UAP | MAINT PROV RTRV SUPER |
| UPDATETIME | 5 to 254 seconds |
| UPDCAL | N Y |
| VALUE | 1 to 9 |
| YCABLE | N Y |

2.2.2 Default Parameter Values

This section describes the default values for the different categories of autonomous messages.

2.2.2.1 10-GE Interface Configuration

[Table 2-2](#) lists the default values for the autonomous messages in the 10-GE interface configuration category.

Table 2-2 10-GE Interface Configuration Default Values

| Parameter | Default |
|-----------|---------|
| FRCENDHOP | N |
| FLC | N |

2.2.2.2 APS

Table 2-3 lists the default values for the autonomous messages in the APS category.

Table 2-3 APS Default Values

| Parameter | Default |
|--------------|---------|
| PSDIRN | UNI |
| RVRTV | N |
| RVRTM | 300 |
| YCABLE | N |
| ENSWOTM | N |
| MSGCH | AUTO |
| MSGHOLDTM | 5000 |
| MSGMAXINTVTM | 15 |
| MSGHOLDCOUNT | 2 |

2.2.2.3 CDP

Table 2-4 lists the default values for the autonomous messages in the CDP category.

Table 2-4 CDP Default Values

| Parameter | Default |
|------------|---------|
| CDP | Y |
| UPDATETIME | 60 |

2.2.2.4 Memory Management

Table 2-5 lists the default values for the autonomous messages in the memory management category.

Table 2-5 Memory Management Default Values

| Parameter | Default |
|-----------|---------|
| CMDMODE | NORMAL |

2.2.2.5 NTP

Table 2-6 lists the default values for the autonomous messages in the NTP category.

Table 2-6 NTP Default Values

| Parameter | Default |
|-----------|---------|
| MASTER | N |
| UPDCAL | N |

2.2.2.6 OSCP

Table 2-7 lists the default values for the autonomous messages in the OSCP category.

Table 2-7 OSCP Default Values

| Parameter | Default |
|------------|---------|
| HELLOINTV | 100 |
| HELLOHLDWN | 3000 |
| INTACTFCTR | 5 |

2.2.2.7 Redundancy

Table 2-8 lists the default values for the autonomous messages in the redundancy category.

Table 2-8 Redundancy Default Values

| Parameter | Default |
|-----------|-----------|
| RVRTV | Y |
| RVTM | 5 minutes |

2.2.2.8 Security

Table 2-9 lists the default values for the autonomous messages in the security category.

Table 2-9 Security Default Values

| Parameter | Default |
|-----------|-----------|
| RVRTV | Y |
| RVTM | 5 minutes |
| SRVRTV | Y |
| SRVTM | 5 minutes |

2.2.2.9 Threshold List Configuration

Table 2-10 lists the default values for the autonomous messages in the threshold list configuration category.

Table 2-10 Threshold List Configuration Default Values

| Parameter | Default |
|-----------|------------------------|
| TRGAPS | N |
| INDEX | Lowest available index |

2.2.2.10 Topology Neighbor Configuration

[Table 2-11](#) lists the default values for the autonomous messages in the topology neighbor configuration category.

Table 2-11 Topology Neighbor Configuration Default Values

| Parameter | Default |
|-----------|---------|
| LINKDRN | BOTH |

2.2.2.11 Transparent Interface Configuration

[Table 2-12](#) lists the default values for the autonomous messages in the transparent interface configuration category.

Table 2-12 Transparent and VOA Interface Configuration Default Values

| Parameter | Default |
|-----------|---|
| CDP | Y |
| FLC | N |
| LASERFREQ | The lower laser frequency for the 2.5-Gbps transponder module |
| LSC | N |
| OFC | N |

2.2.2.12 VOA Module Interface Configuration

[Table 2-13](#) lists the default values for the autonomous messages in the VOA module interface configuration category.

Table 2-13 Transparent and VOA Interface Configuration Default Values

| Parameter | Default |
|-----------|---------|
| ATTENMODE | AUTO |
| DESATTEN | -25 dBm |
| DESPower | -25 dBm |

2.3 Access Identifiers

The AID code directs an input command to its intended physical or data entity inside the NE. Equipment modules and facilities are typical examples of entities addressed by the access code. [Table 2-14](#) lists the AIDs for the Cisco ONS 15540 ESPx.

Table 2-14 AIDs for the Cisco ONS 15540 ESPx

| AID | Description |
|------------|--|
| Slots | SLOT-[0-11] SLOT-[6-7] SLOT-[2-5, 8-11]-[0-3] SLOT-[0-1]-[0-3] |
| Interfaces | TRANSPARENT-[2-5, 8-11]-[0-3]-0 WAVE-[2-5, 8-11]-[0-3] WAVE-[0-1] WAVEETHERPHY-[2-5, 8-11]-[0-1] TENGIGETHERPHY-[2-5, 8-11]-[0-1] FILTER-[2-5,8-11]-[0-3]-0 FILTER-[2-5,8-11]-[0-3]-[0-1] FILTER-[0-1]-[0-3]-[0-3] FILTER-[0-1]-[0-3]-[0-7] FILTER-[0-1]-[0-3]-[0-15] FILTER-[0-1]-[0-3]-[0-31] FILTERBAND-[0-1]-[0,2]-[0-1] FILTERGROUP-[0-1]-[0,2]-[0-1] OSCFILTER-[0-5,8-11]-[0-3] THRU-[0-1]-[0-3] THRU-[2-5,8-11]-[0-3] WDM-[0-1]-[0-3] WDM-[2-5,8-11]-[0-3] WDMRELAY-[0-1]-[0-3]-[0-1] WDMSPILT-[0-1]-[0-3]-[0-1] VOAIN-[2-5,8-11]-[0-3]-[0-3] VOAOUT-[2-5,8-11]-[0-3]-[0-3] ETHERDCC-[2-5,8-11]-[0-1]-[0-1] FE-0 FE-SBY-0 LOOPBACK-[0-255] |
| Memory | BOOTFLASH SBY-BOOTFLASH DISK-[0-1] SBY-DISK-[0-1] NVRAM SBY-NVRAM PCMCIA-[0-1] SBY-PCMCIA-[0-1] SYSTEM |

2.4 Errors

Errors may be generated by any command or command response message. The format of an error message is as follows:

```

SID DATE TIME
M CTAG DENY
<ERRCDE>
/* <ERRMSG> */

```

Table 2-15 lists the error codes and messages.

Table 2-15 Error Codes and Messages

| Error Code | Error Message |
|------------|---|
| EANS | Access not supported |
| EATN | Invalid for access type |
| EFON | Feature option not provided |
| EN2T | Not 2-wire terminate and leave |
| ENAC | Not equipped with alarm cutoff |
| ENAD | Not equipped with audit capability |
| ENAR | Not equipped with automatic reconfiguration |
| ENAT | Request invalid for access type |
| ENDG | Not equipped with diagnostic capability |
| ENDS | Not equipped with duplex switching |
| ENEA | Not equipped with error analysis capability |
| ENEQ | Not equipped |
| ENEX | Not equipped with exercise capability |
| ENFE | Feature not provided |
| ENFL | Not equipped for fault locating |
| ENHN | Not hybrid network |
| ENMB | Not multipoint bridge |
| ENMD | Not equipped with memory device |
| ENPM | Not equipped for performance monitoring |
| ENPS | Not equipped with protection switching |
| ENRE | Not recognized equipage |
| ENRI | Not equipped for retrieving specified information |
| ENRS | Not equipped for restoration |
| ENSA | Not equipped for scheduling audit |
| ENSG | Not software generic |
| ENSI | Not equipped for setting specified information |
| ENSS | Not equipped with synchronization switching |
| ENTL | Not terminate and leave |
| ERLC | Red-lined circuit |
| ERNS | RTU does not support command |
| ESPG | Software program |

Table 2-15 Error Codes and Messages (continued)

| Error Code | Error Message |
|-------------------|---|
| ETNS | TSC does not support command |
| FNCR | NE fail.-circuit restored to last cond.-mon-term ¹ |
| FNDT | No dial tone detected |
| FNEC | NTE has lost 8-kHz byte clock |
| FNSC | NTE has lost 64-kHz bit clock |
| FRCE | RTU component or configuration error |
| FRDA | RTU does not answer the call |
| FREC | RTU 8-kHz byte clock lost |
| FRNR | RTU does not reply |
| IBEX | Block, extra |
| IBMS | Block, missing |
| IBNC | Block, not consistent |
| ICNV ² | Invalid command |
| IDMS | Data missing |
| IDNC | Data not consistent |
| IDNV | Data invalid |
| IDRG | Data range error |
| IEAE | Entity to be created already exists |
| IENE | Specified object entity does not exist |
| IAC | Invalid access identifier (AID) |
| IICM ³ | Invalid command |
| IICT | Invalid correlation tag |
| IIDT | Invalid data parameter |
| IIFM | Invalid data format |
| IIPG | Invalid parameter grouping |
| IISP | Invalid syntax or punctuation |
| IITA | Invalid target identifier |
| INAC | Access number not correct |
| INUP | Non-null unimplemented parameter |
| IPEX | Parameter extra |
| IPMS | Parameter missing |
| IPNC | Parameter not consistent |
| IPNV | Parameter invalid |
| ISCH | Syntax invalid character |
| ISPC | Syntax punctuation |
| ITSN | Invalid/inactive test session number |

Table 2-15 Error Codes and Messages (continued)

| Error Code | Error Message |
|-------------------|---|
| PICC | Illegal command code |
| PIMA | Invalid memory address |
| PIMF | Invalid memory file |
| PIUC | Stated user privilege code is illegal |
| PLNA | Login not active |
| RABY | All taps busy |
| RALB | All units of requested type are busy |
| RANB | Access network busy |
| RCBY | Circuit busy |
| RCIN | Requested circuit ID does not exist |
| RNAN | Requested NE access number does not exist |
| RNAU | Requested NE access number unassigned |
| RNBY | NE is busy |
| RRCB | Unit specified by routing code busy |
| RRNG | Requested change exceeds range |
| RTBY | Requested tap busy |
| RTEN | Requested tap does not exist |
| RTUB | Test unit busy |
| SAAL | Already allowed |
| SAAS | Already assigned |
| SABT | Aborted |
| SACS | Access unit cannot sync on facility signal |
| SADC | Already disconnected |
| SADS | Access unit in diagnostic state |
| SAIN | Already inhibited |
| SAIS | Already in-service |
| SAMS | Already in maintenance state |
| SAOP | Already operated |
| SAOS | Already out-of-service |
| SAPF | Access path continuity check failed |
| SAPR | Already in protection state |
| SARB | All resources busy |
| SATF | Automatic test failed |
| SCAT | Circuit is already connected to another tap |
| SCBS | Channel busy |
| SCIS | Circuit in split condition |

Table 2-15 Error Codes and Messages (continued)

| Error Code | Error Message |
|-------------------|---|
| SCNA | Command not able to be aborted |
| SCNF | Command not found |
| SCNS | Circuit not in split condition |
| SCOS | Channel out-of-service |
| SCSD | Cannot split DS0B circuit |
| SCSN | Invalid command sequence |
| SDAS | Diagnosis already started |
| SDBE | Internal data base error |
| SDFA | Duplex unit failed |
| SDL D | Duplex unit locked |
| SDNA | Duplex unit not available |
| SDNC | Input data is not consistent with NE data |
| SDNR | Data not ready |
| SDNS | Diagnosis not started yet |
| SEOS | NTE is out-of-service |
| SFAS | Fault locating already started |
| SFNS | Fault locating not started yet |
| SFYA | Facility reports yellow alarm |
| SLNS | Log not started yet |
| SLOS | TSC to RTU link out-of-service |
| SNCC | Not cross-connected |
| SNCN | NTE unable to execute command |
| SNDS | NTE is in a diagnostic state |
| SNIM | NTE access complete, circuit was in monitor state |
| SNIS | Not in service |
| SNML | No monitor line established |
| SNNB | NTE could not sync on DS0B signal |
| SNNS | NTE could not sync on DS1 signal |
| SNOS | NTE is out-of-service |
| SNPR | Not in protection state |
| SNRM | System not in restoration mode |
| SNRS | Not reserved |
| SNSR | No switch request outstanding |
| SNVS | Not in valid state |
| SNYA | NTE has detected a yellow alarm |
| SOSE | Operating system error |

Table 2-15 Error Codes and Messages (continued)

| Error Code | Error Message |
|-------------------|---|
| SOST | Out-of-service, testing |
| SPFA | Protection unit failed |
| SPLD | Protection unit locked |
| SPNA | Process not able to be aborted |
| SPNF | Process not found |
| SRAC | Requested access configuration is invalid |
| SRAN | Unable to release access system |
| SRCI | Requested command(s) inhibited |
| SRCN | Requested condition already exists |
| SROF | Requested operation failed |
| SROS | Required RTU out-of-service |
| SRQN | Invalid request |
| SRTN | Unable to release tap |
| SRTO | Reply timeout occurred |
| SSCE | Systemic (snider) communications error |
| SSNG | Subrate selected is incorrect |
| SSNP | Test signal not pseudo-random |
| SSNQ | Test signal not QRS |
| SSPN | Speed selected is incorrect |
| SSRD | Switch request denied |
| SSRE | System resources exceeded |
| SSTP | Execution stopped due to hardware or software problem |
| STAB | Test aborted |
| STLC | Tap unable to locate channel |
| STNO | TSC/RTU to TAU link out of service |
| STOS | Test access unit out of service |
| STTI | Tap idle |
| SWFA | Working unit failed |
| SWLD | Working unit locked |

1. Network element failure. The circuit is restored to the last condition, monitor, or terminate and leave.
2. For historical reasons, ICNV and IICM have been left in as valid error codes even though from inspection they are not unique (descriptions for both say Invalid Command). ICNV and IICM are not the preferred error codes for invalid, that is, unsupported commands by a test system controller (TSC) or NE. Where possible, specific DENY messages associated with a particular command should be used. However, when used, the ICNV is appropriate for responses originating from a TSC, and IICM is the choice for an NE.
3. An identical error code found in GR-833-CORE (SNOS STATUS, NOT CURRENTLY OUT OF SERVICE) is omitted here and will be removed from the list of valid error codes in a subsequent issue of GR-833-CORE.

2.5 Commands by Category

Table 2-16 lists the TL1 commands for the Cisco ONS 15540 ESPx by category.

Table 2-16 TL1 Commands by Category

| Category | Command or Autonomous Message |
|-------------------------------|--|
| 10-GE interface configuration | ED-GBE10 RTRV-GBE10 RTRV-PM-GBE10 INIT-REG-GBE10 OPR-LPBK-GBE10 RLS-LPBK-GBE10 |
| Alarms and faults | ALW-MSG-ALL INH-MSG-ALL RTRV-ALM-ALL RTRV-ALM-ENV RTRV-COND-ALL RTRV-LOG |
| APS | ENT-FFP-OCH ED-FFP-OCH RTRV-FFP-OCH DLT-FFP-OCH OPR-PROTNSW-OCH RLS-PROTNSW-OCH |
| CDP | ED-NE-CDP RST-NE-CDP RTRV-NE-CDP RTRV-CDPNBR-OCH |
| Generic NE configuration | ED-NE-GEN RTRV-NE-GEN INIT-SYS SET-SID RTRV-HDR ED-DAT RTRV-TOD |
| IP configuration | ENT-IP ED-IP DLT-IP RTRV-IP ENT-IPROUTE-STATIC DLT-IPROUTE-STATIC RTRV-IPROUTE INIT-REG-ETH |

Table 2-16 TL1 Commands by Category (continued)

| Category | Command or Autonomous Message |
|------------------------------|---|
| Memory management | CPY-MEM DLT-MEM RST-MEM SQUEEZE-MEM FORMAT-MEM RTRV-MEM RTRV-FILE |
| NTP | SET-NTP ENT-NTPASSOC DLT-NTPASSOC RTRV-NTPASSOC RTRV-NTP |
| Optical parameter monitoring | RTRV-PM-rr SET-TH-rr SET-ATTR-rr RTRV-TH-rr RTRV-ATTR-rr |
| OSCP | ED-NE-OSCP RTRV-NE-OSCP |
| Patch configuration | ENT-PATCH DLT-PATCH RTRV-PATCH |
| Redundancy | SW-DX-EQPT ALW-SWDX-EQPT INH-SWDX-EQPT RTRV-EQPT RTRV-PM-EQPT |
| Security | ENT-USER-SECU ED-USER-SECU DLT-USER-SECU RTRV-USER-SECU ACT-USER CANC-USER ED-PID |
| Threshold list configuration | ENT-THR-OCH ED-THR-OCH DLT-THR-OCH RTRV-THR-OCH |
| Topology neighbor commands | ENT-NBR DLT-NBR RTRV-NBR |

Table 2-16 TL1 Commands by Category (continued)

| Category | Command or Autonomous Message |
|-------------------------------------|--|
| Transparent interface configuration | ED-OCH RTRV-OCH SET-PMMODE-OCH RTRV-PMMODE-OCH INIT-REG-OCH OPR-LPBK-OCH RLS-LPBK-OCH RTRV-PM-ENCAP |
| VOA module interface configuration | SET-VOA RTRV-VOA |



TL1 Commands

This chapter describes the TL1 commands used in the Cisco ONS 15540 ESPx environment.

Each TL1 command must be less than or equal to 255 characters. Any command larger than 255 characters must be split into multiple commands



Note

TL1 commands that are entered incorrectly are not completed.

3.1 ACT-USER: Activate User

Use this command to log into the NE (network element).

| Section | ACT-USER Description |
|------------------|--|
| Category | Security |
| Security | Retrieve |
| Related Messages | 3.4 CANC-USER: Cancel User 3.14 DLT-USER-SECU: Delete User Security 3.25 ED-USER-SECU: Edit User Security 3.33 ENT-USER-SECU: Enter User Security 3.79 RTRV-USER-SECU: Retrieve User Security |
| Input Format | ACT-USER:[<tid>]:<uid>:<ctag>::<pid>; Where: <ul style="list-style-type: none"> • <ctag> is the correlation tag. • <uid> is the user identifier. It is a text string with a maximum length of 16 characters. • <pid> is the user login password. It is a text string with a minimum length of six characters. • <tid> is the target identifier. |
| Input Example | To log into the NE, use the following: ACT-USER:ons155xx:admin:123::myswd; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.2 ALW-MSG-ALL: Allow Message All

Use the command to transmit all REPT-ALM, REPT-EVT, and REPT-SW autonomous messages.

| Section | ALW-MSG-ALL Description |
|------------------|---|
| Category | Alarms and faults |
| Security | Retrieve |
| Related Messages | 3.35 INH-MSG-ALL: Inhibit Message All |
| Input Format | ALW-MSG-ALL:[<tid>]:<ctag>; <ul style="list-style-type: none"> • <ctag> is the correlation tag. • <tid> is the target identifier. |
| Input Example | To transmit all REPT ALM, REPT EVT, and REPT SW autonomous messages, use the following: ALW-MSG-ALL:ons155xx::123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.3 ALW-SWDX-EQPT: Allow Switch Duplex Equipment

Use this command to switch between active and standby processor cards.

| Section | ALW-SWDX-EQPT Description |
|------------------|---|
| Category | Redundancy configuration |
| Security | Maintenance |
| Related Messages | 3.36 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment 3.86 SW-DX-EQPT: Switch Duplex Equipment |
| Input Format | ALW-SWDX-EQPT:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag. |
| Input Example | To switch between active and standby processor cards, use the following: ALW-SWDX-EQPT:ons155xx:SLOT-6:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.4 CANC-USER: Cancel User

Use this command to log out of the NE.



| Section | CANC-USER Description |
|------------------|--|
| Category | Security |
| Security | Retrieve |
| Related Messages | 3.1 ACT-USER: Activate User 3.14 DLT-USER-SECU: Delete User Security 3.25 ED-USER-SECU: Edit User Security 3.33 ENT-USER-SECU: Enter User Security 3.79 RTRV-USER-SECU: Retrieve User Security |
| Input Format | CANC-USER:[<tid>]:<uid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier. • <ctag> is the correlation tag. |
| Input Example | To log out of the NE, use the following: CANC-USER:ons155xx:admin:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.5 CPY-MEM: Copy Memory

Use this command to copy the contents from one memory location to another.

The AID of the memory device is specified in the <fromdev> and <todev> fields. Optionally, these fields can be set to NULL and the necessary information can be specified as part of the user defined text string in <frommem> and <tomem>.

| Section | CPY-MEM Description |
|------------------|--|
| Category | Memory management |
| Security | Maintenance |
| Related Messages | 3.34 FORMAT-MEM: Format Memory 3.47 RST-MEM: Restore Memory 3.62 RTRV-MEM: Retrieve Memory |

| Section | CPY-MEM Description |
|---------------|---|
| Input Format | <p>CPY-MEM:[<tid>]::<ctag>::<frommem>,<fromdev>,<tomem>,<todev>]: [CMDMODE=<mode>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <frommem> specifies the name of the source file to copy. • <tomem> specifies the name of the target file to which to copy the contents of the file specified in <frommem>. • <fromdev> indicates the name of the source device from which a file is copied. • <todev> indicates the name of the target device to which a file is copied. • <mode> indicates the mode of operation. Valid values are FRCD or NORMAL. In FRCD mode of operation, any existing file is overwritten. In NORMAL mode of operation, if a file is already present by the name specified in <tomem>, the copy request is denied. The default mode is NORMAL. <p> Note If this command is used to copy a file to a TFTP location, then the CMDMODE parameter is ignored and any existing file is overwritten.</p> |
| Input Example | <p>To copy the configuration from running-config to startup-config, use the following:</p> <pre>CPY-MEM:ons155xx::123::"running-config", "startup-config";</pre> <p> Note The double quotes are optional in the previous example.</p> <p>To copy the configuration from a TFTP location, use the following:</p> <pre>CPY-MEM:ons155xx::123::"tftp://172.20.46.50/admin/ons15540-i-mz", "bootflash:ons15540-i-mz";</pre> <p>To copy an image from the bootflash memory to the Flash PC card in slot 0, use the following:</p> <pre>CPY-MEM:ons155xx::123::"bootflash:ons15540-i-mz", "disk0:ons15540-i-mz";</pre> <p>To use the <fromdev> and <todev> parameters to specify the Flash PC devices involved, use the following:</p> <pre>CPY-MEM:ons155xx::123::"ons15540-i-mz",BOOTFLASH,"ons15540-i-mz", DISK-0;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.6 DLT-FFP-OCH: Delete Facility Protection OCH

Use this command to delete a facility protection group.

This command behaves as if executed in forced mode. Upon deletion of a protection group, the system switches service to the working line, irrespective of the state of the working line.

| Section | DLT-FFP-OCH Description |
|------------------|--|
| Category | APS |
| Security | Retrieve |
| Related Messages | 3.16 ED-FFP-OCH: Edit Facility Protection 3.55 RTRV-FFP-OCH: Retrieve Facility Protection OCH |
| Input Format | DLT-FFP-OCH:[<tid>]:<wkg_aid>,<prot_aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working port AID. Valid values are WAVEPATCH-slot-subcard-port, TRANSPARENT-slot-subcard-0, TENGIGETHERPHY-slot-subcard, or WDMSPPLIT-slot-subcard-port. • <prot_aid> is the protection port AID. Valid values are WAVEPATCH-slot-subcard-port, TRANSPARENT-slot-subcard-0, TENGIGETHERPHY-slot-subcard, or WDMSPPLIT-slot-subcard-port. • <ctag> is the correlation tag. |
| Input Example | To delete a facility protection group, use the following: DLT-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:125; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.7 DLT-IP: Delete IP

Use this command to delete IP related configurations on the network management Ethernet port or the OSC interface.

| Section | DLT-IP Description |
|------------------|---|
| Category | IP configuration |
| Security | Retrieve |
| Related Messages | 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.18 ED-IP: Edit IP 3.27 ENT-IP: Enter IP 3.59 RTRV-IP: Retrieve IP 3.60 RTRV-IPROUTE: Retrieve IP Route 3.85 SQUEEZE-MEM: Squeeze Memory |

| Section | DLT-IP Description (continued) |
|---------------|--|
| Input Format | DLT-IP:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid > is FE-0, FE-SBY-0, WAVE-slot, ETHERDCC-slot-subcard-0, or LOOPBACK-[0-255]. • <ctag> is the correlation tag. |
| Input Example | To delete IP-related configurations on the active NME port, use the following: DLT-IP:ons155xx:FE-0:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.8 DLT-IPROUTE-STATIC: Delete IP Route Static

Use this command to delete IP static routes.

| Section | DLT-IPROUTE-STATIC Description |
|------------------|---|
| Category | IP configuration |
| Security | Provisioning |
| Related Messages | 3.7 DLT-IP: Delete IP 3.18 ED-IP: Edit IP 3.27 ENT-IP: Enter IP 3.59 RTRV-IP: Retrieve IP 3.60 RTRV-IPROUTE: Retrieve IP Route 3.85 SQUEEZE-MEM: Squeeze Memory |
| Input Format | DLT-IPROUTE-STATIC:[<tid>]::<ctag>:::PREFIXADDR=<addr>, PREFIXMASK=<mask>, [ROUTEIF=<interface>],[ROUTEADDR=<routeaddr>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <addr> is the IP address. • <mask> is the IP subnet mask. • <interface> is the static route interface AID. • <routeaddr> is the static route IP address. |
| Input Example | To delete IP static routes, use the following: DLT-IPROUTE-STATIC:ons155xx::123:::PREFIXADDR=10.1.0.0, PREFIXMASK=255.255.0.0, ROUTEIF=WAVE-1; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.9 DLT-MEM: Delete Memory

Use this command to delete a file from memory specified by the AID.

The file is simply marked as deleted but not erased from memory.

| Section | DLT-MEM Description |
|------------------|--|
| Category | Memory Management |
| Security | Provisioning |
| Related Messages | 3.5 CPY-MEM: Copy Memory 3.47 RST-MEM: Restore Memory 3.62 RTRV-MEM: Retrieve Memory |
| Input Format | DLT-MEM:[<tid>]:<aid>:<ctag>::FILENAME=<filename>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is being deleted. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <filename> is the filename. |
| Input Example | To delete a file from memory specified by the AID, use the following: DLT-MEM:ons155xx:DISK-0:123::"ons15540-i-mz"; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.10 DLT-NBR: Delete Neighbor

Use this command to delete neighbor entries for a port or to disable learning through CDP on a port.

If LINKDIRN is specified, then only the neighbor entry for that particular direction is deleted.

Otherwise, all neighbor entries on the port are deleted.



Note

If neighbors are discovered through CDP, then LINKDIRN is always both and the value specified in LINKDIRN is ignored.

| Section | DLT-NBR Description |
|------------------|--|
| Category | Topology neighbor configuration |
| Security | Maintenance |
| Related Messages | 3.29 ENT-NBR: Enter Neighbor 3.63 RTRV-NBR: Retrieve Neighbor |

| Section | DLT-NBR Description (continued) |
|---------------|---|
| Input Format | <p>DLT-NBR:[<tid>]:<aid>:<ctag>:::[LINKDIRN=<linkdirn>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <aid> identifies the interface and can be one of the following: <ul style="list-style-type: none"> – TENGIGETHERPHY-slot-subcard-0 – TRANSPARENT-slot-subcard-0 – WDM-slot-subcard • <linkdirn > is the link direction. Both transmit and receive links of this port are connected to the neighbor specified by the rest of the command. <ul style="list-style-type: none"> – BOTH - The neighbor is on both the transmit and receive link of this port. BOTH is the default. – TX - The neighbor is on the transmit link of this port. – RX - The neighbor is on the receive link of this port. <p>For direct links between nodes, LINKDIRN is set to BOTH because there is only one neighbor connected to the port. For configurations with an EDFA connected in one direction, use TX or RX, as appropriate, for the EDFA or neighboring node connected to the port.</p> |
| Input Example | <p>To delete a physical neighbor in the transmit direction, use the following:</p> <p>DLT-NBR:ons155xx:WDM-0-0:125:::LINKDIRN=TX;</p> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.11 DLT-NTPASSOC: Delete NTP Associations

Use this command to delete an existing NTP association.

| Section | DLT-NTPASSOC Description |
|------------------|---|
| Category | NTP |
| Security | Provisioning |
| Related Messages | <p>3.30 ENT-NTPASSOC: Enter NTP Associations</p> <p>3.67 RTRV-NTP: Retrieve NTP</p> <p>3.68 RTRV-NTPASSOC: Retrieve NTP Associations</p> |
| Input Format | <p>DLT-NTPASSOC:[<tid>]:<ctag>:::ASSOCTYPE=<assoctype>, ASSOCIPADDR=<associpaddr>;</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <assoctype> is the association type. Valid values are PEER or SERVER. • <associpaddr> is the association IP address. |

| Section | DLT-NTPASSOC Description (continued) |
|---------------|---|
| Input Example | To delete an existing NTP association, use the following: DLT-NTPASSOC:ons155xx::123::ASSOCTYPE=SERVER, ASSOCIPADDR=172.16.246.1; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.12 DLT-PATCH: Delete Patch

Use this command to delete a patch configuration.

The CTYPE value for an existing patch cannot be edited. You must delete the patch and make a new patch with the new CTYPE value.

| Section | DLT-PATCH Description |
|------------------|---|
| Category | Patch configuration |
| Security | Provisioning |
| Related Messages | 3.31 ENT-PATCH: Enter Patch 3.70 RTRV-PATCH: Retrieve Patch |
| Input Example | DLT-PATCH:<tid>:<from_aid>,<to_aid>:<ctag>; <ul style="list-style-type: none"> • <tid> is the target identifier. • <from_aid> identifies the port patched from, to the port identified by <to_aid>. Valid values for <from_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <to_aid> identifies the port patched to, from the port identified by <from_aid>. Valid values for <to_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <ctag> is the correlation tag. |
| Input Example | To delete a patch configuration, use the following: DLT-PATCH:ons155xx:WDM-0-0,THRU-0-0:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.13 DLT-THR-OCH: Delete Threshold OCH

Use this command to delete either a complete alarm threshold list or particular thresholds within a list.

When deleting particular thresholds from a list, both the ERRTYPE and THRTYPE parameters must be specified.

| Section | DLT-THR-OCH Description |
|------------------|--|
| Category | Threshold list configuration |
| Security | Provisioning Maintenance |
| Related Messages | 3.32 ENT-THR-OCH: Enter Thresholds OCH 3.76 RTRV-THR-OCH: Retrieve Thresholds OCH 3.77 RTRV-TH-rr: Retrieve Threshold 3.84 SET-TH-rr: Set Optical Threshold |
| Input Format | <p>DLT-THR-OCH:[<tid>]:<thrlistname>:<ctag>:::[ERRTYPE=<errtype>, THRTYPE=<thrtype>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <thrlistname> specifies the threshold list. • <ctag> is the correlation tag. • <errtype> indicates the type of error counter to which the threshold applies. Valid values are as follows: <ul style="list-style-type: none"> – CVS - SONET/SDH section CV errors – CVRD - 8B/10B code violations and running disparity errors – CDLHEC - CDL HEC errors – CRC - Cyclic redundancy check errors • <thrtype> indicates the threshold type. Valid values are as follows: <ul style="list-style-type: none"> – DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. – FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. – EVTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. – ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. |
| Input Example | <p>To delete the threshold list or particular thresholds, use the following:</p> <pre>DLT-THR-OCH:ons155xx:sonet-cvs:123;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.14 DLT-USER-SECU: Delete User Security

Use this command to delete an existing user account.

| Section | DLT-USER-SECU Description |
|------------------|--|
| Category | Security |
| Security | Retrieve |
| Related Messages | 3.1 ACT-USER: Activate User 3.4 CANC-USER: Cancel User 3.25 ED-USER-SECU: Edit User Security 3.33 ENT-USER-SECU: Enter User Security 3.79 RTRV-USER-SECU: Retrieve User Security |
| Input Format | DLT-USER-SECU:[<tid>]:<uid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier. • <ctag> is the correlation tag. |
| Input Example | To delete an existing user account, use the following: DLT-USER-SECU:ons155xx:admin:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.15 ED-DAT: Edit Date

Use this command to edit the date and time on the NE.

| Section | ED-DAT Description |
|------------------|--|
| Category | Generic NE configuration |
| Security | Provisioning |
| Related Messages | 3.58 RTRV-HDR: Retrieve Header 3.78 RTRV-TOD: Retrieve Time of Day |
| Input Format | ED-DAT:[<tid>]::<ctag>::[<date>],[<time>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <date> is the current date. The format is YY-MM-DD. • <time> is the current time. The format is HH-MM-SS. |
| Input Example | To edit the date and time on the NE, use the following: ED-DAT:ons155xx::123::03-02-11; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.16 ED-FFP-OCH: Edit Facility Protection

Use this command to edit the attributes associated with an already created optical 1+1 protection channel and to put the protection group in-service or out-of-service. If the protection group is put out-of-service, then the currently active path continues to remain as the active path.

| Section | ED-FFP-OCH Description |
|------------------|--|
| Category | APS |
| Security | Retrieve |
| Related Messages | 3.6 DLT-FFP-OCH: Delete Facility Protection OCH 3.55 RTRV-FFP-OCH: Retrieve Facility Protection OCH |
| Input Format | <p>ED-FFP-OCH:[<tid>]:<wkg_aid>,<prot_aid>:<ctag>:::[PROTID=<protid>], [PSDIRN=<psdirn>], [RVRTV=<rvrtv>],[RVRTM=<rvrtm>], [YCABLE=<ycable>],[ENSWOTM=<enswotm>], [MSGCH=<msgch>], [MSGHOLDTM=<msgholdtm>], [MSGHOLDCOUNT=<msgholdcount>], [MSGMAXINTVTM=<msgmaxintvtm>], [FENDPROTID=<fendprotid>], [FENDIPADDR=<fendipaddr>]: [<pst>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working port AID. Valid values are WAVEPATCH-slot-subcard-port, TRANSPARENT-slot-subcard-0, TENGIGETHERPHY-slot-subcard, or WDMSPLIT-slot-subcard-port. • <prot_aid> is the protection port AID. Valid values are WAVEPATCH-slot-subcard-port, TRANSPARENT-slot-subcard-0, TENGIGETHERPHY-slot-subcard, or WDMSPLIT-slot-subcard-port. • <ctag> is the correlation tag. • <protid> is the protection group identifier. It is a case-sensitive string and can have a maximum of 32 characters. If <protid> is not specified, a protection group name is created with the name of the <wkg_aid>. • <psdirn> is the protection switch direction. Valid values are UNI (unidirectional) and BI (bidirectional). The default is UNI. • <rvrtv> specifies the revertive mode. This feature applies only to y-cable protection. Valid values are Y or N. The default is N. • <rvrtm> is the revertive timer, which applies only if the revertive mode is enabled. The revertive timer specifies the interval to wait before performing a revertive switch. The range is 0 to 720 seconds. The default is 300 seconds. • <ycable> specifies the y-cable mode. This parameter indicates whether the type of protection is y-cable or not. Valid values are Y or N. The default is N. • <enswotm> is the switchover enable timer. This timer is used to delay reenabling of auto-failover to prevent rapid switching between the standby and active links. The range of values is 1 to 120 seconds. The default is 2 seconds. |

| Section | ED-FFP-OCH Description (continued) |
|--------------------------|--|
| Input Format (continued) | <ul style="list-style-type: none"> • <msgch> APS Message Channel. This parameter configures the type of transport channel used to exchange APS protocol messages. Valid values are as follows: <ul style="list-style-type: none"> - DCC - APS messages are transmitted over the data communications channels (DCCs) in the overhead of the associated channels. - OSC - APS messages are transmitted over the Optical Supervisory Channel. - AUTO - APS automatically selects a transport mechanism to send APS messages. The DCC and OSC transport mechanisms are attempted. - IP - APS messages are transmitted over IP. The IP network can consist of any combination of DCCs, OSCs and out-of-band data communication networks (DCNs). <p>The default is AUTO.</p> • <msgholdtm> is the APS message channel holddown timer. This parameter specifies the minimum time between successive event-triggered APS messages, in units of milliseconds. The range is 100 to 10,000 milliseconds. The default is 5000 milliseconds. • <msgholdcount> is the APS channel message holddown count. This parameter specifies the maximum number of APS messages that can be sent within one MSGHOLDTM interval. The range is 2 to 10 messages. The default is 2 messages. • <msgmaxintvmtm> is the APS channel message maximum interval timer. An APS message is sent unconditionally, whenever the interval specified has elapsed since the last transmission of an APS message. The range is 1 to 120 seconds. The default is 15 seconds. • <fendprotid> is the far-end protection ID. This parameter is a case-sensitive string specifying the APS group at the far-end NE to which the message is being sent over DCC, IP, or OSC message channels. • <fendipaddr> is the far-end IP address. This parameter specifies the IP address of the far-end NE, which is used as the destination address when APS messages are transmitted over the IP message channel. • <pst> is the primary state, used to administratively control the state of the interface, whether it is IS (in-service) or OOS (out-of-service). It also controls the state of the laser on this interface. The default value is IS. If an interface is administratively shut down, then the laser on the interface still sends management and control information. The laser needs to be shut down explicitly. To shut down the interface alone, use OOS-MA as the PST value. To shut down the laser as well, use the PST value of OOS-MA and the SST value of LASERSHUT. |
| Input Example | <p>To enable a previously configured APS group, use the following:</p> <pre>ED-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:123::: IS;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.17 ED-GBE10: Edit 10-GE

Use this command to configure the 10-GE transponder module interfaces, including forced end-of-hop behavior supported by CDL (Converged Data Link). CDL provides OAM&P (operation, administration, maintenance and provisioning) in Ethernet packet-based optical networks without a SONET/SDH layer.

| Section | ED-GBE10 Description |
|------------------|--|
| Category | Interface configuration-10 GE |
| Security | Provisioning |
| Related Messages | 3.57 RTRV-GBE10: Retrieve 10-GE Interfaces |

| Section | ED-GBE10 Description (continued) |
|---------------|--|
| Input Format | <p>ED-GBE10:[<tid>]:<aid>:<ctag>::[CDL=<cdl>],[FLC=<flc>],[FRCENDHOP=<frcendhop>],[THRLISTNAME=<thrlistname>]:[<pst>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the interface and can be one of the following: <ul style="list-style-type: none"> – WAVEETHERPHY-slot-subcard – TENGIGETHERPHY-slot-subcard – WAVEPATCH-slot-subcard-port • <cdl> enables or disables the CDL on the given interface. This is applicable only on TENGIGETHERPHY-slot-subcard and WAVEETHERPHY-slot-subcard AIDs. If CDL is enabled on a tengigetherphy interface, an etherdcc interface is created with AID of ETHERDCC-slot-subcard-1. Valid values are Y or N. The default value is N. • <flc> enables or disables forward laser control on TENGIGETHERPHY-slot-subcard and WAVEETHERPHY-slot-subcard AIDs. If forward laser control is enabled, the transmit laser is shut when the cross-connect receive port on the switch is in alarm condition. Valid values are Y or N. The default is N. • <frcendhop> enables or disables the CDL end-of-hop behavior on the given interface. Valid values are Y or N. The default value is N. <p>The CDL node behavior defines how defect indications are handled. A node behaving as end-of-hop terminates hop-by-hop defect indications. This configuration is valid only when APS is not configured on the interface. If APS is configured, the node behaves as end-of-hop regardless of this object setting. If APS is not configured, we recommend forcing the end-of-hop behavior at administrative boundaries. This ensures that FDI-H and BDI-H between two admin domains reflects only errors that occur between the domains. This parameter can only be used with aid WAVEETHERPHY-slot-subcard.</p> <ul style="list-style-type: none"> • <thrlistname> assigns a threshold list name to a TENGIGETHERPHY-slot-subcard or WAVEETHERPHY-slot-subcard AID. The threshold list sets thresholds for errors being monitored on this interface. The operator associates multiple threshold lists with an interface. To remove a threshold list from an interface, a NULL value should be passed for that particular list, using the ED-GBE10 command. • <pst> administratively controls the state of the interface, whether it is IS (in-service) or OOS (out-of-service). It also controls the state of the laser on this interface. The default value is IS. If an interface is administratively shut down, the laser on the interface still sends management and control information. The laser needs to be shut down explicitly. To shut down the interface alone, the PST value of OOS-MA should be used. To shut down the laser as well, the PST value of OOS-MA and SST value of LASERSHUT should be used. |
| Input Example | <p>To force end-of-hop behavior on the waveetherphy interface in slot 9, subcard 0, use the following:</p> <pre>ED-GBE10:ons155xx:WAVEETHERPHY-9-0:123:::FRCENDHOP=Y;</pre> |
| Errors | <p>Errors are listed in Table 2-15 on page 2-9.</p> |

3.18 ED-IP: Edit IP

Use this command to edit the IP address and mask on the network management Ethernet port or the OSC wave interface.


Note


This command cannot be used to change an unnumbered interface configuration. To modify an unnumbered interface configuration, delete the existing configuration using the DLT-IP command and reconfigure using the ENT-IP command.

| Section | ED-IP Description |
|------------------|---|
| Category | IP configuration |
| Security | Retrieve |
| Related Messages | 3.7 DLT-IP: Delete IP 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.27 ENT-IP: Enter IP 3.59 RTRV-IP: Retrieve IP 3.60 RTRV-IPROUTE: Retrieve IP Route 3.85 SQUEEZE-MEM: Squeeze Memory |
| Input Format | ED-IP:[<tid>]:<aid>:<ctag>:::IPADDR=<addr>,IPMASK=<mask>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are FE-0, SBY-FE-0, or WAVE-slot. • <ctag> is the correlation tag. • <addr> is the IP address. • <mask> is the IP subnet mask. |
| Input Example | Assuming that an IP address was previously configured on the FE-0 interface, to change the address and mask values, use the following: ED-IP:ons155xx:FE-0:123:::IPADDR=172.16.30.10, IPMASK=255.255.0.0; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.19 ED-NE-CDP: Edit Network Element CDP

Use this global level CDP command to edit CDP attributes for the entire system.

| Section | ED-NE-CDP Description |
|------------------|--|
| Category | CDP |
| Security | Provisioning |
| Related Messages | 3.64 RTRV-NE-CDP: Retrieve Network Element CDP |

| Section | ED-NE-CDP Description (continued) |
|---------------|---|
| Input Format | <p>ED-NE-CDP:[<tid>]::<ctag>:::[CDP=<cdp>],[UPDATETIME=<updatetime>],[HOLDTIME=<holdtime>],[SENDVER=<sendver>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <cdp> enables or disables CDP at the NE level. Valid values are Y or N. The default value is Y. • <updatetime> specifies how often the NE sends CDP packets. Valid values range from 5 to 254 seconds. The default value is 60 seconds. • <holdtime> sets the time for which a received CDP packet must be held before discarding. Valid values range from 10 to 255 seconds. The default value is 180 seconds. <p> Note The holdtime should not be set to a value less than the updatetime value.</p> <ul style="list-style-type: none"> • <sendver> indicates the highest version of CDP packets being sent. Valid values are 1 or 2. If SENDVER is 2, then both CDP version 1 and version 2 are sent by the NE. If SENDVER is 1, then only CDP version 1 packets are sent by the NE. The default is 2. |
| Input Example | <p>To edit CDP attributes for the NE, use the following:</p> <pre>ED-NE-CDP:ons155xx::123::UPDATETIME=30,HOLDTIME=90;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.20 ED-NE-GEN: Edit Network Element General

Use this command for generic NE configurations.

| Section | ED-NE-GEN Description |
|------------------|---|
| Category | Generic NE configuration |
| Security | Retrieve |
| Related Messages | 3.65 RTRV-NE-GEN: Retrieve Generic NE Configuration Values |
| Input Format | <p>ED-NE-GEN:[<tid>]::<ctag>:::[CFGREG=<configregval>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <configregval> is the string value that specifies the configuration register setting in hexadecimal. |

| Section | ED-NE-GEN Description (continued) |
|---------------|---|
| Input Example | To edit general NE configurations, use the following: ED-NE-GEN:ons155xx::123::CFGREG=0x0; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.21 ED-NE-OSCP: Edit Network Element OSCP

Use this command to configure the OSCP protocol.

| Section | ED-NE-OSCP Description |
|------------------|--|
| Category | OSCP |
| Security | Provisioning |
| Related Messages | 3.66 RTRV-NE-OSCP: Retrieve Network Element OSCP |
| Input Format | ED-NE-OSCP:[<tid>]::<ctag>:::[HELLOINTV=<hello_intv>], [HELLOHLDWN=<hldwn_time>],[INACTFCTR=<factor>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <hello_intv> is the Hello interval. It is the time between successive Hello packets in milliseconds. Valid values range from 100 to 10,000 ms. The default value is 200 ms. • <hldwn_time> is the Hello hold down timer. It is the time interval for which no more than one Hello packet can be sent. Valid values range from 150 to 30,000 ms. The default value is 3000 ms. • <factor> is the inactivity factor. It is the number of Hello intervals to wait before declaring a link as down. Valid values range from 1 to 150. The default value is 5. |
| Input Example | To configure OSCP protocol parameters, use the following: ED-NE-OSCP:ons155xx::123::HELLOINTV=500,HELLOHLDWN=200,INACTFCTR=10; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |


3.22 ED-OCH: Edit Optical Channel

Use this command to configure attributes on a transparent interface.

| Section | ED-OCH Description |
|----------|-------------------------------------|
| Category | Transparent interface configuration |
| Security | Provisioning |

| Section | ED-OCH Description (continued) |
|------------------|---|
| Related Messages | 3.69 RTRV-OCH: Retrieve Optical Channel 3.42 OPR-LPBK-OCH: Operate Loopback OCH 3.69 RTRV-OCH: Retrieve Optical Channel |

| Section | ED-OCH Description (continued) |
|------------------|---|
| Related Messages | 3.69 RTRV-OCH: Retrieve Optical Channel |
| | 3.42 OPR-LPBK-OCH: Operate Loopback OCH |
| | 3.69 RTRV-OCH: Retrieve Optical Channel |

| Section | ED-OCH Description (continued) |
|--------------|--|
| Input Format | <p data-bbox="578 264 1518 359">ED-OCH:[<tid>]:<aid>:<ctag>:::[ENCAP=<encap>],[RATE=<rate>],[FLC=<flc>],[LSC=<lsc>],[OFC=<ofc>],[THRLISTNAME=<name>],[CDP=<cdp>],[LASERFREQ=<laserfreq>]:[<pst>];</p> <p data-bbox="578 369 659 401">Where:</p> <ul data-bbox="594 422 1518 1535" style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface configured. Valid values of AID are TRANSPARENT-slot-subcard-0, WAVE-slot-subcard, WAVE-slot, WAVEPATCH-slot-subcard-port, and ETHERDCC-slot-subcard-port. • <encap> indicates the protocol encapsulation configured on the transparent interface only. Valid values are as follows: <ul style="list-style-type: none"> - OC3 - OC12 - OC48 - STM1 - STM4 - STM16 - ESCON - FE - FDDI - FICON-1G - FICON-2G - FC-1G - FC-2G - SYSPLEX-CLO - SYSPLEX-ETR - SYSPLEX-ISC-COMP - SYSPLEX-ISC-PEER - GIGE - TENGIGE - UNKNOWN <p data-bbox="578 1556 626 1587"></p> <p data-bbox="578 1598 1518 1692">Note The default value is UNKNOWN. This parameter can be modified only when the interface is in the OOS state or when it is being brought down to OOS state in the same command.</p> <ul data-bbox="594 1724 1518 1785" style="list-style-type: none"> • <rate> indicates the clock rate being configured on a transparent interface. This parameter is configured only when the encapsulation is set to UNKNOWN. |

| Section | ED-OCH Description (continued) |
|--------------------------|---|
| Input Format (continued) | <ul style="list-style-type: none"> • <flc> enables and disables forward laser control. If forward laser control is enabled, the transmit laser is shut down when the cross connect receive port on the switch is in alarm condition. Valid values are Y or N. The default is N. • <lsc> enables or disables laser safety control. The LSC parameter can be configured on wave interfaces only when the carrier boards have no optical splitter. If laser safety control is enabled, the transmit laser on the trunk side is shut down when the receive signal is not available on the fiber. Valid values are Y or N. The default value is N. • <ofc> enables or disables the OFC (open fibre control) safety protocol. The OFC parameter can be modified only when the encapsulation is FC-1G, FC-2G, or FICON and applies to transparent interfaces only. Valid values are Y or N. The default value is N. • <thrlistname> refers to the name entered using the ENT-THR-OCH command. The threshold list sets thresholds for errors monitored on this interface. The ampersand (&) operator associates multiple threshold lists with an interface. To delete a threshold list from an interface, a null value should be passed for that particular list, using the ED-OCH command. • <cdp> enables or disables CDP (Cisco Discovery Protocol) on this port. It applies to the WAVE-slot (OSC) and ETHERDCC ports only. Valid values are Y or N. The default is Y. • <laserfreq> specifies the transmit frequency transponder modules capable of generating more than one laser frequency. The frequency is represented in GHz. This parameter applies only to WAVE-slot-subcard AIDs and can be modified only when the interface is in the OOS (out-of-service) state or when it is brought down to OOS state with this command. The default is the lower frequency for the transponder module. • <pst> is the primary state. The value set in this state determines if the interface is shut down or active. IS (in-service) renders the interface administratively up. OOS is used to administratively shut down the interface. The default value is OOS. |

| Section | ED-OCH Description (continued) |
|---------------|--|
| Input Example | <p>To configure SONET OC-12 service, enable FLC, and associate the threshold list named “sonet-cvs” on the transparent interface in slot 3, subcard 0, use the following:</p> <pre>ED-OCH:ons155xx:TRANSPARENT-3-0-0:123:::ENCAP=OC12,FLC=Y, THRLISTNAME=sonet-cvs;</pre> <p>To configure the wave interface in slot 2, subcard 0, with FLC and LSC enabled, use the following:</p> <pre>ED-OCH:ons155xx:WAVE-2-0:123:::THRLISTNAME=sonet-cvs,FLC=Y, LSC=Y, LASERFREQ=159800;</pre> <p>To configure an unknown protocol with a rate of 125,000 Kbps on a transparent interface in slot 2, subcard 0, use the following:</p> <pre>ED-OCH:ons155xx:TRANSPARENT-2-0-0:123:::ENCAP=UNKNOWN, RATE=125000;</pre> <p>To enable or disable the OFC safety protocol on a transparent interface in slot 2, subcard 0, use the following:</p> <pre>ED-OCH:ons155xx:TRANSPARENT-2-0-0:123:::ENCAP=FC-1G,OFC=Y;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.23 ED-PID: Edit Password

Use this command to edit your own password.

| Section | ED-PID Description |
|------------------|---|
| Category | Security |
| Security | Provisioning |
| Related Messages | 3.1 ACT-USER: Activate User, page 3-1 |
| Input Format | <p>ED-PID:[<tid>]:<uid>:<ctag>::<oldpid>,<newpid>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier, a string value with a maximum size of 64 characters. • <ctag> is the correlation tag. • <oldpid> is the old password, which is a string with a maximum size of 25 characters. • <newpid> is the new user login password, which is a string with a maximum size of 25 characters. |
| Input Example | <p>To edit your own password, use the following:</p> <pre>ED-PID:ons155xx:admin:123::mypswn,newpswn;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.24 ED-THR-OCH: Edit Thresholds OCH

Use this command to edit the parameters for an existing threshold in a list.

| Section | ED-THR-OCH Description |
|------------------|--|
| Category | Threshold list configuration |
| Security | Retrieve |
| Related Messages | 3.76 RTRV-THR-OCH: Retrieve Thresholds OCH 3.84 SET-TH-rr: Set Optical Threshold |
| Input Format | <p>ED-THR-OCH:[<tid>]:<thrlistname>:<ctag>::ERRTYPE=<errtype>, THRTYPE=<thrtype>, [VALUE=<value>], [TRGAPS=<trgaps>], [DESCR=<descr>];</p> <p>where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <thrlistname> indicates the name of the threshold list being edited. • <ctag> is the correlation tag. • <errtype> indicates the type of error counter to which the threshold applies. Possible values are as follows: <ul style="list-style-type: none"> – CVS – SONET section CV errors – CVRD – 8B/10B code violations and running disparity errors – CDLHEC – CDL HEC errors – CRC – Cyclic redundancy check errors • <thrtype> indicates the threshold type. Valid values are as follows: <ul style="list-style-type: none"> – DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. – FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. – EVTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. – ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. • <value> specifies the threshold. If the value assigned here is x, the actual threshold is in the form of 10^{-x}. • <trgaps> is the APS trigger. If enabled, a protection switch occurs when the threshold is exceeded. Valid values are Y or N. The default value is Y when ERRTYPE is CVS and N for all other ERRTYPE values. • <index> is an integer value used to uniquely identify a particular threshold within a list of thresholds. The range is 1 to 64. When no value is specified for this parameter, the index for the threshold being created defaults to the lowest available index in that threshold list. • <descr> is a string used to assign a description to the threshold that is being configured. The maximum length of this string is 255 characters. |

| Section | ED-THR-OCH Description (continued) |
|---------------|--|
| Input Example | To edit the parameters for an existing threshold in a list, use the following: ED-THR-OCH:ons155xx:sonet-cvs:123:::ERRTYPE=CVS,THRTYPE=DEG, VALUE=5; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.25 ED-USER-SECU: Edit User Security

Use this command to edit the user identifier, password, or privilege levels associated with a user.



Note

Only a superuser can perform this function.

| Section | ED-USER-SECU Description |
|------------------|--|
| Category | Threshold list configuration |
| Security | Retrieve |
| Related Messages | 3.1 ACT-USER: Activate User 3.14 DLT-USER-SECU: Delete User Security 3.33 ENT-USER-SECU: Enter User Security 3.79 RTRV-USER-SECU: Retrieve User Security |
| Input Format | <p>[<tid>]:<uid>:<ctag>::<newuid>,<newpid>,,<uap>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier, a string value with a maximum size of 64 characters. • <ctag> is the correlation tag. • <newuid> is the new value of the user identifier. It replaces the old value indicated by the <uid>. This field has the same format as the <uid> field. • <uap> is the user access privilege level. Valid values are as follows: <ul style="list-style-type: none"> – MAINT - maintenance level – PROV - provisioning level – RTRV - retrieve level – SUPER - superuser level |
| Input Example | To edit the user identifier, password, or privilege levels associated with a user, use the following: ED-USER-SECU:ons155xx:admin:123::sonalm,password,,PROV; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.26 ENT-FFP-OCH: Enter Optical Protection


Use this command to configure splitter protection, line card protection, and trunk fiber based protection.

| Section | ENT-FFP-OCH Description |
|------------------|---|
| Category | APS |
| Security | Retrieve |
| Related Messages | 3.6 DLT-FFP-OCH: Delete Facility Protection OCH 3.55 RTRV-FFP-OCH: Retrieve Facility Protection OCH |
| Input Format | <p>ENT-FFP-OCH:[<tid>]:<wkg_aid>,<prot_aid>:<ctag>:::[PROTID=<protid>], [PSDIRN=<psdirn>], [RVRTV=<rvrtv>],[RVRTM=<rvrtm>], [YCABLE=<ycable>],[ENSWOTM=<enswotm>], [MSGCH=<msgch>],[MSGHOLDTM=<msgholdtm>], [MSGHOLDCOUNT=<msgholdcount>], [MSGMAXINTVTM=<msgmaxintvtm>], [FENDPROTID=<fendprotid>], [FENDIPADDR=<fendipaddr>]: [<pst>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working port AID. For splitter protection, the AID is in the form WAVEPATCH-slot-subcard-port, where port equals 0 or 1. For y-cable protection, the AID is in the form TRANSPARENT-slot-subcard-0 or TENGIGETHERPHY-slot-subcard. For trunk fiber based protection, the AID is WDMSPPLIT-slot-subcard-port, where port is 0 or 1. • <prot_aid> is the protection port AID. For splitter protection, the AID refers to the wavepatch interface. Hence, the AID is in the form wavepatch-slot-subcard-port, where port equals 0 or 1. For the y-cable protection scheme, the AID is in the form TRANSPARENT-slot-subcard-0 or TENGIGETHERPHY-slot-subcard. For trunk fiber based protection, the AID is WDMSPPLIT-slot-subcard-port, where port is 0 or 1. • <ctag> is the correlation tag. • <protid> is the protection group identifier or protection group name. The string can have a maximum of 32 characters. If <protid> is not specified, a protection group name is created with the name of the wkg_aid. • <psdirn> is the switching mode. Valid values are UNI (unidirectional) and BI (bidirectional). The default is UNI. • <rvrtv> is the revertive mode that applies only if monitoring in the standby state is supported. Valid values are Y or N. The default is N. If the value is Y, then the protection switching system reverts service to the active line after restoration. • <rvrtm> is the revertive timer that applies only if the mode is revertive and specifies the wait interval for revertive switching. The range is 0 to 720 seconds. The default is 300 seconds. • <ycable> specifies whether the type of protection is y-cable or not. Valid values are Y or N. The default is N. • <enswotm> specifies the switchover-enable timer. The timer delays re-enabling of auto-failover (to prevent rapid switching between standby and active states). The range is 1 to 120 seconds and the default is two seconds. |

| Section | ENT-FFP-OCH Description (continued) |
|--------------------------|--|
| Input Format (continued) | <ul style="list-style-type: none"> • <msgch> specifies the APS message channel. This parameter configures the type of transport channel used to exchange APS protocol messages. Valid values are as follows: <ul style="list-style-type: none"> – DCC - APS messages are transmitted over the data communications channels (DCCs) in the overhead of the associated channels. – OSC - APS messages are transmitted over the optical supervisory channel. – AUTO - APS automatically selects a transport mechanism to send APS messages. DCC and OSC are attempted. – IP - APS messages are transmitted over IP. The IP network can consist of any combination of DCCs, OSCs and out-of-band Data Communication Networks (DCNs). The default is AUTO. • <msgholdtm> specifies the APS message channel holddown time. This parameter specifies the minimum time between successive event-triggered APS messages in units of milliseconds. The range is 100 to 10000 milliseconds. The default is 5000 milliseconds. • <msgholdcount> specifies the APS channel message holddown count. This parameter specifies the maximum number of APS messages that can be sent within one MSGHOLDTM interval. The range is 2 to 10 messages. The default is 2 messages. • <msgmaxintvmtm> specifies the APS channel message maximum interval time. An APS message is sent unconditionally whenever the amount of time specified by this object has elapsed since the last transmission of an APS message. The range is 1 to 120 seconds. The default is 15. • <fendprotid> is the far-end protection identifier. This parameter is a case-sensitive string specifying the APS group at the far-end NE to which the message is being sent over DCC, IP, or OSC message channels. • <fendipaddr> specifies the far end IP address. This parameter specifies the IP address of the far end, which is used as the destination address when APS messages are transmitted. • <pst> is the primary state. It sets the protection group to be in service or out of service, upon creation. Valid values are IS (in-service) and OOS (out-of-service). OOS-MA (OOS for maintenance) is implied. The default is IS. |
| Input Example | <p>To configure splitter protection, use the following:</p> <pre>ENT-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:123::: PROTID=switch1-aps,PSDIRN=BI:OOS;</pre> <p>To configure y-cable protection, use the following:</p> <pre>ENT-FFP-OCH:ons155xx:TRANSPARENT-3-0-0,TRANSPARENT-4-0-0::: PROTID=switch2-aps,RVRTV=Y,RVRTM=6,ENSWOTM=10,YCABLE=Y;</pre> <p>To configure trunk fiber based protection, use the following:</p> <pre>ENT-FFP-OCH:ons155xx:WDMSPPLIT-0-1-0,WDMSPPLIT-0-1-1::: PROTID=switch3-aps,PSDIRN=BI:IS;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |


3.27 ENT-IP: Enter IP

Use this command to configure the network management Ethernet port or the OSC interface.

| Section | ENT-IP Description |
|------------------|---|
| Category | IP configuration |
| Security | Retrieve |
| Related Messages | 3.7 DLT-IP: Delete IP 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.18 ED-IP: Edit IP 3.28 ENT-IPROUTE-STATIC: Enter Static Routes 3.59 RTRV-IP: Retrieve IP |
| Input Format | <p>ENT-IP:[<tid>]:<aid>:<ctag>:::IPADDRTYPE=<addr_type>,[IPADDR=<addr>],[IPMASK=<mask>],[IPUNIF=<interface>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid > is the access identifier. Valid values are FE-0, FE-SBY-0, WAVE-slot, ETHERDCC-slot-subcard-0, or LOOPBACK-[0-255]. If the AID is LOOPBACK-port, then the loopback interface is created and the parameters are assigned to it. • <ctag> is the correlation tag. • <addr_type> specifies the address type. This parameter has one of the following values: <ul style="list-style-type: none"> – ADDR indicates that the IP address is specified. – UNMBR indicates that the unnumbered interface is specified. • <addr> indicates the IP address. This parameter is mandatory if IPADDRTYPE is set to ADDR. • <mask> indicates the IP address subnet mask and is mandatory if IPADDRTYPE is set to ADDR. • <interface> shows the AID of the unnumbered interface and is mandatory if IPADDRTYPE is set to UNMBR. Applicable interfaces are as explained in the earlier <aid> description. <p> Note If the unnumbered and LOOPBACK-0 combination is used, the AID can be only WAVE-slot or ETHERDCC-slot-subcard-0.</p> |
| Input Example | <p>To configure an IP address on a network management interface, use the following:</p> <pre>ENT-IP:ons155xx:FE-0:123:::IPADDRTYPE=ADDR, IPADDR=172.16.42.110, IPMASK=255.255.255.0;</pre> <p>To unnumber WAVE-1-0 to LOOPBACK-0 interface, use the following:</p> <pre>ENT-IP:ons155xx:WAVE-1-0:123:::IPADDRTYPE=UNMBR, IPUNIF=LOOPBACK-0;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.28 ENT-IPROUTE-STATIC: Enter Static Routes


Use this command to create static routes.

| Section | ENT-IPROUTE-STATIC Description |
|------------------|--|
| Category | IP configuration |
| Security | Retrieve |
| Related Messages | 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.60 RTRV-IPROUTE: Retrieve IP Route |
| Input Format | <p>ENT-IPROUTE-STATIC:[<tid>]:<ctag>:::PREFIXADDR=<addr>, PREFIXMASK=<mask>, [ROUTEIF=<interface>], [ROUTEADDR=<routeaddr>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <addr> specifies the prefix IP address for the static route. • <mask> specifies the prefix mask. • <interface> specifies the AID of the routing interface. • <routeaddr > specifies the IP address of the routing interface <p> Note At least one of the two parameters, ROUTEIF or ROUTEADDR, needs to be specified. There is no Edit command associated with the Enter command. If any of the parameters associated with the static route needs to be changed, the entire route needs to be deleted and a new route created.</p> |
| Input Example | <p>To configure a static route for a particular address through the OSC WAVE-0 port, use the following:</p> <pre>ENT-IPROUTE-STATIC:ons155xx::123:::PREFIXADDR=10.1.0.0, PREFIXMASK=255.255.0.0, ROUTEIF=WAVE-0;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.29 ENT-NBR: Enter Neighbor

Use this command to configure a physical neighbor on a port.

| Section | ENT-NBR Description |
|------------------|---|
| Category | Topology neighbor configuration |
| Security | Provisioning |
| Related Messages | 3.10 DLT-NBR: Delete Neighbor 3.63 RTRV-NBR: Retrieve Neighbor |

| Section | ENT-NBR Description (continued) |
|--------------|---|
| Input Format | <p data-bbox="537 260 1472 359">ENT-NBR:[<tid>]:<aid>:<ctag>::DSCVRY=<dscvry>, [LINKDIRN=<linkdirn>], [NBRNAME=<nbrname>], [NBRPORT=<nbrport>], [NBRAGENTIP=<nbragentip>], [PRXYPORT=<prxyport>];</p> <p data-bbox="537 373 618 401">Where:</p> <ul data-bbox="553 422 1472 793" style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the interface and can be one of the following: <ul data-bbox="597 510 1024 625" style="list-style-type: none"> – TRANSPARENT-slot-subcard-0 – TENGIGETHERPHY-slot-subcard – WDM-slot-subcard • <dscvry> specifies the means of discovery of this neighbor. It could have one of the following values: <ul data-bbox="597 720 1398 793" style="list-style-type: none"> – CDP - The neighbor information learned dynamically through CDP. – MANUAL - The neighbor information manually entered by the user. <hr/> <p data-bbox="537 814 586 852"></p> <p data-bbox="537 856 1472 919">Note When CDP is specified, LINKDIRN defaults to both and other parameters should not be entered.</p> <hr/> <ul data-bbox="553 957 1472 1108" style="list-style-type: none"> • <linkdirn > is the link direction. Both transmit and receive links of this port are connected to the neighbor specified by the rest of the command. <ul data-bbox="597 1035 1235 1108" style="list-style-type: none"> – TX - The neighbor is on the transmit link of this port. – RX - The neighbor is on the receive link of this port. <p data-bbox="581 1125 1472 1251">For direct links between nodes, the LINKDIRN is both and there can be only one neighbor configured on the port. If an EDFA is connected to one direction of the port, there can be two neighbors, one configured for LINKDIRN = TX and the other for LINKDIRN = RX.</p> <ul data-bbox="553 1266 1472 1768" style="list-style-type: none"> • <nbrname> is the name of the neighbor NE. The string has a maximum of 64 characters and it is suggested that this be the <tid> of the neighbor NE. • <nbrport> is the name of the port on the neighbor NE. The string has a maximum of 32 characters and it is suggested that this be the <aid> of the port to which the local port is connected. • <nbragentip> is the IP address of the management agent on the neighbor. String has a maximum of 32 characters. • <prxyport> specifies the AID of the proxy port. This parameter is valid only when DSCVRY = CDP. In the case of external ports that do not run CDP on their own (but are intranode connected to a port running CDP), then physical topology on the external port can be learned through CDP running on the proxy port specified through this parameter. Valid AIDs are as follows: <ul data-bbox="597 1703 1040 1768" style="list-style-type: none"> – WAVE-slot (the OSC wave port) – ETHERNETDCC-slot-subcard-port. |

| Section | ENT-NBR Description (continued) |
|---------------|--|
| Input Example | To manually configure a physical neighbor on a port, use the following: ENT-NBR:ons155xx:WDM-0-0:123:::DSCVRY=MANUAL,LINKDIRN=RX, NBRNAME=shelf2,NBRPORT=WDM-0-0, NBRAGENTIP=172.16.20.1; To discover a physical neighbor enabling CDP on a port, use the following: ENT-NBR:ons155xx:WDM-0-0:100:::DSCVRY=CDP, PRXYPORT=WAVE-0; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.30 ENT-NTPASSOC: Enter NTP Associations

Use this command to configure NTP associations for synchronizing system clocks over the network. Two types of associations can be created:

- Peer - The system synchronizes to a peer system and allows the peer to synchronize as well.
- Server - The system synchronizes to the server, but not the other way around.



Note

More than one association can be specified through multiple invocations of this command.

| Section | ENT-NTPASSOC Description |
|------------------|--|
| Category | NTP |
| Security | Provisioning |
| Related Messages | 3.11 DLT-NTPASSOC: Delete NTP Associations 3.68 RTRV-NTPASSOC: Retrieve NTP Associations |
| Input Format | ENT-NTPASSOC:[<tid>]::<ctag>:::ASSOCTYPE=<assoctype>, ASSOCIPADDR=<associpaddr>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <assoctype> indicates the type of association. Valid values are SERVER and PEER. • <associpaddr> specifies the IP address of the server or peer. |
| Input Example | To configure an NTP server association, use the following: ENT-NTPASSOC:ons155xx::123:::ASSOCTYPE=SERVER, ASSOCIPADDR=172.16.246.1; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.31 ENT-PATCH: Enter Patch

Use this command to configure patches between ports on the same network element.

| Section | ENT-PATCH Description |
|------------------|---|
| Category | Patch configuration |
| Security | Provisioning |
| Related Messages | 3.12 DLT-PATCH: Delete Patch 3.70 RTRV-PATCH: Retrieve Patch |
| Input Format | <p>ENT-PATCH:[<tid>]:<from_aid>,<to_aid>:<ctag>::[<ctype>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <from_aid> identifies the port you patched from to the port identified by <to_aid>. Valid values for <from_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – TENGIGETHERPHY-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <to_aid> identifies the port you patched from the port identified by <from_aid>. Valid values for <to_aid> are as follows: <ul style="list-style-type: none"> – FILTER-slot-subcard-0 – OSCFILTER-slot-subcard – TENGIGETHERPHY-slot-subcard – THRU-slot-subcard – WAVE-slot – WAVEPATCH-slot-subcard-port – WDM-slot-subcard • <ctag> is the correlation tag. • <ctype> is a position defined parameter and can be either 2WAY or 1WAY. When 1WAY is specified, then the patch is from the <from_aid> port to the <to_aid> port is either transmit or receive. 2WAY implies both transmit and receive patches between the two ports. The default is 2WAY. |
| Input Example | <p>To create a bidirectional patch between the wavepatch port in slot 2, subcard 0, port 0, and the filter port in slot 0, subcard 0, port 0, use the following:</p> <pre>ENT-PATCH:ons155xx:WAVEPATCH-2-0-0,FILTER-0-0-0:123::;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.32 ENT-THR-OCH: Enter Thresholds OCH

Use this command to set thresholds for errors that are being monitored on an interface. This command is used every time a new threshold is added to a threshold list.

| Section | ENT-THR-OCH Description |
|------------------|--|
| Category | Threshold list configuration |
| Security | Provisioning |
| Related Messages | 3.13 DLT-THR-OCH: Delete Threshold OCH 3.76 RTRV-THR-OCH: Retrieve Thresholds OCH 3.77 RTRV-TH-rr: Retrieve Threshold 3.84 SET-TH-rr: Set Optical Threshold |

| Section | ENT-THR-OCH Description (continued) |
|---------------|--|
| Input Format | <p data-bbox="537 260 1472 352">ENT-THR-OCH:[<tid>]:<THRLISTNAME>:<ctag>::ERRTYPE=<errtype>, THRTYPE=<thrtype>, VALUE=<value>, [TRGAPS=<trgaps>], [INDEX=<index>], [DESCR=<descr>];</p> <p data-bbox="537 373 625 403">Where:</p> <ul data-bbox="537 424 1472 1549" style="list-style-type: none"> <li data-bbox="537 424 901 453">• <tid> is the target identifier. <li data-bbox="537 464 1344 493">• <thrlistname> indicates the name of the threshold list being created. <li data-bbox="537 504 901 533">• <ctag> is the correlation tag. <li data-bbox="537 554 1430 613">• <errtype> indicates the type of error counter to which the threshold applies. Valid values are as follows: <ul data-bbox="597 634 1317 793" style="list-style-type: none"> <li data-bbox="597 634 1003 663">– CVS - SONET section CV errors <li data-bbox="597 674 1317 703">– CVRD - 8B/10B code violations and running disparity errors <li data-bbox="597 714 959 743">– CDLHEC - CDL HEC errors <li data-bbox="597 753 1081 783">– CRC - Cyclic Redundancy Check errors <li data-bbox="537 814 1472 1150">• <thrtype> indicates the threshold type. Valid values are as follows: <ul data-bbox="597 856 1472 1150" style="list-style-type: none"> <li data-bbox="597 856 1472 915">– DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. <li data-bbox="597 926 1451 984">– FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. <li data-bbox="597 995 1398 1054">– EVTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. <li data-bbox="597 1064 1451 1150">– ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type when <errtype> is not CVS. <li data-bbox="537 1161 1472 1220">• <value> specifies the threshold value as 10^{-x}, where <value> is x. The range is 3 to 9. <li data-bbox="537 1230 1472 1331">• <trgaps> is a trigger APS, such as protection switch on threshold exceeding. Valid values are Y or N. The default value is Y when ERRTYPE is CVS and is N for all other ERRTYPE values. <li data-bbox="537 1341 1472 1472">• <index> is an integer value used to uniquely identify a particular threshold within a list of thresholds. The range is 1 to 64. When no value is specified for this parameter, the index for the threshold being created defaults to the lowest available index in that threshold list. <li data-bbox="537 1482 1430 1549">• <descr> is a string used to assign a description to the threshold that is being configured. The maximum length of this string is 255 characters. |
| Input Example | <p data-bbox="537 1562 1472 1621">To configure the SONET section CV threshold and add it to the threshold list sonet-cvs, use the command:</p> <pre data-bbox="537 1642 1472 1705">ENT-THR-OCH:ons155xx:sonet-cvs:123::ERRTYPE=CVS,THRTYPE=DEGR,VALUE=7,INDEX=1;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.33 ENT-USER-SECU: Enter User Security

Use this command to create a user ID and set security parameters.

| Section | ENT-USER-SECU Description |
|------------------|---|
| Category | Security |
| Security | Retrieve |
| Related Messages | 3.1 ACT-USER: Activate User 3.4 CANC-USER: Cancel User 3.14 DLT-USER-SECU: Delete User Security 3.25 ED-USER-SECU: Edit User Security 13.79 RTRV-USER-SECU: Retrieve User Security |
| Input Format | ENT-USER-SECU:[<tid>]:<uid>:<ctag>::<pid>,,<uap>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier, a string value with a maximum size of 64 characters. • <ctag> is the correlation tag. • <pid> is the user login password, a string value with a maximum length of 25 characters. • <uap> is the user access privilege level. Valid values are as follows: <ul style="list-style-type: none"> – MAINT - Maintenance level – PROV - Provisioning level – RTRV - Retrieve level – SUPER - Superuser level |
| Input Example | To create a user ID and set security parameters, use the following: ENT-USER-SECU:ons155xx:admin:123::psword,,PROV; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.34 FORMAT-MEM: Format Memory

Use this command to permanently format a Flash PC device.

| Section | FORMAT-MEM Description |
|------------------|---|
| Category | Memory management |
| Security | Retrieve |
| Related Messages | 3.5 CPY-MEM: Copy Memory 13.47 RST-MEM: Restore Memory 3.62 RTRV-MEM: Retrieve Memory |

| Section | FORMAT-MEM Description (continued) |
|---------------|--|
| Input Format | FORMAT-MEM:[<tid>]:<aid>:<ctag>:::[CMDMODE=<mode>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device that is being formatted. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <mode> indicates the mode of operation. Valid values are FRCD and NORMAL. In FRCD mode, any files that may be present on the Flash PC device, are permanently erased as part of the format operation. If any files are present on the Flash PC device in NORMAL mode, the format request is denied. The default mode is NORMAL. |
| Input Example | To permanently format a Flash PC device, use the following: FORMAT-MEM:ons155xx:BOOTFLASH:123:::CMDMODE=FRCD; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.35 INH-MSG-ALL: Inhibit Message All

Use this command to disable autonomous messages from being transmitted.

| Section | INH-MSG-ALL Description |
|------------------|---|
| Category | Alarms and faults |
| Security | Retrieve |
| Related Messages | 3.2 ALW-MSG-ALL: Allow Message All |
| Input Format | INH-MSG-ALL:[<tid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |
| Input Example | To disable autonomous messages from being transmitted, use the following: INH-MSG-ALL:ons155xx::123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.36 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment

Use this command to inhibit automatic or manual switching from the active to the standby processor card. It also disables configuration syncs between the two processor cards. This command is usually used when performing software upgrades.

| Section | INH-SWDX-EQPT Description |
|------------------|---|
| Category | Redundancy configuration |
| Security | Maintenance |
| Related Messages | 3.3 ALW-SWDX-EQPT: Allow Switch Duplex Equipment 3.86 SW-DX-EQPT: Switch Duplex Equipment |
| Input Format | INH-SWDX-EQPT:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag. |
| Input Example | To inhibit automatic or manual switching from the active to the standby processor card, or disable configuration syncs between the two processor cards, use the following: INH-SWDX-EQPT:ons155xx:SLOT-6:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.37 INIT-REG-ETH: Initialize Register Ethernet

Use this command to clear the counters associated with a specific Ethernet AID.



Note

Issuing this command clears all counters.

| Section | INIT-REG-ETH Description |
|------------------|--|
| Category | IP configuration |
| Security | Retrieve |
| Related Messages | 3.18 ED-IP: Edit IP 3.59 RTRV-IP: Retrieve IP |
| Input Format | INIT-REG-ETH:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid > indicates the interface where counters are being cleared. Valid values are FE-0 and FE-SBY-0. • <ctag> is the correlation tag. |

| Section | INIT-REG-ETH Description (continued) |
|---------------|---|
| Input Example | To clear the counters associated with a specific Ethernet facility, use the following: INIT-REG-ETH:ons155xx:FE-0:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.38 INIT-REG-GBE10: Initialize Register 10-GE

Use this command to clear the counters associated with a specific 10-GE facility.



Note

Issuing this command clears all counters.

| Section | INIT-REG-GBE10 Description |
|------------------|--|
| Category | 10-GE interface configuration |
| Security | Maintenance |
| Related Messages | 3.57 RTRV-GBE10: Retrieve 10-GE Interfaces, page 3-58 |
| Input Format | INIT-REG-GBE10:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface on which counters are being cleared. Valid values are WAVEETHERPHY-slot-subcard and TENGIGETHERPHY-slot-subcard. • <ctag> is the correlation tag. |
| Input Example | To clear the counters associated with a waveetherphy port in slot 2, subcard 0, use the following: INIT-REG-GBE10:ons155xx:WAVEETHERPHY-2-0:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.39 INIT-REG-OCH: Initialize Register OCH

Use this command to clear the counters associated with a specific OCH facility.



Note

Issuing this command clears all counters.

| Section | INIT-REG-OCH Description |
|------------------|--|
| Category | Transparent interface configuration |
| Security | Maintenance |
| Related Messages | 3.69 RTRV-OCH: Retrieve Optical Channel, page 3-70 |

| Section | INIT-REG-OCH Description (continued) |
|---------------|---|
| Input Format | INIT-REG-OCH:[<tid>]:<aid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates interface on which counters are being cleared. Valid values are TRANSPARENT-slot-subcard-0 and WAVE-slot-subcard. • <ctag> is the correlation tag. |
| Input Example | To clear the counters associated with the transparent interface in slot 2, subcard 0, use the following: INIT-REG-OCH:ons155xx:TRANSPARENT-2-0-0:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.40 INIT-SYS: Initialize System

Use this command to initialize or reset a processor card on the system.

| Section | INIT-SYS Description |
|------------------|---|
| Category | Generic NE configuration |
| Security | Retrieve |
| Related Messages | 3.83 SET-SID: Set System Identification |
| Input Format | INIT-SYS:[<tid>]:<aid>:<ctag>;; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the card that needs to be reset. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag. |
| Input Example | To initialize or reset the processor card in slot 6, use the following: INIT-SYS:ons155xx:SLOT-6:123;;; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.41 OPR-LPBK-GBE10: Operate Loopback on the 10-GE

Use this command to operate a specific type of loopback on the port specified by the AID.

| Section | OPR-LPBK-GBE10 Description |
|------------------|--|
| Category | 10-GE interface configuration |
| Security | Maintenance |
| Related Messages | 3.44 RLS-LPBK-GBE10: Release Loopback on the 10-GE |

| Section | OPR-LPBK-GBE10 Description (continued) |
|---------------|---|
| Input Format | <p>OPR-LPBK-GBE10:[<tid>]:<aid>:<ctag>::,,,<lpbktype>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface on which the loopback is being created. Valid values are WAVEETHERPHY-slot-subcard and TENGIGETHERPHY-slot-subcard. • <lpbktype> indicates the type of loopback that is being created. Valid values are as follows: <ul style="list-style-type: none"> – FACILITY - The signal from the receive input is looped back to the transmit output. – TERMINAL - The signal bound for transmit output is looped back to the receive input. This is an internal loopback used for hardware debug and diagnostics. |
| Input Example | <p>To create a facility loopback on the waveetherphy interface in slot 2, subcard 0, use the following:</p> <p>OPR-LPBK-GBE10:ons155xx:WAVEETHERPHY-2-0:123::,,FACILITY;</p> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.42 OPR-LPBK-OCH: Operate Loopback OCH

Use this command to operate a specific type of loopback on the port specified by the AID.

| Section | OPR-LPBK-OCH Description |
|------------------|--|
| Category | Transparent interface configuration |
| Security | Maintenance |
| Related Messages | 3.45 RLS-LPBK-OCH: Release Loopback OCH |
| Input Format | <p>OPR-LPBK-OCH:[<tid>]:<aid>:<ctag>::,,,<lpbktype>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface on which the loopback is being created. Valid values are TRANSPARENT-slot-subcard-0 and WAVE-slot-subcard. • <ctag> is the correlation tag. • <lpbktype> indicates the type of loopback that is being created. Valid values are as follows: <ul style="list-style-type: none"> – FACILITY - The signal from the receive input is looped back to the transmit output. – TERMINAL - The signal bound for the transmit output is looped back to the receive input. This is an internal loopback used for hardware debug and diagnostics. |

| Section | OPR-LPBK-OCH Description (continued) |
|---------------|---|
| Input Example | To create a facility loopback on the transparent interface in slot 2, subcard 0, use the following: OPR-LPBK-OCH:ons155xx:TRANSPARENT-2-0-0:123::,,FACILITY; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.43 OPR-PROTNSW-OCH: Operate Protection Switch OCH

Use this command to enable the NE to perform a protection switch or a lockout.

| Section | OPR-PROTNSW-OCH Description |
|------------------|--|
| Category | APS |
| Security | Maintenance |
| Related Messages | 3.46 RLS-PROTNSW-OCH: Release Protection Switch OCH |
| Input Format | OPR-PROTNSW-OCH:[<tid>]:<aid>:<ctag>:<sc> Where: <ul style="list-style-type: none"> • <aid> is the working or protection port AID to which a switch request is directed. Valid values are TRANSPARENT-slot-subcard-0, WAVEPATCH-slot-subcard-port, or TENGIGETHERPHY-slot-subcard. If the AID identifies the working line, then service is switched from working to protection. If the AID identifies the protection line, then service is switched back to the working line. • <sc> is the switch command. Valid values are as follows: <ul style="list-style-type: none"> – MAN - Switch from working or back to working is done based on the AID specified unless a request of equal or higher priority is in effect. – FRCD - Switch from working or back to working is done based on the AID specified unless a request of equal or higher priority is in effect. – LOCKOUT - Lockout all switchovers to the protection facility. If the protection facility is currently active, then the lockout request is denied. <p>The lockout request has the highest priority and takes effect regardless of signal condition. The forced switch command is the next highest priority.</p> <p>The manual switchover request has the lowest priority and only completes if there is no protection path lockout or forced switchover is in effect, or the signal has failed or degraded.</p> |
| Input Example | To enable the NE to perform a protection switch or a lockout, use the following: OPR-PROTNSW-OCH:ons155xx:WAVEPATCH-2-0-1:123::FRCD; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.44 RLS-LPBK-GBE10: Release Loopback on the 10-GE

Use this command to release a specific type of loopback on the port specified by the AID.

| Section | RLS-LPBK-GBE10 Description |
|------------------|---|
| Category | 10-GE interface configuration |
| Security | Maintenance |
| Related Messages | 3.57 RTRV-GBE10: Retrieve 10-GE Interfaces |
| Input Format | <p>RLS-LPBK-GBE10:[<tid>]:<aid>:<ctag>::,,,<lpbktype>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface on which the loopback is being released. Valid values are WAVEETHERPHY-slot-subcard and TENGIGETHERPHY-slot-subcard. • <ctag> is the correlation tag. • <lpbktype> indicates the type of loopback that is being released. Valid values are as follows: <ul style="list-style-type: none"> – FACILITY - The signal from the receive input loops back to the transmit output. – TERMINAL - The signal to the transmit output loops back to the receive input. This is an internal loopback used for hardware debugging and diagnostics |
| Input Example | <p>To release a facility loopback on the waveetherphy interface in slot 2, subcard0, use the following:</p> <pre>RLS-LPBK-GBE10:ons155xx:WAVEETHERPHY-2-0:123::,,FACILITY;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.45 RLS-LPBK-OCH: Release Loopback OCH

Use this command to release a specific type of loopback on the port specified by the AID.

| Section | RLS-LPBK-OCH Description |
|------------------|---|
| Category | Transparent interface configuration |
| Security | Maintenance |
| Related Messages | 3.42 OPR-LPBK-OCH: Operate Loopback OCH |

| Section | RLS-LPBK-OCH Description (continued) |
|---------------|---|
| Input Format | RLS-LPBK-OCH:[<tid>]:<aid>:<ctag>::,,,<lpbktype>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the interface on which the loopback is being released. Valid values are TRANSPARENT-slot-subcard-0 and WAVE-slot-subcard. • <ctag> is the correlation tag. • <lpbktype> indicates the type of loopback that is being released. FACILITY is the valid value, where the signal from the receive input is looped back to the transmit output. |
| Input Example | To release a facility loopback on the transparent interface in slot 2, subcard 0, use RLS-LPBK-OCH:ons155xx:TRANSPARENT-2-0-0:123::,,FACILITY; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.46 RLS-PROTNSW-OCH: Release Protection Switch OCH

Use this command to clear the previous switchover request.



Note

A lockout or a forced or manual switchover request stays in effect until the system reboots.

| Section | RLS-PROTNSW-OCH Description |
|------------------|---|
| Category | APS |
| Security | Maintenance |
| Related Messages | 3.43 OPR-PROTNSW-OCH: Operate Protection Switch OCH |
| Input Format | RLS-PROTNSW-OCH:[<tid>]:<aid>:<ctag>::; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the port AID to which the switch request is directed. Valid values are TRANSPARENT-slot-subcard-0, WAVEPATCH-slot-subcard-port, or TENGIGETHERPHY-slot-subcard. |
| Input Example | To clear the previous request, use the following: RLS-PROTNSW-OCH:ons155xx:WAVEPATCH-2-0-1:123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.47 RST-MEM: Restore Memory

Use this command to recover a file that was previously deleted, but not erased, using the DLT-MEM command.

**Note**

A deleted file cannot be recovered if a valid one with the same name exists. The existing file needs to be deleted before the already deleted one can be recovered. If two files with the same name were deleted, the index is used to uniquely identify the file to be recovered.

| Section | RST-MEM Description |
|------------------|--|
| Category | Memory Management |
| Security | Retrieve |
| Related Messages | 3.5 CPY-MEM: Copy Memory 3.34 FORMAT-MEM: Format Memory 3.62 RTRV-MEM: Retrieve Memory |
| Input Format | RST-MEM:[<tid>]:<aid>:<ctag>:::INDEX=<index>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is being recovered. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <index> specifies the index number associated with the deleted file. This is an integer value and can be obtained by using the RTRV-MEM command. |
| Input Example | To recover a file that was previously deleted, but not erased, using the DLT-MEM command, use the following: RST-MEM:ons155xx:BOOTFLASH:123::INDEX=4; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.48 RST-NE-CDP: Restore Global CDP Attributes

Use this command to restore all global CDP attribute settings to their default values.

| Section | RST-NE-CDP Description |
|------------------|--|
| Category | CDP |
| Security | Maintenance |
| Related Messages | 3.19 ED-NE-CDP: Edit Network Element CDP 3.64 RTRV-NE-CDP: Retrieve Network Element CDP |
| Input Format | RST-NE-CDP:[<tid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |

| Section | RST-NE-CDP Description (continued) |
|---------------|---|
| Input Example | To restore all global CDP attribute settings to their default values, use the following: RST-NE-CDP:ons155xx::123; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.49 RTRV-ALM-ALL: Retrieve Alarms All

Use this command to retrieve alarms for a given facility, card, or module.



Note

Only alarms with severities critical, major, or minor can be retrieved using this command.

| Section | RTRV-ALM-ALL Description |
|------------------|---|
| Category | Alarms and faults |
| Security | Retrieve |
| Related Messages | 3.2 ALW-MSG-ALL: Allow Message All |
| Input Format | RTRV-ALM-ALL:[<tid>]:[<aid>]:<ctag>::[<ntfncde>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are SLOT-slot and SLOT-slot-subcard. • <ctag> is the correlation tag. • <ntfncde> indicates the type of notification generated on the NE when a threshold is exceeded or cleared. Valid values are CR, MJ, or MN. |
| Input Example | To retrieve alarms for the module in slot 2, subcard 0, use the following: RTRV-ALM-ALL:ons155xx:SLOT-2-0:123::MJ; To retrieve alarms for the client port in slot 2, subcard 0, use the following: RTRV-ALM-ALL:ons155xx:TRANSPARENT-2-0-0:123::MJ; |
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>:<severity>,<alarm>,SA,,,,,\\"<text>\\" ; |

| Section | RTRV-ALM-ALL Description (continued) |
|----------------|---|
| Output Example | <p>The output if no alarm condition exists:</p> <pre>SID DATE TIME M 123 COMPLD ;</pre> <p>The output if a matching alarm condition exists:</p> <pre>SID DATE TIME M 123 COMPLD "TRANSPARENT-2-0-0:MJ,LOF,SA,,,,,\\"Loss Of Frame\\"" ;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.50 RTRV-ALM-ENV: Retrieve Alarms Environmental

Use this command to retrieve environmental alarms on the system.

| Section | RTRV-ALM-ENV Description |
|------------------|--|
| Category | Alarms and faults |
| Security | Retrieve |
| Related Messages | 3.49 RTRV-ALM-ALL: Retrieve Alarms All, page 3-45 |
| Input Format | <p>RTRV-ALM-ENV:[<tid>]:[<aid>]:<ctag>::[<ntfcncde>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. • <ctag> is the correlation tag. • <ntfcncde> indicates the type of notification generated on the NE when a threshold is exceeded or cleared. Valid values are CR, MJ, or MN. |
| Input Example | <p>To retrieve major environmental alarms, use the following:</p> <pre>RTRV-ALM-ENV:ons155xx::123::MJ;</pre> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD ":<severity>,<alarm>,,,\\"<text>\\"" ;</pre> |
| Output Example | <p>The output if a matching alarm condition exists:</p> <pre>SID DATE TIME M 123 COMPLD "Chassis:MJ,HITEMP,,,\\"Chassis temperature too high\\"" ;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.51 RTRV-ATTR-rr: Retrieve Attributes

Use this command to retrieve the severity levels assigned to the threshold values configured on the wavepatch and waveetherphy interfaces interfaces.

| Section | RTRV-ATTR-rr Description |
|------------------|--|
| Category | Alarms and faults |
| Security | Retrieve |
| Related Messages | 3.48 RST-NE-CDP: Restore Global CDP Attributes 3.80 SET-ATTR-rr: Set Attributes |
| Input Format | <p>RTRV-ATTR-rr [<tid>]:[<aid>]:<ctag>::[<ntfcncde>],[<condtype>],[<dirn>];</p> <p>Where:</p> <ul style="list-style-type: none"> • rr is OCH. • <tid> is the target identifier. • <aid> indicates wavepatch and waveetherphy interfaces on which the threshold is to be set. Valid values are WAVEPATCH-slot-subcard-port or WAVEETHERPHY-slot-subcard. • <ctag> is the correlation tag. • <ntfcncde> indicates the type of notification generated on the NE when a threshold is exceeded or cleared. Valid values are CR, MJ, or MN. • <condtype> is the monitored condition type. Valid values are as follows: <ul style="list-style-type: none"> – OPRHA - Receive optical power level corresponding to the high alarm threshold. If the optical power level is greater than the threshold associated with this parameter, an alarm is generated. – OPRLA - Receive optical power level corresponding to the low alarm threshold. If the optical power level is less than the threshold associated with this parameter, an alarm is generated. – OPRHW - Receive optical power level corresponding to the high warning threshold. If the optical power level is greater than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. – OPRLW - Receive optical power level corresponding to the low warning threshold. If the optical power level is less than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. • <dirn> is the direction associated with the information. Valid values are RCV or TRMT. The default is both directions. |
| Input Example | <p>To retrieve the severity levels assigned to the threshold values configured on wavepatch interfaces on the transponder cards, use the following:</p> <pre>RTRV-ATTR-OCH:ons155xx:WAVEPATCH-8-0-0:123::,OPRHA;</pre> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<aid>:<severity>,<condtype>,<dirn>" ;</pre> |

| Section | RTRV-ATTR-rr Description (continued) |
|----------------|---|
| Output Example | The output for wavepatch interfaces: <pre>SID DATE TIME M 123 COMPLD "WAVEPATCH-8-0-0:MJ,OPRHA,,RCV" ;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.52 RTRV-CDPNBR-OCH: Retrieve CDP Neighbor OCH

Use this command to retrieve neighbor information discovered by CDP on a specific port in the NE or on all ports of the NE.

| Section | RTRV-CDPNBR-OCH Description |
|------------------|--|
| Category | CDP |
| Security | Retrieve |
| Related Messages | 3.10 DLT-NBR: Delete Neighbor 3.29 ENT-NBR: Enter Neighbor 3.63 RTRV-NBR: Retrieve Neighbor |
| Input Format | RTRV-CDPNBR-OCH:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> specifies the port AID to retrieve information for the neighbor on that port only. NULL retrieves information on all neighbors. • <ctag> is the correlation tag. |
| Input Example | To retrieve neighbor information discovered by CDP on a specific port in the NE or on all ports of the NE, use the following: RTRV-CDPNBR-OCH:ons155xx::123; |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<aid>:NBRNAME=<nbrname>,NBRPORT=<nbrport>, CAPABILITY=<capability>,TTL=<ttl>" ;</pre> |

| Section | RTRV-CDPNBR-OCH Description (continued) |
|----------------|---|
| Output Example | <p>SID DATE TIME M 123 COMPLD "WAVE-1-0:NBRNAME=Switch2,NBRPORT=PORT-0,CAPABILITY=S, TTL=158" ; Where:</p> <ul style="list-style-type: none"> • <NBRNAME> shows the name of the neighboring device, typically, the SID of that device. The maximum size is 255 characters. • <NBRPORT> is the name of the neighboring port. Typically, the AID of that port. • <CAPABILITY> indicates the capability of the neighboring device. It is a string formed by the concatenation of one or more of the following values: <ul style="list-style-type: none"> - R - Router, - T - Trans bridge - B - Source route bridge - S - Switch - H - Host - I - IGMP - r - Repeater • <TTL> Time To Live value. This is the amount of time in seconds before this neighbor information is discarded unless the NE receives another packet on this port with the same information. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.53 RTRV-COND-ALL: Retrieve Condition All

Use this command to retrieve current standing conditions associated with specified equipment or facility. This command retrieves conditions with all severities.

| Section | RTRV-COND-ALL Description |
|------------------|--|
| Category | Alarms and faults |
| Security | Retrieve |
| Related Messages | 3.49 RTRV-ALM-ALL: Retrieve Alarms All 3.50 RTRV-ALM-ENV: Retrieve Alarms Environmental |
| Input Format | RTRV-COND-ALL:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. • <ctag> is the correlation tag. |
| Input Example | To retrieve current standing conditions associated with specified equipment or facility, use the following: RTRV-COND-ALL:ons155xx:TRANSPARENT-8-0-0:123;; |
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>,<encap>:<severity>,<condtype>,NSA,,,,\"<text>\\"" ; |
| Output Example | The output for conditions on the transparent interface: SID DATE TIME M 123 COMPLD "TRANSPARENT-8-0-0,OC3:MN,CVS,NSA, ,,,\"Code Violation- Section - Exceed Degrade\"" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.54 RTRV-EQPT: Retrieve Equipment

Use this command to retrieve the redundancy configurations. It also retrieves inventory information for the specified module.

The PST and SST values in the last position defined block also indicate the redundancy states, when the AID specified in this command is SLOT-6 or SLOT-7. The values of PST-PSTQ and SST are reported under different operating conditions.

Active processor card states are as follows:

- For normal active, PST=IS-NR.
- For active processor card in fault state, PST=IS-ANR, SST=FLT,ACT.

Standby processor card states are as follows:

- If standby peer has hardware state missing, PST=OOS-AU, SST=UEQ.

- If standby peer has hardware state non-participant, PST=OOS-AU, SST=AINS.
- If standby peer has hardware state of standby, PST=IS-ANR, SST=STBYC.
- If standby is in fault state, PST=IS-ANR, SST=FLT, STBYC or STBYH (depending on software redundancy state.)
- If the standby is normal and in hot standby state, PST=IS-NR, SST=STBYH.

Under maintenance mode (when an INH-SWDX command has been issued for a standby processor card):

- If hardware state is missing, PST=OOS-AUMA, SST=UEQ,STBYI.
- If hardware state is non-participant and software redundancy state is disabled, PST=OOS-AURST, SST=AINS,STBYI.

For all other software redundancy states such as unknown, negotiating, or standby cold, PST=IS-RST, SST=STBYI.

In addition to these values, two SST values indicate the synchronization status on the running and startup configurations.

- NRCSYNC - Running config is not in sync
- NSCSYNC - Startup config is not in sync

| Section | RTRV-EQPT Description |
|------------------|---|
| Category | Redundancy configuration |
| Security | Retrieve |
| Related Messages | 3.36 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment 3.86 SW-DX-EQPT: Switch Duplex Equipment |
| Input Format | RTRV-EQPT:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The value is SLOT-slot. The default is all AIDs. • <ctag> is the correlation tag. |
| Input Example | To retrieve inventory information for the CPU switch module in slot 6, use the following: RTRV-EQPT:ons155xx:SLOT-6:123; To retrieve inventory information for modules in card in slot 8, use the following: RTRV-EQPT:ons155xx:SLOT-8:123; |

| Section | RTRV-EQPT Description (continued) |
|---------------|--|
| Output Format | <p data-bbox="537 260 927 291">Output format for processor cards:</p> <pre data-bbox="537 310 1349 499"> SID DATE TIME M CTAG COMPLD "<aid>:<clei>:PN=<pn>,SN=<sn>,OPN=<opn>,HWVER=<hwver>, SWVER=<swver>,FWVER=<fwver>,BOOTLDR=<bootldr>, ROMMONVER=<rommonver>,HWREDSTATE=<hwredstate>, SWREDSTATE=<swredstate>,,:<pst>,<sst>,<sst>"; </pre> <p data-bbox="537 514 1094 546">Output format for 2.5-Gbps transponder modules:</p> <pre data-bbox="537 562 1357 751"> SID DATE TIME M CTAG COMPLD "<aid>:<clei>:PN=<pn>,SN=<sn>,OPN=<opn>,HWVER=<hwver>,, FSWVER=<fwver>,,,,LASERFREQLOW=<laserfreqlow>, LASERFREQHIGH=<laserfreqhigh>:<pst>,<sst>,<sst>" ; </pre> <p data-bbox="537 766 1058 798">Output format for 10-GE transponder modules:</p> <pre data-bbox="537 814 1365 961"> SID DATE TIME M CTAG COMPLD "<aid>:<clei>:PN=<pn>,SN=<sn>,OPN=<opn>,HWVER=<hwver>,, FSWVER=<fwver>,,,,LASERFREQ=<laserfreq>:<pst>,<sst>,<sst>" ; </pre> |

| Section | RTRV-EQPT Description (continued) |
|----------------|--|
| Output Example | <pre data-bbox="576 262 1518 514"> SID DATE TIME M 123 COMPLD "SLOT-5:CLIE:PN=73-5656-03,SN=CAB0516HK2,OPN=N/A, HWVER=2.0,SWVER=12.1,FWVER=1.24, BOOTLDR=12.1(7a)EY2,ROMMONVER=12.1(7r)EY, HWREDSTATE=ACT,SWREDSTATE=ACT :IS-NR,NRCSYNC,NSCSYNC" ; </pre> <p data-bbox="576 535 657 556">Where:</p> <ul data-bbox="576 577 1518 1795" style="list-style-type: none"> • PN is a string that shows part number, maximum length is 32 characters. • SN is a string that shows serial number, maximum length is 32 characters. • OPN is a string that shows the orderable product number, maximum length is 32 characters. • HWVER is a string that shows the hardware version number, maximum length is 32 characters. • SWVER is a string that shows the image version running on this processor card, maximum length is 32 characters • FWVER is a string that shows functional software image version running on this module, maximum length is 32 characters. • BOOTLDR is a string that shows the bootloader image version, maximum length is 32 characters. This parameter is applicable to processor card only. • ROMMONVER is a string that shows the ROMMON version and has a maximum length of 32 characters. This parameter is applicable to processor cards only. • SWREDSTATE shows software redundancy state. This parameter is applicable to processor cards only. Valid values are as follows: <ul data-bbox="625 1239 1015 1795" style="list-style-type: none"> - NK - Not known - DSBL - Disabled - INIT - Initialization - SBYC - StandbyCold - SBYCC - StandbyColdConfig - SBYCF - StandbyColdFileSys - SBYCB - StandbyColdBulk - SBYH - StandbyHot - ACTF - ActiveFast - ACTD - ActiveDrain - ACTPR - ActivePreConfig - ACTPS - ActivePostConfig - ACT - Active |


| Section | RTRV-EQPT Description (continued) |
|----------------------------|--|
| Output Example (continued) | <ul style="list-style-type: none"> • HWREDSTATE shows the hardware redundancy state. This parameter is applicable to processor cards only. Valid values are as follows: <ul style="list-style-type: none"> – NP - Nonparticipant – ACT - Active – SBY - Standby – MISS - Missing – ERR - Errored <p>To retrieve inventory information for a 2.5-Gbps transponder module in slot 8:</p> <pre>SID DATE TIME M 123 COMPLD " SLOT-8:CLEI:PN=73-5656-03,SN=CAB0516HK2,OPN=N/A,HWVER=2.0, SWVER=12.1,FWVER=1.89,LASERFREQLOW=194500, LASERFREQHIGH=198500:IS-NR,," ;</pre> <p>Where:</p> <ul style="list-style-type: none"> • LASERFREQLOW indicates the lower ITU grid laser frequency that this card is capable of generating. This parameter applies only to transponder cards that are capable of generating one or more laser frequencies. • LASERFREQHIGH indicates the higher ITU grid laser frequency that this card is capable of generating. This parameter applies only to transponder cards that are capable of generating one or more laser frequencies. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.55 RTRV-FFP-OCH: Retrieve Facility Protection OCH

Use this command to retrieve optical facility protection information.

| Section | RTRV-FFP-OCH Description |
|------------------|---|
| Category | APS |
| Security | Retrieve |
| Related Messages | 3.6 DLT-FFP-OCH: Delete Facility Protection OCH 3.16 ED-FFP-OCH: Edit Facility Protection 3.26 ENT-FFP-OCH: Enter Optical Protection, page 3-26 |

| Section | RTRV-FFP-OCH Description (continued) |
|---------------|---|
| Input Format | <p>RTRV-FFP-OCH:[<tid>]:[<wkg_aid>],[<prot_aid>]:<ctag>:::[PROTID=<protid>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <wkg_aid> is the working access identifier. Valid values are WAVEPATCH-slot-subcard-port, TRANSPARENT-slot-subcard-0, TENGIGETHERPHY-slot-subcard, or WDMSPPLIT-slot-subcard-port. • <prot_aid> is the protection access identifier. Valid values are WAVEPATCH-slot-subcard-port, TRANSPARENT-slot-subcard-0, TENGIGETHERPHY-slot-subcard, or WDMSPPLIT-slot-subcard-port. • <ctag> is the correlation tag. • <protid> is the protection group identifier. It is a case-sensitive string and can have a maximum of 32 characters. |
| Input Example | <p>To retrieve optical facility protection information, use the following:</p> <pre>RTRV-FFP-OCH:ons155xx:WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:123;</pre> |
| Output Format | <pre> SID DATE TIME M CTAG COMPLD "<wkg_aid>,<prot_aid>:ACTIVE=<active>,STANDBY=<standby>, PROTID=<protid>, PSDIRN=<psdirn>,RVRTV=<rvrtv>,RVRTM=<rvrtm>, ENSWOTM=<enswotm>,SRCHUPMIN=<srchupmin>, SRCHUPMAX=<srchupmax>,FENDDIRN=<fenddirn>,MSGCH=<msgch>, MSGCHCUR=<msgchcur>,MSGHOLDTM=<msgholdtm>, MSGCHST=<msgchst>,MSGHOLDCOUNT=<msgholdcount>, MSGMAXTM=<msgmaxtm>:<pst>" ; </pre> |

| Section | RTRV-FFP-OCH Description (continued) |
|----------------|---|
| Output Example | <pre>SID DATE TIME M 123 COMPLD "WAVEPATCH-2-0-0,WAVEPATCH-2-0-1:ACTIVE=WAVEPATCH-2-0-0, STANDBY=WAVEPATCH-2-0-1,PROTID=switch1-aps,PSDIRN=BI, RVRTV=Y,RVRTM=300,ENSWOTM=10,SRCHUPMIN=2, SRCHUPMAX=32,FENDDIRN=UNI,MSGCH=AUTO,MSGCHCUR=DCC, MSGHOLDTM=1500,MSGCHST=IS,MSGHOLDCOUNT=2, MSGMAXTM=15:IS" ;</pre> <p>Where:</p> <ul style="list-style-type: none"> • ACTIVE indicates the AID of the currently active interface. • STANDBY indicates the AID of the interface in standby. • FENDDIRN indicates the switching mode of the remote facility. Valid values are as follows: <ul style="list-style-type: none"> - UNI - Unidirectional - BI - Bidirectional - UNKNOWN - Unknown <p> Note If switching mode of this (near end) facility, that is PSDIRN is configured as UNI, then its active switching mode will always be UNI. If PSDIRN is configured as BI, then the active switching mode is BI only if the FENDDIRN is BI. If FENDDIRN is UNI, then the active switching mode becomes UNI.</p> <ul style="list-style-type: none"> • MSGCHCUR indicates the currently used message channel. This parameter applies only when MSGCH is set to AUTO. • MSGCHST indicates if the message channel is up or down. Valid values are as follows: <ul style="list-style-type: none"> - IS - in service - OOS - out-of-service |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.56 RTRV-FILE: Retrieve File

Use this command to retrieve the contents of the configuration files.

| Section | RTRV-FILE Description |
|------------------|---|
| Category | Memory Management |
| Security | Retrieve |
| Related Messages | 3.61 RTRV-LOG: Retrieve Log 3.80 SET-ATTR-rr: Set Attributes |

| Section | RTRV-FILE Description (continued) |
|---------------|--|
| Input Format | <p>RTRV-FILE:[<tid>]:<aid>:<ctag>::FILENAME=<filename>,[LINES=<lines>],[OFFSET=<offset>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is to be retrieved. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], NVRAM, SBY-NVRAM, SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <filename> is a string that shows the name of the configuration file whose contents are to be retrieved. The maximum string length is 255 characters. • <lines> is an optional parameter. It is an integer value that indicates the number of lines to retrieve at a time. If this parameter is not configured, the entire file is retrieved as is. • <offset> is an optional parameter. It is an integer value that indicates the offset within a file. The contents of the file starting at this offset is retrieved. The default value is zero, which means that the contents from the beginning of the file are retrieved. |
| Input Example | <p>To retrieve the contents of the configuration files, use the following:</p> <pre>RTRV-FILE:ons155xx::123::FILENAME=running-config,LINES=24;</pre> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<text>" ;</pre> |

| Section | RTRV-FILE Description (continued) |
|----------------|---|
| Output Example | <pre> SID DATE TIME M 123 COMPLD "version 12.1 no service pad service timestamps debug uptime service timestamps log uptime no service password-encryption service internal service compress-config ! hostname snmp-man ! boot system bootflash:ons15540-i-mz.tirth redundancy keepalive-threshold 12 associate group bb associate group aa aps working Transparent8/0/0 aps protection Transparent8/1/0 aps y-cable aps enable aps timer switchover min-interval 20 enable password lab ! ! threshold-list abc" ; </pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.57 RTRV-GBE10: Retrieve 10-GE Interfaces

Use this command to retrieve the CDL related information for the given interface.

The PST and SST values in the last position defined block indicate the current status of the interface. The values of PST-PSTQ and SST, under different conditions, are listed as follows:

- If the interface is administratively shut down by using the ENT-GBE10 command, values returned is PST=OOS-MA, SST=MT.
- If the interface is administratively shut down and the laser is shut as well, values returned are PST=OOS-MA, SST=LASERSHUT.
- If the interface is down because of alarms on the link, such as Loss of Signal, Loss of Frame, or Loss of Light, values returned are PST=OOS-AU and SST=FAF.
- If the interface is down because of Loss of Signal or Loss of Light, and safety protocols such as LSC, FLC, or OFC are enabled on the interface, causing the transmit laser to shut down, values returned are PST=OOS-AU and SST=LASERSHUT.
- If the interface is down because of alarms and is also administratively shut down, values returned are PST=OOS-AUMA, SST=FAF, MT.

- If there is an entity failure on the NE because the interface is down, values returned are PST=OOS-AU, SST= SGEO.
- If the transmit laser fails at an interface, values returned are PST=OOS-AU, SST=FLT, LASERFAIL.
- If only thresholds are being exceeded on the interface, values returned are PST=IS-ANR.
- Under normal operating conditions, values returned are PST=IS-NR.

| Section | RTRV-GBE10 Description |
|------------------|---|
| Category | 10-GE interface configuration |
| Security | Retrieve |
| Related Messages | 3.17 ED-GBE10: Edit 10-GE 3.38 INIT-REG-GBE10: Initialize Register 10-GE 3.41 OPR-LPBK-GBE10: Operate Loopback on the 10-GE 3.44 RLS-LPBK-GBE10: Release Loopback on the 10-GE |
| Input Format | RTRV-GBE10:[<tid>]:[<aid>]:<ctag>; where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the interfaces and can be one of the following: <ul style="list-style-type: none"> - WAVEETHERPHY-slot-subcard - WAVEPATCH-slot-subcard-port - TENGIGETHERPHY-slot-subcard • <ctag> is the correlation tag. |
| Input Example | To retrieve the CDL information from the waveetherphy interface in slot 9, subcard 0, use the following: RTRV-GBE10:ons155xx:WAVEETHERPHY-9-0:123; |
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>:THRLISTNAME=<thrlistname>,FRCENDHOP=<frcendhop>, NODEBEHAVIOUR=<nodebehaviour>,LPBKTYPE=<lpbktype>:<pst>" ; |

| Section | RTRV-GBE10 Description (continued) |
|----------------|--|
| Output Example | SID DATE TIME M 123 COMPLD "WAVEETHERPHY-9-0:THRLISTNAME=cdl_thresh,FRCENDHOP=N, NODEBEHAVIOUR=ENDOFFPATH, LPBKTYPE=FACILITY:IS-NR" ; Where: <ul style="list-style-type: none"> • <NODEBEHAVIOUR> indicates whether the interface is end-of-path or end-of-hop. Any OAM information associated with a path or hop is terminated on this interface. • <LPBKTYPE> indicates the type of loopback on the interface. Valid values are as follows: <ul style="list-style-type: none"> – FACILITY - where the signal from the receive input is looped back to the transmit output – TERMINAL - where the signal bound for transmit output is looped back to the receive input. This is an internal loopback and it is used for hardware debug and diagnostics. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.58 RTRV-HDR: Retrieve Header

Use this command to request that an NE simply reply with a normal response indicating COMPLD.

The information of interest in the reply is the reply itself, along with information that the NE has about itself, specifically <source_identifier>, <date>, and <time>.

| Section | RTRV-HDR Description |
|------------------|---|
| Category | Generic NE configuration |
| Security | Retrieve |
| Related Messages | 3.15 ED-DAT: Edit Date, page 3-11 3.78 RTRV-TOD: Retrieve Time of Day, page 3-83 |
| Input Format | RTRV-HDR:[<tid>]::<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |
| Output Format | SID DATE TIME M CTAG COMPLD ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.59 RTRV-IP: Retrieve IP

Use this command to retrieve IP configurations.

| Section | RTRV-IP Description |
|------------------|---|
| Category | IP configuration |
| Security | Retrieve |
| Related Messages | 3.7 DLT-IP: Delete IP 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.18 ED-IP: Edit IP 3.27 ENT-IP: Enter IP 3.60 RTRV-IPROUTE: Retrieve IP Route |
| Input Format | RTRV-IP:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. • <ctag> is the correlation tag. |
| Input Example | To retrieve IP configurations, use the following: RTRV-IP:ons155xx:FE-0:123; |
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>:IPADDRTYPE=<ipaddrtype>,IPADDR=<ipaddr>, IPMASK=<ipmask>" ; |
| Output Example | SID DATE TIME M 123 COMPLD "FE-0:IPADDRTYPE=ADDR,IPADDR=172.16.42.110, IPMASK=255.255.255.0" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.60 RTRV-IPROUTE: Retrieve IP Route

Use this command to retrieve IP routing information.

| Section | RTRV-IPROUTE Description |
|------------------|--|
| Category | IP configuration |
| Security | Retrieve |
| Related Messages | 3.8 DLT-IPROUTE-STATIC: Delete IP Route Static 3.18 ED-IP: Edit IP 3.27 ENT-IP: Enter IP |

| Section | RTRV-IPROUTE Description (continued) |
|----------------|---|
| Input Format | RTRV-IPROUTE:[<tid>]::<ctag>:::ROUTETYPE=<roustetype>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <roustetype> indicates if the route is a static route or is learned dynamically from a routing protocol. Valid values are STATIC and DYNAMIC. The only value currently supported is STATIC. |
| Input Example | To retrieve IP routing information, use the following: RTRV-IPROUTE:ons155xx::123:::ROUTETYPE=STATIC; |
| Output Format | SID DATE TIME M CTAG COMPLD "ROUTETYPE=<roustetype>,PREFIXADDR=<prefixaddr>, PREFIXMASK=<prefixmask>,ROUTEIF=<routeif>" ; |
| Output Example | SID DATE TIME M 123 COMPLD "ROUTETYPE=STATIC,PREFIXADDR=10.1.0.0, PREFIXMASK=255.255.0.0, ROUTEIF=WAVE-0-0" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.61 RTRV-LOG: Retrieve Log

Use this command to retrieve the console buffer log on the NE.

| Section | RTRV-LOG Description |
|------------------|--|
| Category | Alarms and faults |
| Security | Retrieve |
| Related Messages | 3.2 ALW-MSG-ALL: Allow Message All, page 3-2 3.3 ALW-SWDX-EQPT: Allow Switch Duplex Equipment, page 3-2 3.35 INH-MSG-ALL: Inhibit Message All, page 3-36 3.36 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment, page 3-37 3.49 RTRV-ALM-ALL: Retrieve Alarms All, page 3-45 3.50 RTRV-ALM-ENV: Retrieve Alarms Environmental, page 3-46 |
| Input Format | RTRV-LOG:[<tid>]::<ctag>:::[<lognm>]; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <lognm> specifies the name of the log to be retrieved. Only the value SYSLOG is currently supported. The default is SYSLOG. |

| Section | RTRV-LOG Description (continued) |
|----------------|--|
| Input Example | To retrieve the console buffer log on the NE, use the following: RTRV-LOG:ons155xx::123::; |
| Output Format | SID DATE TIME M CTAG COMPLD "<text>" ; /* RTRV-LOG */ |
| Output Example | SID DATE TIME M 123 COMPLD "SYSLOG::00:00:23: %LINK-3-UPDOWN: Interface Transparent7/0/0, changed state to down" "SYSLOG::00:00:24: %LINEPROTO-5-UPDOWN: Line protocol on Interface Transparent7/0/0, changed state to down" "SYSLOG::00:00:38: %LCMDC-3-MIB_ICDRLK_ALM: Ingress CDR Locking error CLEAR MAJOR Tran7/0/0" ; /* RTRV-LOG */ |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.62 RTRV-MEM: Retrieve Memory

Use this command to retrieve information on all the files that are present on the Flash device.

| Section | RTRV-MEM Description |
|------------------|--|
| Category | Memory Management |
| Security | Retrieve |
| Related Messages | 3.9 DLT-MEM: Delete Memory 3.5 CPY-MEM: Copy Memory 3.47 RST-MEM: Restore Memory 3.85 SQUEEZE-MEM: Squeeze Memory |

| Section | RTRV-MEM Description (continued) |
|----------------|--|
| Input Format | <p>RTRV-MEM:[<tid>]:[<aid>]:<ctag>:::[FILENAME=<file>],[STATUS=<status>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device from which the file is being retrieved. Valid values are BOOTFLASH, DISK-[0-1], PCMCIA-[0-1], NVRAM, SBY-NVRAM, SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. • <file> specifies a filename. This is a string with a maximum of 255 characters. • <status> filters the files that are retrieved. Valid values are ACTIVE, DELETED, or ALL. ACTIVE refers to all the files that are currently undeleted. DELETED refers to files that have been marked deleted. ALL is used to retrieve all files. The default value is ALL. |
| Input Example | <p>To retrieve information on all the files that are present on the Flash device, use the following:</p> <p>RTRV-MEM:ons155xx:DISK-0:123;</p> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<aid>:INDEX=<index>,ACCESS=<access>,SIZE=<size>,DATE=<date>, TIME=<time>,FILENAME=<filename>,STATUS=<status>" ;</pre> |
| Output Example | <pre>SID DATE TIME M 123 COMPLD "BOOTFLASH:INDEX=1,ACCESS=RW,SIZE=145678,DATE=12-115.01, TIME=10-22-00,FILENAME=ons15540-i-mz,STATUS=ACTIVE" "BOOTFLASH:INDEX=2,ACCESS=RW,SIZE=146140,DATE=12-115.01, TIME=13-10-00,FILENAME=ons15540-i-mz.temp,STATUS=DELETED" ;</pre> <p>Where:</p> <ul style="list-style-type: none"> • INDEX shows the index number associated with the deleted file. • ACCESS shows the permissions on that file. Valid values are RW (read/write) and RO (read-only). • SIZE shows the size of the file in bytes. • DATE is the string that shows the date of the file. The format is MM-DD-YY. • TIME is the string that shows the time on the file. The format is HH-MM-SS. • NAME is the string that shows the name of the file. The maximum length is 255 characters. |
| Errors | <p>Errors are listed in Table 2-15 on page 2-9.</p> |

3.63 RTRV-NBR: Retrieve Neighbor

Use this command to retrieve the neighbor information on port(s).

If the AID value is not provided, then information about all the neighbors discovered (for all of the ports) is retrieved.

| Section | RTRV-NBR Description |
|------------------|--|
| Category | Topology neighbor configuration |
| Security | Retrieve |
| Related Messages | 3.10 DLT-NBR: Delete Neighbor 3.29 ENT-NBR: Enter Neighbor |
| Input Format | RTRV-NBR:[<tid>]:[<aid>]:<ctag>; <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the interface and can be one of the following: <ul style="list-style-type: none"> – TRANSPARENT-slot-subcard-0 – TENGIGETHERPHY-slot-subcard – WDM-slot-subcard • <ctag> is the correlation tag. |
| Input Example | To retrieve the neighbor information on ports, use the following: RTRV-NBR:ons155xx:WDM-0-0:123; |
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>:DSCVRY=<dscrvy>,LINKDIRN=<linkdirn>,NBRNAME=<nbrname>, NBRPORT=<nbrport>,NBRAGENTIP=<nbragentip>" ; |
| Output Example | SID DATE TIME M 123 COMPLD "WDM-0-0:DSCVRY=MANUAL,LINKDIRN=RX, NBRNAME=shelf2,NBRPORT=WDM-0-0, NBRAGENTIP=172.16.20.1" "WDM-0-0:DSCVRY=MANUAL,LINKDIRN=TX, NBRNAME=edfa_box1,NBRPORT=in_port, NBRAGENTIP=172.16.20.9" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.64 RTRV-NE-CDP: Retrieve Network Element CDP

Use this command to retrieve global CDP information.

| Section | RTRV-NE-CDP Description |
|----------|-------------------------|
| Category | CDP |
| Security | Retrieve |

| Section | RTRV-NE-CDP Description (continued) |
|------------------|--|
| Related Messages | 3.19 ED-NE-CDP: Edit Network Element CDP, page 3-16 |
| Input Format | RTRV-NE-CDP:[<tid>]::<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |
| Input Example | To retrieve global CDP information, use the following: RTRV-NE-CDP:ons155xx::123; |
| Output Format | SID DATE TIME M CTAG COMPLD "CDP=<cdp>,UPDATETIME=<updatetime>,HOLDTIME=<holdtime>, SENDVER=<sendver>" ; |
| Output Example | SID DATE TIME M 123 COMPLD "CDP=Y,UPDATETIME=60,HOLDTIME=180,SENDVER=2" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.65 RTRV-NE-GEN: Retrieve Generic NE Configuration Values

Use this command to retrieve generic NE configuration values.

| Section | RTRV-NE-GEN Description |
|------------------|--|
| Category | Generic NE configuration |
| Security | Retrieve |
| Related Messages | 3.20 ED-NE-GEN: Edit Network Element General, page 3-17 |
| Input Format | RTRV-NE-GEN:[<tid>]::<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |
| Input Example | To retrieve generic NE configuration values, use the following: RTRV-NE-GEN:ons155xx::123; |
| Output Format | SID DATE TIME M CTAG COMPLD "CURCFGREG=<curcfgreg>,NEWCFGREG=<newcfgreg>, SWVER=<swver>,SWNAME=<swname>,SYSFILE=<sysfile>, CMPLTIME=<cmpltime>,CMPLBY=<cmplby>,BOOTLDR=<bootldr>" ; |

| Section | RTRV-NE-GEN Description (continued) |
|----------------|--|
| Output Example | SID DATE TIME M 123 COMPLD "CURCFGREG=0x0,NEWCFGREG=0x2,SWVER=12.1, SWNAME=ONS15540-I-M, SYSFILE=bootflash:ons15540-i-mz, CMPLTIME=01-10-11-19-33,CMPLBY=hqluong" ; Where: <ul style="list-style-type: none"> • CURCFGREG shows the current configuration register setting in hexadecimal. • NEWCFGREG shows the new (the value that takes effect on next reload) configuration register setting in hexadecimal. • SWVER indicates the software version; the maximum length is 32 characters. • SWNAME indicates the name of the software image; the maximum length is 64 characters. • SYSFILE indicates the system image file; the maximum length is 255 characters. • CMPLTIME indicates the compiled time. The format of this string is YY-MM-DD-HH-MM. • CMPLBY indicates the username of person who compiled this software image; maximum length is 8 characters. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.66 RTRV-NE-OSCP: Retrieve Network Element OSCP

Use this command to retrieve the configurations for OSCP.

| Section | RTRV-NE-OSCP Description |
|------------------|---|
| Category | OSCP |
| Security | Retrieve |
| Related Messages | 3.21 ED-NE-OSCP: Edit Network Element OSCP |
| Input Format | RTRV-NE-OSCP:[<tid>]::<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |
| Input Example | To retrieve the configurations for OSCP, use the following: RTRV-NE-OSCP:ons155xx::123; |
| Output Format | SID DATE TIME M CTAG COMPLD "HELLOINTV=<hellointv>,HELLOHLDWN=<hellohldwn>, INACTFCTR=<inactfctr>" ; |

| Section | RTRV-NE-OSCP Description (continued) |
|----------------|---|
| Output Example | SID DATE TIME M 123 COMPLD "HELLOINTV=500,HELLOHLDWN=200,INACTFCTR=10" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.67 RTRV-NTP: Retrieve NTP

Use this command to retrieve the NTP status parameters for the system.

| Section | RTRV-NTP Description |
|------------------|--|
| Category | NTP |
| Security | Retrieve |
| Related Messages | 3.11 DLT-NTPASSOC: Delete NTP Associations 3.30 ENT-NTPASSOC: Enter NTP Associations |
| Input Format | RTRV-NTP:[<tid>]::<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |
| Output Format | SID DATE TIME M CTAG COMPLD "SYNCSTATE=<syncstate>,STRATUM=<stratum>, REFIPADDR=<refipaddr>,NOMFREQ=<nomfreq>,ACTFREQ=<actfreq>, PRECISION=<precision>,REFTIME=<reftime>,CLKOFFSET=<clkoffset>, ROOTDELAY=<rootdelay>,ROOTDISP=<rootdisp>,PEERDISP=<peerdisp>" ; |

| Section | RTRV-NTP Description (continued) |
|----------------|---|
| Output Example | <pre>SID DATE TIME M 123 COMPLD "SYNCSTATE=Y,STRATUM=4,REFIPADDR=172.16.246.1,NOMFREQ=250 , ACTFREQ=249.9999,PRECISION=24, REFTIME=09:09:38.885PSTSunDec302001, CLKOFFSET=7.7674,ROOTDELAY=113.39,ROOTDISP=386.72, PEERDISP=1.57" ;</pre> <p>Where:</p> <ul style="list-style-type: none"> • SYNCSTATE indicates whether clock is synchronized. Valid values are Y or N. • STRATUM indicates the stratum of the reference clock. This is an integer value from 1 to 16. • REFIPADDR indicates the IP address of the peer/server from where the reference clock is being derived. • NOMFREQ shows the nominal frequency in Hz. • ACTFREQ shows the actual frequency in Hz. • PRECISION indicates the precision of the derived clock. If the value specified here is x, the actual precision is in the form 2^x. • REFTIME indicates the clock reference time. • CLKOFFSET shows the clock offset in milliseconds. • ROOTDELAY shows a string value that shows the root delay in milliseconds. • ROOTDISP shows the root dispersion in milliseconds. • PEERDISP shows the peer dispersion in milliseconds. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.68 RTRV-NTPASSOC: Retrieve NTP Associations

Use this command to retrieve the NTP parameters for each association that is created.

| Section | RTRV-NTPASSOC Description |
|------------------|---|
| Category | NTP |
| Security | Retrieve |
| Related Messages | 3.11 DLT-NTPASSOC: Delete NTP Associations 3.30 ENT-NTPASSOC: Enter NTP Associations 3.67 RTRV-NTP: Retrieve NTP |
| Input Format | <pre>RTRV-NTPASSOC:[<tid>]::<ctag>;</pre> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |

| Section | RTRV-NTPASSOC Description (continued) |
|----------------|---|
| Output Format | <pre> SID DATE TIME M CTAG COMPLD "ASSOCTYPE=<assotype>,ASSOCIPADDR=<associpaddr>, ASSOCSTRATUM=<assocstratum>,ASSOCREFID=<assocrefid>, ASSOC POLL=<assocpoll>,ASSOCREACH=<assocreach>, ASSOCDELAY=<assocdelay>,ASSOCOFFSET=<assocoffset>, ASSOCDISP=<assocdisp>" ; </pre> |
| Output Example | <pre> SID DATE TIME M 123 COMPLD "ASSOCTYPE=SERVER,ASSOCIPADDR=172.16.246.1, ASSOCSTRATUM=2,ASSOCREFID=172.16.10.80,ASSOC POLL=64, ASSOCREACH=377,ASSOCDELAY=1.4,ASSOCOFFSET=-23005, ASSOCDISP=4925" ; </pre> <p>Where:</p> <ul style="list-style-type: none"> • ASSOCTYPE shows the association type. The values are SERVER and PEER. • ASSOCIPADDR shows the IP address of the server or peer. • ASSOCSTRATUM shows the stratum of the peer's clock. It has an integer value from 1 to 16. • ASSOCREFID indicates the reference ID of the peer is an IP address. • ASSOC POLL indicates the interval at which the local host polls the peer. This is an integer value in seconds. • ASSOCREACH indicates the reachability status of the peer. This is an integer value from 0 to 255. • ASSOCDELAY shows the estimated round-trip delay of the peer clock with reference to the local clock, in seconds. • ASSOCOFFSET shows the estimated offset of the peer clock with reference to the local clock, in seconds. • ASSOCDISP shows the estimated error between the peer clock and the local clock, in seconds. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.69 RTRV-OCH: Retrieve Optical Channel

Use this command to retrieve interface configuration information.

The PST and SST values in the last position defined block indicate the current status of the interface. The values of PST-PSTQ and SST, under different conditions, are listed as follows:

- If the interface is administratively shut down by using the ENT-OCH command, values returned are PST=OOS-MA, SST=MT.
- If the interface and the laser are shut down administratively, values returned are PST=OOS_MA, SST=MT, LASER.

- If the interface is down because of alarms on the link, such as Loss of Signal/Loss of Frame, Loss of Light, values returned are PST=OOS-AU, SST=FAF.
- If the interface is down because of alarms and is also administratively shut down, values returned are PST=OOS-AUMA, SST=FAF, MT.
- If there is an entity failure on the NE because the interface is down, values returned are PST=OOS-AU, SST= SGEO.
- If the transmit laser fails at an interface, values returned is PST=OOS-AU, SST=FLT.
- If only thresholds are exceeded on the interface, values returned are PST=IS-ANR. For wavepatch interfaces only, the SST value also indicates the current state with respect to APS of the interface.
- If the wavepatch is currently active, the SST value of ACT is returned.
- If the wavepatch is currently standby, the value of STBYH is returned.
- Under normal operating conditions, values returned are PST=IS-NR.


| Section | RTRV-OCH Description |
|------------------|--|
| Category | Transparent interface configuration |
| Security | Retrieve |
| Related Messages | 3.22 ED-OCH: Edit Optical Channel 3.42 OPR-LPBK-OCH: Operate Loopback OCH 3.69 RTRV-OCH: Retrieve Optical Channel 3.69 RTRV-OCH: Retrieve Optical Channel |
| Input Format | RTRV-OCH:[<tid>]:[<aid>]:<ctag> Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <AID> indicates the interface that is being configured. Valid values are TRANSPARENT-slot-subcard-0, WAVE-slot-subcard, WAVEPATCH-slot-subcard-port, or ETHERDCC-slot-subcard-port. • <ctag> is the correlation tag. |
| Input Example | To retrieve interface configuration information, use the following: RTRV-OCH:ons155xx:TRANSPARENT-10-0-0:123; RTRV-OCH:ons155xx:WAVE-8-0:123; |
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>:THRLISTNAME=<thrlistname>,FLC=<flc>,LSC=<lsc>, LASERFREQ=<laserfreq>,LPBKTYPE=<lpbktype>:<pst>" ; |

| Section | RTRV-OCH Description (continued) |
|----------------|---|
| Output Example | <pre>SID DATE TIME M 123 COMPLD "TRANSPARENT-10-0-0:ENCAP=OC3,THRLISTNAME=sonet-cvs, FLC=N,LPBKTYPE=FACILITY:IS-NR" ; SID DATE TIME M 123 COMPLD "WAVE-8-0:THRLISTNAME=sonet-cvs,FLC=N,LSC=Y, LASERFREQ=159800, LPBKTYPE=FACILITY:IS-NR" ;</pre> <p>Where:</p> <ul style="list-style-type: none"> • LASERFREQ can be retrieved only on the AID WAVE-slot-subcard. • LPBKTYPE indicates the type of loopback on the interface. Valid values are as follows: <ul style="list-style-type: none"> – FACILITY - where the signal from the receive input is looped back to the transmit output. – TERMINAL - where the signal bound for transmit output is looped back to the receive input. This is an internal loopback and it is used for hardware debug and diagnostics. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.70 RTRV-PATCH: Retrieve Patch

Use this command to retrieve the patch configuration.


| Section | RTRV-PATCH Description |
|------------------|---|
| Category | Patch configuration |
| Security | Retrieve |
| Related Messages | 3.12 DLT-PATCH: Delete Patch 3.31 ENT-PATCH: Enter Patch |

| Section | RTRV-PATCH Description (continued) |
|----------------|--|
| Input Format | <p>RTRV-PATCH:[<tid>]:[<from_aid>],[<to_aid>]:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <from_aid> identifies the port patched to the port identified by <to_aid>. Valid values for <from_aid> are as follows: <ul style="list-style-type: none"> - FILTER-slot-subcard-0 - OSCFILTER-slot-subcard - THRU-slot-subcard - WAVE-slot - WAVEPATCH-slot-subcard-port - WDM-slot-subcard • <to_aid> identifies the port patched from the port identified by <from_aid>. Valid values for <to_aid> are as follows: <ul style="list-style-type: none"> - FILTER-slot-subcard-0 - OSCFILTER-slot-subcard - THRU-slot-subcard - WAVE-slot - WAVEPATCH-slot-subcard-port - WDM-slot-subcard • <ctag> is the correlation tag. <p> Note If the AID value is not provided, then information for all the patches is retrieved. If both the AIDs are specified, all the patches associated with the specified AIDs is retrieved.</p> |
| Input Example | <p>To retrieve the patch configuration, use the following:</p> <pre>RTRV-PATCH:ons155xx::123;</pre> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<from_aid>,<to_aid>:<dirn>" ;</pre> |
| Output Example | <pre>SID DATE TIME M 123 COMPLD "WAVEPATCH-2-0-0,FILTER-0-0-0:2WAY" "WDM-0-0,THRU-0-0:2WAY" ;</pre> |
| Errors | <p>Errors are listed in Table 2-15 on page 2-9.</p> |

3.71 RTRV-PM-ENCAP: Retrieve Performance Encapsulation

Use this command to retrieve the performance monitoring parameters related to error counters for transponder and OSC wave interfaces specified by the AID. The parameter is specified by <montype> and the <tmper> specifies the accumulation time period.

| Section | RTRV-PM-ENCAP Description |
|------------------|---|
| Category | Transparent interface configuration |
| Security | Retrieve |
| Related Messages | 3.22 ED-OCH: Edit Optical Channel |
| Input Format | <p>RTRV-PM-ENCAP:[<tid>]:[<aid>]:<ctag>::[<montype>],,,,[<tmper>], [<mondat>],[<montm>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates transparent interface or wave interface for which performance monitor data is being retrieved. Valid values are TRANSPARENT-slot-subcard-0, WAVE-slot-subcard, or WAVE-slot. • <ctag> is the correlation tag. • <montype> is the monitored parameter type. Valid values are as follows: <ul style="list-style-type: none"> – FC - Indicates the number of times signal failure threshold was exceeded on an interface. – DC - Indicates the number of times signal degrade threshold was exceeded on an interface. – PSC - Shows protection switch count (for APS) on the AID. – ESS - Errored second count (section). – SEFS-S - Severely errored framing seconds count. – SESS - Severely errored second count. – CVRD - Coding violations and running disparity errors. – CDLHEC - CDL header error count. This parameter applies to the OSC WAVE-slot AIDs only. <p>The default is all montypes.</p> <ul style="list-style-type: none"> • <tmper> is the time period for the counts. Valid values are 15-MIN, 24-HR, or TOTAL. The 15-MIN and 24-HR counts are reported only for the SONET-related counters CVS, ESS, SEFS-S, and SESS. For all other counters, only TOTAL counts are reported. • <mond> is the day the AID was monitored. The format is YY-MM-DD. • <montm> is the time the AID was monitored. The format is HH:SS. |
| Input Example | <p>To retrieve the performance monitoring parameters for the transparent interface in slot 2, subcard 0, use the following:</p> <pre>RTRV-PM-ENCAP:ons155xx:TRANSPARENT-2-0-0:123;</pre> |

| Section | RTRV-PM-ENCAP Description (continued) |
|----------------|---|
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>:<error>,<count>,COMPL,,,<interval>" ; |
| Output Example | SID DATE TIME M 123 COMPLD "TRANSPARENT-2-0-0,OC3:CVS,153,COMPL,,15-MIN" "TRANSPARENT-2-0-0,OC3:FC,0,COMPL,,TOTAL" "TRANSPARENT-2-0-0,OC3:DC,5,COMPL,,TOTAL" "TRANSPARENT-2-0-0,OC3:PSC,6,COMPL,,TOTAL" ; Where: <ul style="list-style-type: none"> • FC is the number of times signal failure threshold was exceeded on an interface. • DC is the number of times signal degrade threshold was exceeded on an interface. • PSC is the protection switch count (for APS) on the interface.  <p>Note Valid values for the time period for this command include 15-MIN, 24-HR and TOTAL. The 15-MIN and 24-HR counts are reported only for SONET related counters. That is CVS, ESS, SEFS-S, SESS. For all other counters, only TOTAL counts is reported.</p> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.72 RTRV-PM-EQPT: Retrieve Performance Monitoring Equipment

Use this command to retrieve performance monitoring data for a processor card.

| Section | RTRV-PM-EQPT Description |
|------------------|--|
| Category | Redundancy Configuration |
| Security | Retrieve |
| Related Messages | 3.37 INIT-REG-ETH: Initialize Register Ethernet, page 3-37 |
| Input Format | RTRV-PM-EQPT:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag. |
| Input Example | To retrieve performance monitoring parameters for the processor card in slot 6, use the following: RTRV-PM-EQPT:ons155xx:SLOT-6:123; |

| Section | RTRV-PM-EQPT Description (continued) |
|----------------|---|
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<aid>:<montype>,<date>,,,,<interval>" ;</pre> |
| Output Example | <pre>SID DATE TIME M 123 COMPLD "SLOT-6:SWCT,1,,," "SLOT-6:SWTM,0,,,,01-10-11-19-33" "SLOT-6:AVAILUPTM,0,,,,00-00-03-04-35" "SLOT-6:INITM,0,,,,00-00-00-22-33" "SLOT-6:RCSYNCTM,0,,,,00-00-00-02-18" "SLOT-6:SCSYNCTM,0,,,,00-00-00-06-01" ; /* RTRV-PM-EQPT */</pre> <p>Where:</p> <ul style="list-style-type: none"> • SWCT is an integer and shows switchover counts. • SWTM is a string and shows the last switchover time in YY-MM-DD-HH-MM. • AVAILUPTM shows available uptime such as time since the last event when the entire system was down. The format is YY-MM-DD-HH-MM. • INITM shows the time since this module was initialized. The format is YY-MM-DD-HH-MM. • RCSYNCTM shows the time since the last running-config sync. The format is YY-MM-DD-HH-MM. • SCSYNCTM shows the time since the last startup-config sync. The format is YY-MM-DD-HH-MM. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.73 RTRV-PM-GBE10: Retrieve Performance Monitoring on 10-GE

Use this command to retrieve the performance monitoring parameters on the 10-GE transponder module interfaces.

| Section | RTRV-PM-GBE10 Description |
|------------------|--|
| Category | 10-GE interface configuration |
| Security | Retrieve |
| Related Messages | 3.75 RTRV-PM-rr: Retrieve Performance Monitoring |

| Section | RTRV-PM-GBE10 Description (continued) |
|----------------|---|
| Input Format | <p>RTRV-PM-GBE10:[<tid>]:[<aid>]:<ctag>::[<montype>],,, [<tmper>],[<mondat>],[<montm>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> identifies the interface and can be one of the following: <ul style="list-style-type: none"> – WAVEETHERPHY-slot-subcard – TENGIGETHERPHY-slot-subcard • <ctag> is the correlation tag. • <montype> specifies the performance monitor parameter. Valid values are as follows: <ul style="list-style-type: none"> – CVRD specifies coding violations and running disparity errors count. – CRC specifies cyclic redundancy checksum errors. • <tmper> is the time period for the counts. Valid values are 15-MIN, 24-HR, or TOTAL. The 15-MIN and 24-HR counts are reported only for the SONET-related counters CVS, ESS, SEFS-S, and SESS. For all other counters, only TOTAL counts are reported. • <mond> is the day the AID was monitored. The format is YY-MM-DD. • <montm> is the time the AID was monitored. The format is HH:SS. |
| Input Example | <p>To retrieve the performance monitor information related to error counters from waveetherphy interface in slot 9, subcard 0, use the following:</p> <pre>RTRV-PM-GBE10:ons155xx:WAVEETHERPHY-9-0:123;</pre> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<aid>:<error>,<count>,COMPL,,,<interval>" ;</pre> |
| Output Example | <pre>SID DATE TIME M 123 COMPLD "WAVEETHERPHY-9-0:CRC,50,COMPL,,TOTAL" "WAVEETHERPHY-9-0:CVRD,60,COMPL,,TOTAL" "WAVEETHERPHY-9-0:CDLHEC,500,COMPL,,TOTAL" "WAVEETHERPHY-9-0:INVALIDFLOWID,10000,COMPL,,TOTAL" "WAVEETHERPHY-9-0:NONCDLPAK,15.0,COMPL,,TOTAL";</pre> <p>Where:</p> <ul style="list-style-type: none"> • CDLHEC shows CRC error counts in the CDL header. • INVALIDFLOWID shows the count associated with the CDL flow identifier lookup errors encountered in the receive direction. • NONCDLPAK shows the count associated with the number of packets received without a CDL header in the receive direction. This counter is incremented only when CDL is enabled on the interface. |
| Errors | <p>Errors are listed in Table 2-15 on page 2-9.</p> |

3.74 RTRV-PMODE-OCH: Retrieve Performance Mode OCH

Use this command to retrieve the configuration for performance monitoring.

| Section | RTRV-PMODE-OCH Description |
|------------------|--|
| Category | Transparent interface configuration |
| Security | Retrieve |
| Related Messages | 3.82 SET-PMODE-OCH: Set Performance Mode OCH |
| Input Format | RTRV-PMODE-OCH:[<tid>]:[<aid>]:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The value is TRANSPARENT-slot-subcard-0. • <ctag> is the correlation tag. |
| Input Example | To retrieve the configuration for performance monitoring, use the following: RTRV-PMODE-OCH:ons155xx:TRANSPARENT-10-0-0:123; |
| Output Format | SID DATE TIME M CTAG COMPLD " <aid>:.,,<pmmode>" ; |
| Output Example | SID DATE TIME M 123 COMPLD "TRANSPARENT-10-0-0:.,,ON" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.75 RTRV-PM-rr: Retrieve Performance Monitoring

Use this command to retrieve the performance monitoring information for optical parameters on a transponder module interface specified by the AID. The parameter is specified by <montype> and <tmper> specifies the accumulation time period.



Note

The value returned for all optical power related montype parameters is in the range of -40 to 25 dBm. The value returned for all laser bias current related montype parameters is in hundreds of microamperes and has a range from 0 to 10000. The value returned for all laser temperature related montype parameters is in tenths of degrees centigrade and has a range from -500 to 850.

| Section | RTRV-PM-rr Description |
|------------------|--|
| Category | Optical parameter monitoring |
| Security | Retrieve |
| Related Messages | 3.72 RTRV-PM-EQPT: Retrieve Performance Monitoring Equipment 3.71 RTRV-PM-ENCAP: Retrieve Performance Encapsulation |

| Section | RTRV-PM-rr Description (continued) |
|---------------|--|
| Input Format | <p>RTRV-PM-rr:[<tid>]:[<aid>]:<ctag>::[<montype>],[<monlev>],[<dirn>],[<tmper>],[<mondatt>],[<montm>];</p> <p>Where:</p> <ul style="list-style-type: none"> • rr is OCH. • <tid> is the target identifier. • <aid > is the access identifier. The value of AID can be WAVE-slot-subcard, WAVEETHERPHY-slot-subcard, or WAVEPATCH-slot-subcard-port. • <ctag> is the correlation tag. • <montype> is the performance monitoring parameter. Valid values are as follows: <ul style="list-style-type: none"> – OPR indicates the current value of the received optical power level. – OPRMIN indicates the minimum value of the received optical power level during a particular interval. – OPRMAX indicates the maximum value of the received optical power level during a particular interval. – OPRAVG indicates the average value of the received optical power level during a particular interval. • <monlev> is the level for the performance monitoring parameter. Valid values are n-UP and n-DN, where n is a decimal number indicating the number of levels in the desired direction. • <dirn> is the direction. Valid values are RCV or TRMT. • <tmper> is the time period for the counts. Valid values are 15-MIN, 24-HR, or TOTAL. The 15-MIN and 24-HR counts are reported only for the SONET-related counters CVS, ESS, SEFS-S, and SESS. For all other counters, only TOTAL counts are reported. • <mond> is the day the AID was monitored. The format is YY-MM-DD. • <montm> is the time the AID was monitored. The format is HH:SS. |
| Input Example | <p>To retrieve the performance monitor information for the optical parameters monitored on the wavepatch interface in slot 8, subcard 0, port 0, use the following:</p> <pre>RTRV-PM-OCH:ons155xx:WAVEPATCH-8-0-0:123;</pre> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<aid>:<montype>,<value>,COMPL,,<dirn>,<interval>,<date>,<time>" ;</pre> |

| Section | RTRV-PM-rr Description (continued) |
|----------------|---|
| Output Example | <pre>SID DATE TIME M 123 COMPLD "WAVEPATCH-8-0-0:OPR,11.0,COMPL,,RCV,CURRENT" "WAVEPATCH-8-0-0:OPRMIN,5.0,COMPL,,RCV,15-MIN,05-09,22-45" "WAVEPATCH-8-0-0:OPRMAX,15.0,COMPL,,RCV,15-MIN,05-09,22-45" "WAVEPATCH-8-0-0:OPRAVG,10.0,COMPL,,RCV,15-MIN,05-09,22-45" ;</pre> <p>Where:</p> <ul style="list-style-type: none"> • OPR indicates the current value of the received optical power level. • OPRMIN indicates the minimum value of the received optical power level during a particular interval. • OPRMAX indicates the maximum value of the received optical power level during a particular interval. <p>OPRAVG indicates the average value of the received optical power level during a particular interval.</p> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.76 RTRV-THR-OCH: Retrieve Thresholds OCH

Use this command to retrieve the configurations for thresholds. The complete threshold list or specific thresholds within the list can be retrieved.



Note

When retrieving a particular threshold from a list, both the ERRRTYPE and THRRTYPE parameters, along with the THRLISTNAME, must be specified.

| Section | RTRV-THR-OCH Description |
|------------------|--|
| Category | Threshold list configuration |
| Security | Retrieve |
| Related Messages | 3.13 DLT-THR-OCH: Delete Threshold OCH 3.32 ENT-THR-OCH: Enter Thresholds OCH 3.77 RTRV-TH-rr: Retrieve Threshold 3.84 SET-TH-rr: Set Optical Threshold |

| Section | RTRV-THR-OCH Description (continued) |
|----------------|---|
| Input Format | <p>RTRV-THR-OCH:[<tid>]:[<thrlistname>]:<ctag>:::[ERRRTYPE=<errtype>, THRRTYPE=<thrtype>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <thrlistname> specifies the threshold list. • <ctag> is the correlation tag. • <errtype> indicates the type of error counter to which the threshold applies. Valid values are as follows: <ul style="list-style-type: none"> - CVS - SONET/SDH section CV errors - CVRD - 8B/10B code violations and running disparity errors - CDLHEC - CDL HEC errors - CRC - Cyclic redundancy check errors • <thrtype> indicates the threshold type. Valid values are as follows: <ul style="list-style-type: none"> - DEGR - Indicates that a signal degrade condition has been reached. Use this threshold type only when <errtype> is CVS. - FAIL - Indicates that a signal failure condition has been reached. Use this threshold type only when <errtype> is CVS. - EVTTHR - Indicates that a non-service affecting condition has been reached. Use this threshold type only when <errtype> is not CVS. - ALMTHR - Indicates that a service affecting condition has been reached. Use this threshold type only when <errtype> is not CVS. |
| Input Example | <p>To retrieve the configurations for thresholds, use the following:</p> <pre>RTRV-THR-OCH:ons155xx:sonet-cvs:123;</pre> |
| Output Format | <pre>SID DATE TIME M CTAG COMPLD "<thrlistname>:ERRRTYPE=<errtype>,THRRTYPE=<thrtype>,VALUE=<value>, INDEX=<index>,TRGAPS=<trgaps>,DESCR=<descr>" ;</pre> |
| Output Example | <pre>SID DATE TIME M 123 COMPLD "sonet-cvs:ERRRTYPE=CVS,THRRTYPE=DEGR,VALUE=7,INDEX=1, TRGAPS=Y,DESCR=xxx" ;</pre> |
| Errors | <p>Errors are listed in Table 2-15 on page 2-9.</p> |

3.77 RTRV-TH-rr: Retrieve Threshold

Use this command to retrieve the optical power threshold values configured on the wavepatch interfaces and waveetherphy interfaces interfaces.

| Section | RTRV-TH-rr Description |
|------------------|--|
| Category | Optical Parameter Monitoring |
| Security | Retrieve |
| Related Messages | 3.24 ED-THR-OCH: Edit Thresholds OCH 3.84 SET-TH-rr: Set Optical Threshold |
| Input Format | RTRV-TH-rr:[<tid>]:[<aid>]:<ctag>::[<montype>]; Where: <ul style="list-style-type: none"> • rr is OCH. • <tid> is the target identifier. • <aid> indicates wavepatch or waveetherphy interfaces on which the threshold is to be set. Valid values are WAVEPATCH-slot-subcard-port or WAVEETHERPHY-slot-subcard. • <ctag> is the correlation tag. • <montype> is the performance monitoring parameter. Valid values are as follows: <ul style="list-style-type: none"> – OPR indicates the current value of the received optical power level. – OPRMIN indicates the minimum value of the received optical power level during a particular interval. – OPRMAX indicates the maximum value of the received optical power level during a particular interval. – OPRAVG indicates the average value of the received optical power level during a particular interval. |
| Input Example | To retrieve the threshold values configured on the wavepatch interfaces, use the following: RTRV-TH-OCH:ons155xx:WAVEPATCH-8-0-0:123::OPRHA; |
| Output Format | SID DATE TIME M CTAG COMPLD "<aid>:<montype>,,<dirn>,<value>" ; |
| Output Example | SID DATE TIME M 123 COMPLD "WAVEPATCH-8-0-0:OPRHA,,RCV,200" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.78 RTRV-TOD: Retrieve Time of Day

Use this command to retrieve time-of-day (TOD) information for the NE.

| Section | RTRV-TOD Description |
|------------------|---|
| Category | Generic NE configuration |
| Security | Retrieve |
| Related Messages | 3.15 ED-DAT: Edit Date |
| Input Format | RTRV-TOD:[<tid>]::<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. |
| Input Example | To retrieve TOD information for the NE, use the following: RTRV-TOD:ons155xx::123; |
| Output Format | SID DATE TIME M CTAG COMPLD "<year>,<month>,<day>,<hour>,<minute>,<second>.<thousandths-of-second>,<timezone>" ; |
| Output Example | SID 2003-02-11 13:30:51 M 123 COMPLD "2003,2,11,13,30,51.879,UTC" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.79 RTRV-USER-SECU: Retrieve User Security

Use this command to retrieve the security parameters associated with a user, except for the password.

| Section | RTRV-USER-SECU Description |
|------------------|---|
| Category | Security |
| Security | Retrieve |
| Related Messages | 3.1 ACT-USER: Activate User 3.4 CANC-USER: Cancel User 3.14 DLT-USER-SECU: Delete User Security 3.25 ED-USER-SECU: Edit User Security 3.33 ENT-USER-SECU: Enter User Security |

| Section | RTRV-USER-SECU Description (continued) |
|----------------|--|
| Input Format | RTRV-USER-SECU:[<tid>]:<uid>:<ctag>; Where: <ul style="list-style-type: none"> • <tid> is the target identifier. • <uid> is the user identifier. • <ctag> is the correlation tag. |
| Input Example | To retrieve the security parameters associated with a user, use the following: RTRV-USER-SECU:ons155xx:admin:123; |
| Output Format | SID DATE TIME M CTAG COMPLD " <uid>:,<security>:" ; |
| Output Example | SID DATE TIME M 123 COMPLD "admin:,PROV:" ; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.80 SET-ATTR-rr: Set Attributes

Use this command to set the severity associated with the thresholds configured using the SET-TH-rr command described in the “[3.84 SET-TH-rr: Set Optical Threshold](#)” section on page 3-87.

| Section | SET-ATTR-rr Description |
|------------------|---|
| Category | Optical Parameter Monitoring |
| Security | Retrieve |
| Related Messages | 3.69 RTRV-OCH: Retrieve Optical Channel 3.77 RTRV-TH-rr: Retrieve Threshold 3.76 RTRV-THR-OCH: Retrieve Thresholds OCH 3.84 SET-TH-rr: Set Optical Threshold |

| Section | SET-ATTR-rr Description (continued) |
|---------------|---|
| Input Format | <p>SET-ATTR-rr:[<tid>]:<aid>:<ctag>::[<ntfncnde>],[<condtype>],[<dirn>];</p> <p>Where:</p> <ul style="list-style-type: none"> • rr is OCH. • <tid> is the target identifier. • <aid> is the access identifier. The value of AID is WAVEPATCH-slot-subcard-port. • <ctag> is the correlation tag. • <ntfncnde> indicates the type of notification generated on the NE when a threshold is exceeded or cleared. When the condtyp parameter corresponds to the high alarm or the low alarm conditions, the notification code can have values CR (critical) or MJ (major) only. The condition is reported through REPT ALM service affect flag is set to SA. When the condtyp parameter corresponds to the high warning or low warning conditions, the notification code can have values MN (minor), NA (not alarmed) or NR (not reported). When the notification code is set to MN, the condition is reported through REPT ALM and the service affect flag is NSA. When the notification code is set to NA, the condition is reported through REPT EVT and the condeff flag is set to SC. When the notification code is set to NR, the condition will not be reported (the information can be retrieved from the NE) and the condeff flag is set to SC. • <condtype> is the monitored condition type. Valid values are as follows: <ul style="list-style-type: none"> – OPRHA - Receive optical power level corresponding to the high alarm threshold. If the optical power level is greater than the threshold associated with this parameter, an alarm is generated. – OPRLA - Receive optical power level corresponding to the low alarm threshold. If the optical power level is less than the threshold associated with this parameter, an alarm is generated. – OPRHW - Receive optical power level corresponding to the high warning threshold. If the optical power level is greater than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. – OPRLW - Receive optical power level corresponding to the low warning threshold. If the optical power level is less than the threshold associated with this parameter, a warning is generated that may be reported using the REPT EVT. • <dirn> is the direction associated with the information. Valid values are RCV or TRMT. The default is both directions. |
| Input Example | <p>To configure a severity of MJ on the high alarm threshold on the received optical power, at the wavepatch interface in slot 8, subcard 0, port 0, use the following:</p> <pre>SET-ATTR-OCH:ons155xx:WAVEPATCH-8-0-0:123::MJ,OPRHA,,RCV;</pre> |
| Errors | <p>Errors are listed in Table 2-15 on page 2-9.</p> |

3.81 SET-NTP: Set NTP

Use this command to configure NTP attributes on the entire system.

| Section | SET-NTP Description |
|------------------|---|
| Category | NTP |
| Security | Maintenance |
| Related Messages | 3.67 RTRV-NTP: Retrieve NTP |
| Input Format | <p>SET-NTP:[<tid>]::<ctag>:::[MASTER=<master>],[MSTRATUM=<mstatum>],[MAXASSOC=<maxassoc>],[CLKPERIOD=<clkperiod>],[UPDCAL=<updcal>];</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <ctag> is the correlation tag. • <master> enables or disables this NE to act as NTP master clock. Valid values are Y or N. The default is N. • <mstratum> indicates stratum value to use while acting as NTP master clock. • <maxassoc> sets the maximum number of NTP associations allowed. Valid values are 0 to 4294967295 . • <clkperiod> sets the length of hardware clock tick in 2^{-32} seconds. Valid values are 0 to 4294967295. • <updcal> indicates whether the NE should update its internal hardware clock with clock value obtained from NTP. Valid values are Y or N. The default is N. |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.82 SET-PMODE-OCH: Set Performance Mode OCH

Use this command to enable and disable performance monitoring on a transparent interface. The <locn> and <modetype> parameters in this command do not apply and are set to NULL.

| Section | SET-PMODE-OCH Description |
|------------------|---|
| Category | Transparent interface configuration |
| Security | Maintenance |
| Related Messages | 3.74 RTRV-PMODE-OCH: Retrieve Performance Mode OCH |
| Input Format | <p>SET-PMODE-OCH:[<tid>]:<aid>:<ctag>:.,,<pmstate>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> is the access identifier. The value is TRANSPARENT-slot-subcard-0. • <ctag> is the correlation tag. • <pmstate> is the performance monitoring state. Valid values are ON or OFF. The default value is OFF. |

| Section | SET-PMMODE-OCH Description (continued) |
|---------------|---|
| Input Example | To enable monitoring on the transparent interface in slot 2, subcard 0, use the following: SET-PMMODE-OCH:ons155xx:TRANSPARENT-2-0-0:123::,ON; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.83 SET-SID: Set System Identification

Use this command to change the NE system identification code to a specific value. The hostname on the device is changed to this value.

| Section | SET-SID Description |
|------------------|---|
| Category | Generic NE configuration |
| Security | Retrieve |
| Related Messages | 3.40 INIT-SYS: Initialize System |
| Input Format | SET-SID:[<tid>]::<ctag>::<SID>; Where: <tid> is the target identifier. <ctag> is the correlation tag. <sid> is the system identifier. |
| Input Example | To change the NE system identification code to a specific value, use the following: SET-SID:ons155xx::123::ons155xx-tl1; |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.84 SET-TH-rr: Set Optical Threshold

Use this command to set a threshold level on the monitored optical parameters. Each monitored parameter has a default threshold value assigned to it.

When this command is used with no attributes specified, it restores the default values.

| Section | SET-TH-rr Description |
|------------------|---|
| Category | Optical parameter monitoring |
| Security | Retrieve |
| Related Messages | 3.77 RTRV-TH-rr: Retrieve Threshold 3.76 RTRV-THR-OCH: Retrieve Thresholds OCH 3.32 ENT-THR-OCH: Enter Thresholds OCH |

| Section | SET-TH-rr Description (continued) |
|---------------|--|
| Input Format | <p>SET-TH-rr:[<tid>]:[<aid>]:<ctag>:[<montype>],[<thlev>],[<dirn>];</p> <p>Where:</p> <ul style="list-style-type: none"> • rr is OCH. • <tid> is the target identifier. • <aid> indicates wavepatch or waveetherphy interfaces on which the threshold is to be set. When the second modifier is set to OCH, valid values are WAVEPATCH-slot-subcard-port or WAVEETHERPHY-slot-subcard. Thresholds for Ex parameters can be configured only on the WAVEPATCH-slot-subcard-port interfaces. Thresholds for the transmit parameters can be configured only on the WAVEETHERPHY-slot-subcard interfaces. • <montype> specifies one of the following threshold types: <ul style="list-style-type: none"> – OPRHA - Receive optical power level corresponding to the high alarm threshold. If the optical power level is greater than the threshold associated with this parameter, an alarm is generated. – OPRLA - Receive optical power level corresponding to the low alarm threshold. If the optical power level is less than the threshold associated with this parameter, an alarm is generated. – OPRHW - Receive optical power level corresponding to the high warning threshold. If the optical power level is greater than the threshold associated with this parameter, a warning is generated that may be reported using REPT EVT. – OPRLW - Receive optical power level corresponding to the low warning threshold. If the optical power level is less than the threshold associated with this parameter, a warning is generated that may be reported using the REPT EVT. |
| Input Example | <p>To configure a high alarm threshold of 20.0 dBm on the received optical power at the wavepatch interface in slot 8, port 0, use the following:</p> <pre>SET-TH-OCH:ons155xx:WAVEPATCH-8-0-0:123::OPRHA,200,,RCV;</pre> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.85 SQUEEZE-MEM: Squeeze Memory

Use this command to permanently delete files and defragment the file system on a Flash memory device.

| Section | SQUEEZE-MEM Description |
|------------------|---|
| Category | Memory Management |
| Security | Retrieve |
| Related Messages | <p>3.5 CPY-MEM: Copy Memory</p> <p>3.34 FORMAT-MEM: Format Memory</p> <p>3.47 RST-MEM: Restore Memory</p> <p>3.62 RTRV-MEM: Retrieve Memory</p> |

| Section | SQUEEZE-MEM Description (continued) |
|---------------|--|
| Input Format | <p>SQUEEZE-MEM:[<tid>]:<aid>:<ctag>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the memory device that is being defragmented. Valid values are BOOTFLASH, DDISK-[0-1], PCMCIA-[0-1], SBY-BOOTFLASH, SBY-DISK-[0-1], or SBY-PCMCIA-[0-1]. • <ctag> is the correlation tag. |
| Input Example | <p>To delete files and defragment the file system on a Flash memory device, use the following:</p> <p>SQUEEZE-MEM:ons155xx:BOOTFLASH:123;</p> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |

3.86 SW-DX-EQPT: Switch Duplex Equipment

Use this command to switch activity from the active to the standby processor card.

| Section | SW-DX-EQPT Description |
|------------------|---|
| Category | Redundancy configuration |
| Security | Maintenance |
| Related Messages | <p>3.3 ALW-SWDX-EQPT: Allow Switch Duplex Equipment</p> <p>3.36 INH-SWDX-EQPT: Inhibit Switch Duplex Equipment</p> |
| Input Format | <p>SW-DX-EQPT:[<tid>]:<aid>:<ctag>::<mode>;</p> <p>Where:</p> <ul style="list-style-type: none"> • <tid> is the target identifier. • <aid> indicates the active processor card. Valid values are SLOT-6 or SLOT-7. • <ctag> is the correlation tag. • <mode> indicates the mode of operation. Valid values are FRCD and NORMAL. The default mode is NORMAL. |
| Input Example | <p>To forcibly make the active processor card in slot 6 switch to standby mode, use the following:</p> <p>SW-DX-EQPT:ons155xx:SLOT-6:123::FRCD;</p> |
| Errors | Errors are listed in Table 2-15 on page 2-9 . |



A

access identifier. See AID

ACT-USER command [3-1](#)

AID

15530 list [2-7](#)

command syntax [1-3](#)

description [1-3](#)

alarm codes

critical [1-4](#)

description [1-4](#)

major [1-4](#)

minor [1-4](#)

non-alarm [1-4](#)

ALW-MSG-ALL [3-2](#)

ALW-MSG-ALL command [3-2](#)

ALW-SWDX-EQPTcommand [3-2](#)

ATAG

description [1-4](#)

format (figure) [1-4](#)

autonomous message tag. See ATAG

C

CANC-USER command [3-3](#)

command completion behavior [1-6](#)

COMPLD [1-6](#)

DENY [1-6](#)

PRTL [1-6](#)

command length [3-1](#)

correlation tag. See CTAG

CPY-MEM command [3-3](#)

CTAG

command syntax [1-3](#)

description [1-3, 2-1](#)

D

default values

BLSR [2-4, 2-5, 2-6, 2-7](#)

DLT-FFP-OCH command [3-4](#)

DLT-IP command [3-5](#)

DLT-IPROUTE-STATIC command [3-6](#)

DLT-MEM command [3-7](#)

DLT-NBR command [3-7](#)

DLT-NTPASSOC command [3-8](#)

DLT-PATCH command [3-9](#)

DLT-THR-OCH command [3-11](#)

DLT-USER-SECU command [3-12](#)

documentation

conventions [xviii](#)

organization [xvii](#)

purpose [xvii](#)

related [xviii](#)

E

ED-FFP-OCH command [3-13](#)

ED-GBE10 command [3-15](#)

ED-IP command [3-17](#)

ED-NE-CDP command [3-17](#)

ED-NE-GEN command [3-18](#)

ED-NE-OSCP command [3-19](#)

ED-OCH command [3-19](#)

ED-PID command [3-23](#)

ED-THR-OCH command [3-24](#)
 ED-USER-SECU command [3-25](#)
 ENT-FFP-OCH command [3-26](#)
 ENT-IP command [3-28](#)
 ENT-IPROUTE-STATIC command [3-29](#)
 ENT-NBR command [3-29](#)
 ENT-NTPASSOC command [3-31](#)
 ENT-PATCH command [3-32](#)
 ENT-THR-OCH command [3-33](#)
 ENT-USER-SECU command [3-35](#)

errors

- description [2-8](#)
- list [2-9](#)

F

FORMAT-MEM command [3-35](#)

I

INH-MSG-ALL command [3-36](#)
 INH-SWDX-EQPT command [3-37](#)
 INIT-REG-ETH command [3-37](#)
 INIT-REG-GBE10 command [3-38](#)
 INIT-REG-OCH command [3-38](#)
 INIT-SYS command [3-39](#)

M

maintenance. See security levels

mixed mode

- timing [1-6](#)

mixed mode timing

- support [1-6](#)

O

OPR-LPBK-GBE10 command [3-39](#)
 OPR-LPBK-OCH command [3-40](#)
 OPR-PROTNSW-OCH command [3-41](#)

P

parameter types [2-1 to ??](#)
 provisioning see security levels

R

retrieve see security levels

RLS-LPBK-GBE10 command [3-42](#)
 RLS-LPBK-OCH command [3-42](#)
 RLS-PROTNSW-OCH command [3-43](#)
 RST-MEM command [3-43](#)
 RST-NE-CDP command [3-44](#)
 RTRV-ALM-ALL command [3-45](#)
 RTRV-ALM-ENV command [3-46](#)
 RTRV-ATTR-OCH command [3-47](#)
 RTRV-CDPNBR-OCH command [3-48](#)
 RTRV-COND-ALL command [3-50](#)
 RTRV-EQPT command [3-50](#)
 RTRV-FFP-OCH command [3-54](#)
 RTRV-FILE command [3-56](#)
 RTRV-GBE10 command [3-58](#)
 RTRV-HDR command [3-60](#)
 RTRV-IP command [3-61](#)
 RTRV-IPROUTE command [3-61](#)
 RTRV-LOG command [3-62](#)
 RTRV-MEM command [3-63](#)
 RTRV-NBR command [3-65](#)
 RTRV-NE-CDP command [3-65](#)
 RTRV-NE-GEN command [3-66](#)
 RTRV-NE-OSCP command [3-67](#)
 RTRV-NTPASSOC command [3-69](#)
 RTRV-NTP command [3-68](#)

RTRV-OCH command [3-70](#)
 RTRV-PATCH command [3-72](#)
 RTRV-PM-ENCAP command [3-74](#)
 RTRV-PM-EQPT command [3-76](#)
 RTRV-PM-GBE10 command [3-77](#)
 RTRV-PMMODE-OCH command [3-79](#)
 RTRV-TH-OCH command [3-83](#)
 RTRV-THR-OCH command [3-81](#)
 RTRV-TOD command [3-84](#)
 RTRV-USER-SECU command [3-84](#)
 RTRV-VOA command [3-85](#)

S

security
 default time outs [1-6](#)
 user [1-5](#)
 security levels [1-6](#)
 maintenance [1-6](#)
 provisioning [1-6](#)
 retrieve [1-6](#)
 superuser [1-6](#)
 sessions
 login [1-2](#)
 opening [1-2](#)
 supported [1-1](#)
 SET-ATTR-OCH command [3-86](#)
 SET-NTP command [3-88](#)
 SET-PMMODE-OCH command [3-88](#)
 SET-SID command [3-89](#)
 SET-TH-OCH command [3-89](#)
 SET-VOA command [3-91](#)
 specification characters
 description [1-3](#)
 SQUEEZE-MEM command [3-92](#)
 superuser see security levels
 SW-DX-EQPT command [3-92](#)

T

target identifier. See TID
 TID
 command syntax [1-3](#)
 description [1-3, 2-1](#)
 timing
 mixed mode [1-6](#)
 TL1
 accessing [1-2](#)
 command syntax [1-3](#)
 description [1-1](#)
 setting up [1-2](#)
 Transaction Language One. See TL1

U

UID
 command syntax [1-3](#)
 description [1-3](#)
 user identifier. See UID

